Frigidaire EAF350

Frigidaire Digital Air Fryer EAF350 User Manual

Model: EAF350

Introduction

This manual provides essential instructions for the safe and efficient operation of your Frigidaire Digital Air Fryer, Model EAF350. Please read this manual thoroughly before first use and retain it for future reference. This appliance is designed for household use only.

Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.

Product Overview

The Frigidaire Digital Air Fryer EAF350 is a 3.7-quart capacity appliance designed for air frying, baking, roasting, and more. It features a digital touch control panel for precise time and temperature adjustments, along with six smart presets for common dishes.

Components

- Main Unit with Digital Control Panel
- Removable Frying Basket
- Crisper Tray (nonstick)
- Handle for Frying Basket

Control Panel

The digital control panel allows you to select cooking functions, adjust time and temperature, and start/stop the cooking process.



Image 1: Front view of the Frigidaire Digital Air Fryer EAF350, showcasing the digital control panel with various preset icons and time/temperature controls.

Setup and First Use

1. **Unpacking:** Carefully remove all packaging materials and promotional labels from the air fryer.
2. **Cleaning:** Wash the frying basket and crisper tray with hot water, dish soap, and a non-abrasive sponge. Wipe the inside and outside of the appliance with a damp cloth. Ensure all parts are completely dry before use.
3. **Placement:** Place the air fryer on a stable, heat-resistant, and level surface. Ensure there is at least 4 inches

(10 cm) of clear space around the back and sides of the appliance to allow for proper ventilation. Do not place it directly against a wall or under cabinets.

4. **Power Connection:** Plug the power cord into a grounded wall outlet. The appliance is now ready for use.
5. **Initial Run (Optional):** For the first use, it is recommended to run the air fryer empty for about 10-15 minutes at 350°F (175°C) to eliminate any manufacturing odors. A slight odor may be present, which is normal and will dissipate.

Operating Instructions

General Operation

1. Pull the frying basket out of the appliance.
2. Place ingredients into the frying basket. Do not exceed the MAX fill line.
3. Slide the frying basket back into the air fryer. Ensure it clicks securely into place.
4. Press the Power button to turn on the appliance.
5. Select a preset function or manually set the time and temperature.
6. Press the Start/Pause button to begin cooking.
7. During cooking, you may pull out the basket to shake or flip ingredients. The air fryer will pause automatically and resume when the basket is reinserted.
8. Once cooking is complete, the timer will beep. Carefully pull out the basket and remove the cooked food.

Using Smart Presets

The Frigidaire EAF350 features 6 smart presets for convenience:

- **Fries:** Optimized for crispy French fries.
- **Bake:** Suitable for small baked goods.
- **Seafood:** Ideal for various seafood preparations.
- **Roast:** For roasting meats and vegetables.
- **Bacon:** Specific setting for cooking bacon.
- **Air Fry:** General air frying setting.

To use a preset, simply press the corresponding icon on the control panel. The appliance will automatically set the recommended time and temperature. You can adjust these settings manually after selecting a preset if desired.

Manual Time and Temperature Control

To manually set cooking parameters:

1. Press the Power button.
2. Use the Temperature control buttons (usually +/-) to set the desired temperature (range: 180°F - 400°F).
3. Use the Time control buttons (usually +/-) to set the desired cooking time.
4. Press the Start/Pause button to begin cooking.



Image 2: Angled view of the Frigidaire Digital Air Fryer EAF350 with its frying basket partially pulled out, revealing a batch of cooked French fries inside. This illustrates the appliance in use.

Cooking Guide and Tips

- **Preheating:** For best results, preheat the air fryer for 3-5 minutes at the desired cooking temperature before adding ingredients.
- **Oil Usage:** Many foods require little to no oil. For a crispier result, lightly toss ingredients with a small amount of oil (e.g., 1 tablespoon for 1 lb of food).
- **Shaking/Flipping:** For even cooking and browning, shake the basket or flip ingredients halfway through the cooking time, especially for smaller items like fries or chicken wings.
- **Batch Cooking:** Avoid overcrowding the basket. Cook in smaller batches if necessary to ensure proper air circulation and even cooking.
- **Doneness:** Always ensure food is cooked to a safe internal temperature. Refer to a food thermometer if unsure.

Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the life of your air fryer.

1. **Unplug and Cool:** Always unplug the air fryer from the power outlet and allow it to cool completely before cleaning.

2. **Frying Basket and Crisper Tray:** These parts are coated with nonstick material. Wash them with hot water, dish soap, and a non-abrasive sponge. For stubborn food residue, soak them in hot water for about 10 minutes before cleaning. **Note:** These parts are not dishwasher safe.
3. **Interior:** Wipe the interior of the appliance with a damp cloth. For heavy grease, use a mild detergent. Avoid abrasive cleaners or metal scouring pads.
4. **Exterior:** Wipe the exterior with a damp cloth. Do not immerse the main unit in water or any other liquid.
5. **Heating Element:** Use a cleaning brush to remove any food residue from the heating element.



Image 3: Angled view of the Frigidaire Digital Air Fryer EAF350 with its frying basket fully inserted and closed, showing the compact design of the appliance.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Air fryer does not turn on.	Appliance is not plugged in. Frying basket is not inserted correctly.	Ensure the power cord is securely plugged into a grounded outlet. Push the frying basket firmly into the appliance until it clicks into place.

Problem	Possible Cause	Solution
Food is not cooked evenly.	Basket is overcrowded. Food was not shaken/flipped.	Cook food in smaller batches. Shake or flip ingredients halfway through cooking.
White smoke coming from the appliance.	Grease residue from previous use. High fat content food.	Clean the basket and crisper tray thoroughly after each use. For high-fat foods, drain excess fat from the basket during cooking.
Food is not crispy.	Too much moisture in food. Not enough oil (for some foods).	Pat food dry before air frying. Lightly toss food with a small amount of oil.

Specifications

Model: EAF350

Capacity: 3.7 Quarts (3.5 Liters)

Wattage: 1200 Watts

Voltage: 120 Volts (AC)

Temperature Range: 180°F - 400°F

Control Method: Digital Touch

Material: Metal, Stainless Steel (with nonstick coating on basket/tray)

Item Weight: Approximately 16.3 Pounds

Dimensions: Approximately 13.25 x 13 x 12.88 inches (Package Dimensions)

Warranty and Support

For warranty information and customer support, please refer to the warranty card included with your purchase or visit the official Frigidaire website. Keep your proof of purchase for warranty claims.
Manufacturer: Frigidaire
UPC: 657768801778

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question