Braun 9556cc

Braun Series 9 Pro+ 9556cc Electric Shaver Instruction Manual

1. Introduction

Thank you for choosing the Braun Series 9 Pro+ 9556cc electric shaver. This advanced grooming device is engineered to provide an exceptionally close and comfortable shave. It integrates cutting-edge technologies such as a 5+1 cutting system, Sonic Vibration Technology, and Artificial Intelligence to adapt to your beard and skin.

This manual contains important information regarding the safe use, operation, maintenance, and troubleshooting of your new shaver and its accompanying 5-in-1 automatic cleaning station. Please read these instructions thoroughly before first use and retain them for future reference.



This image displays the Braun Series 9 Pro+ electric shaver, its protective travel case, and the accompanying 5-in-1 automatic cleaning and charging station. The shaver features a metallic silver finish with a black grip and digital display. The cleaning station is black with a blue indicator light.

2. Important Safety Information

To reduce the risk of electric shock, injury, or damage to the appliance, please observe the following safety precautions:

- This appliance is suitable for cleaning under running tap water. Do not immerse the shaver in water for extended periods.
- The cleaning station is not waterproof. Do not place it in water or use it near water.
- Always unplug the cleaning station before cleaning or maintenance.

- Do not use the appliance with a damaged foil or cord.
- Keep the appliance and its accessories out of reach of children.
- Only use the power supply provided with the appliance.
- Do not disassemble or attempt to repair the appliance yourself. Contact authorized service personnel for repairs.

3. Package Contents

Please check that all items are present in your package:

- Braun Series 9 Pro+ Electric Shaver
- Shaver Case
- 5-in-1 Automatic Alcohol Cleaning Station
- Cleaning Cartridge (x1)
- Power Cord
- Cleaning Brush
- Replacement Blade Set (Inner blade & Outer foil set)

4. Setup

4.1 Initial Charging

1. Connect the power cord to the shaver or the cleaning station.
2. Plug the power cord into an electrical outlet.
3. Allow the shaver to charge fully before its first use. A full charge typically takes approximately 1 hour and provides up to 60 minutes of cordless shaving. The display will indicate charging status.

4.2 Setting up the 5-in-1 Automatic Cleaning Station

1. Open the cleaning station by pressing the release button.
2. Remove the cleaning cartridge from its packaging.
3. Carefully insert the cleaning cartridge into the base of the cleaning station until it clicks into place.
4. Close the cleaning station lid.
5. Connect the cleaning station to the power cord and plug it into an electrical outlet.

5. Operating Instructions

5.1 Shaving

1. Ensure your shaver is charged.
2. Press the power button to turn on the shaver.
3. Hold the shaver at a right angle (90°) to your skin.
4. Stretch your skin and shave against the direction of beard growth.
5. The shaver's Artificial Intelligence Technology will automatically adjust power based on your beard density for an optimal shave.
6. After shaving, press the power button to turn off the shaver.

5.2 Using the Precision Trimmer (Edge Blade)

The integrated precision trimmer is ideal for shaping sideburns, mustaches, and for pre-trimming longer hairs.

1. Slide the precision trimmer upwards to activate it.
2. Use the trimmer to define lines or trim specific areas.
3. Slide the trimmer back down when finished.

5.3 Display Indicators

The shaver features a display that provides information such as battery level (indicated by a 5-segment light display) and cleaning status.

6. Cleaning and Maintenance

6.1 Using the 5-in-1 Automatic Cleaning Station

The cleaning station automatically cleans, lubricates, dries, charges, and hygienically stores your shaver, ensuring it remains like new for up to 18 months. It removes sebum and other dirt that cannot be removed by water alone, achieving 99.9% sterilization.

1. After shaving, ensure the shaver is turned off.
2. Place the shaver head-down into the cleaning station.
3. Press the start button on the cleaning station. The cleaning cycle will begin automatically.
4. The cleaning station will clean, dry, and charge the shaver. The process may take several hours.

6.2 Manual Cleaning

For quick cleaning or when the cleaning station is not available:

1. Turn off the shaver and disconnect it from the power supply.
2. Remove the shaver head.
3. Tap out any loose hair clippings.
4. Rinse the shaver head and the inner cutting elements under warm running water. You may use a mild liquid soap.
5. Use the provided cleaning brush to remove stubborn hair particles from the inner cutting elements. Do not use the brush on the shaver foil, as this may damage it.
6. Allow the shaver head and cutting elements to air dry completely before reattaching.

6.3 Replacing the Cleaning Cartridge

Replace the cleaning cartridge when the indicator light on the cleaning station signals it, or approximately every 3 months with regular use.

1. Unplug the cleaning station from the power outlet.
2. Open the cleaning station lid.
3. Carefully remove the used cartridge and dispose of it responsibly.
4. Insert a new Braun Clean & Renew cleaning cartridge.
5. Close the lid and plug the station back in.

7. Replacement Parts

To maintain optimal shaving performance, it is recommended to replace the shaver head (foil and cutter block) approximately every 18 months, or when the shaving performance noticeably decreases.

- **Replacement Shaver Head:** Refer to your shaver model for the correct replacement part number.
- **Cleaning Cartridges:** Use only genuine Braun Clean & Renew cartridges.

8. Troubleshooting

Problem	Possible Cause	Solution
Shaver does not turn on.	Battery is depleted.	Charge the shaver for at least 5 minutes or until fully charged.
Poor shaving performance.	Shaver head is worn or dirty.	Clean the shaver head thoroughly or replace it if worn.
Cleaning station indicator light is on/blinking.	Cleaning cartridge needs replacement.	Replace the cleaning cartridge.
Shaver display shows an error.	Internal malfunction.	Turn off the shaver, wait a few seconds, and turn it back on. If the error persists, contact customer support.

9. Specifications

- **Model:** Braun Series 9 Pro+ 9556cc
- **Power Source:** Rechargeable Battery
- **Blade Material:** Stainless Steel
- **Head Type:** Foil Shaver
- **Number of Blades:** 5
- **Special Features:** Sonic Vibration Technology, Artificial Intelligence Technology, Braun's Unique Alcohol Cleaning System
- **Dimensions (Package):** 26 x 18 x 16 cm
- **Weight (Package):** 1.4 kg
- **Manufacturer Reference:** 4987176165701

10. Warranty and Support

For warranty information, product registration, or technical support, please refer to the warranty card included in your package or visit the official Braun website for your region. You can also contact Braun customer service directly for assistance with any product-related inquiries.

Online Support: www.braun.com

© 2023 Braun. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

What is the sliding button located above the power switch on the Braun Series 9 Pro+ 9556cc, and how does its position affect the shaving experience?

The sliding button located above the power switch on the Braun Series 9 Pro+ 9556cc is the MultiHeadLock switch. This switch is used to lock the pivoting shaver head into a fixed position for...

Read full answer