Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Nilfisk 128500724

Nilfisk Patio Cleaner Instruction Manual

Model: 128500724
Brand: Nilfisk

1. Product Overview

The Nilfisk Patio Cleaner is an essential attachment designed for high-pressure washers, specifically engineered to efficiently clean various outdoor surfaces. It features an adjustable pressure control and a unique rotating jet system to ensure uniform and thorough cleaning results.

- **Patio Cleaning:** Ideal for banishing dirt and mold from patios, decks, pavements, paths, and driveways.
- **Vertical Surface Cleaning:** Can also be used effectively on vertical surfaces such as walls, fences, and garage doors.
- **Uniform Cleaning:** The integrated skirt and anti-splash cover contain dirt and water, while two rotating jets provide 360-degree cleaning for consistent, homogeneous results.
- **Conical Action:** Ensures that all ridges and uneven angles are thoroughly cleaned.
- **Adjustable Pressure Control:** Allows for cleaning both delicate and rough surfaces by adjusting the pressure at the top of the cleaner.



Figure 1: Nilfisk Patio Cleaner, showing its blue cleaning head and black handle.



Figure 2: Top view of the patio cleaner illustrating its multipurpose use on wood, concrete, stone, outdoor walls, and fences, along with its pressure control and Click&Clean coupling.

2. Setup and Assembly

Before using the Nilfisk Patio Cleaner, ensure your high-pressure washer is properly set up and connected to a water supply. The patio cleaner connects directly to the high-pressure washer lance.

1. **Unpack Components:** Carefully remove all parts from the packaging.
2. **Connect to Lance:** Attach the Nilfisk Patio Cleaner to the end of your high-pressure washer's lance. Ensure a secure connection. For models with Click&Clean coupling, simply click it into place.
3. **Check Compatibility:** Verify that your pressure washer is compatible with this patio cleaner. This model is compatible with Nilfisk Dynamic, Compact, Core, and Excellent high-pressure washers. It is **not** compatible with Nilfisk Premium pressure washers.

	NILFISK COMPACT	NILFISK CORE	NILFISK EXCELLENT	NILFISK PREMIUM
Compact Patio Cleaner Reference number: 128501216 Click&Clean coupling	✓	✓	✓	✗
Mid Patio Cleaner Reference number: 128500724 Click&Clean coupling	✓	✓	✓	✗
Power Patio Cleaner Reference number: 128500954 Bayonet coupling	✓	✓	✓	✓
Super Foam Sprayer Reference number: 128500938 Click&Clean coupling	✓	✓	✓	✗
Power Foam Sprayer Reference number: 128501703 Bayonet coupling	✓	✓	✓	✓

Figure 3: Compatibility chart showing the Nilfisk Mid Patio Cleaner (Reference number: 128500724) is compatible with Nilfisk Compact, Core, and Excellent pressure washers, but not Premium models.

3. Operating Instructions

Follow these steps for effective and safe operation of your Nilfisk Patio Cleaner.

1. **Prepare the Surface:** Clear the area to be cleaned of any loose debris, furniture, or obstacles.
2. **Start Pressure Washer:** Turn on your high-pressure washer according to its own instruction manual.
3. **Adjust Pressure:** Use the adjustable pressure control dial located on the top of the patio cleaner to select the appropriate pressure setting for your surface.
    - Lower pressure for delicate surfaces like wooden decks.
    - Higher pressure for tougher surfaces like stone floors or bricks.
4. **Begin Cleaning:** Place the patio cleaner flat on the surface to be cleaned. Squeeze the trigger on your pressure washer lance to start the water flow. Move the patio cleaner slowly and steadily over the surface in overlapping passes to ensure even cleaning.
5. **Clean Evenly:** The rotating jets and anti-splash cover ensure uniform cleaning without splashing dirt onto surrounding areas.



Figure 4: The patio cleaner effectively cleaning an outdoor tiled surface, demonstrating its anti-splash design.



Figure 5: A user demonstrating the use of the patio cleaner on a vertical wall, highlighting its versatility.

4. Maintenance and Storage

Proper maintenance and storage will extend the life of your Nilfisk Patio Cleaner.

- **After Each Use:** Disconnect the patio cleaner from the pressure washer. Rinse the cleaning head thoroughly with clean water to remove any dirt or debris.
- **Inspect Nozzles:** Periodically check the rotating nozzles for blockages. If blocked, clear them carefully using a small pin or the nozzle cleaning tool provided with your pressure washer (if applicable).
- **Storage:** Store the patio cleaner in a clean, dry place, away from direct sunlight and extreme temperatures. Ensure it is completely dry before storing to prevent mold or mildew growth.
- **Winter Storage:** If storing in freezing conditions, ensure all water is drained from the unit to prevent damage from ice expansion.

5. Troubleshooting

If you encounter issues while using your Nilfisk Patio Cleaner, refer to the following common solutions:

Problem	Possible Cause	Solution
Uneven cleaning or streaks	Blocked nozzles or too fast movement.	Clean the nozzles. Move the patio cleaner more slowly and ensure overlapping passes.
No water flow or low pressure	Water supply issue, pressure washer not fully on, or severe nozzle blockage.	Check water supply and pressure washer operation. Clean nozzles thoroughly.
Excessive splashing	Patio cleaner not flat on surface or skirt damaged.	Ensure the cleaner is flat against the surface. Inspect the skirt for damage and replace if necessary.

If the problem persists, consult your high-pressure washer's manual or contact Nilfisk customer support.

6. Specifications

- **Model Number:** 128500724
- **Brand:** Nilfisk
- **Color:** Black (with blue cleaning head)
- **Item Weight:** Approximately 450 Grams (15.9 ounces)
- **Product Dimensions:** Approximately 0.39"L x 0.39"W x 0.39"H (*Note: These dimensions appear to be generic placeholder values. The actual product is larger.*)
- **Maximum Pressure:** Compatible with pressure washers up to 1300 PSI (Pound per Square Inch)
- **Compatibility:** Nilfisk Dynamic, Compact, Core, and Excellent high-pressure washers. Not compatible with Nilfisk Premium pressure washers.

7. Warranty and Support

Nilfisk products are designed for durability and effectiveness. For information regarding warranty coverage, product registration, or technical support, please refer to the documentation included with your original pressure washer or visit the official Nilfisk website.
For over a century, Nilfisk has been committed to developing premium quality cleaning solutions, constantly innovating to create durable and highly effective products.

© 2025 Nilfisk. All rights reserved.
For more information, visit www.nilfisk.com

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CQPG3T3C

More documents and user manuals: **https://manuals.plus/**