Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Dpofirs Dpofirsfnvb9p24sd-15

Dpofirs 1080p HD Digital Camera User Manual

Model: Dpofirsfnvb9p24sd-15

1. Introduction

Thank you for choosing the Dpofirs 1080p HD Digital Camera. This manual provides essential information for the safe and effective operation of your device. Please read it thoroughly before use and retain it for future reference.
This digital camera is designed for capturing high-definition photos and videos, featuring a 16MP sensor, 1080p video resolution, 16x digital zoom, and a convenient 2.4-inch rotatable LCD screen. It includes a built-in fill light for improved low-light performance and supports various functions like electronic anti-shake and loop recording.

2. Safety Information

- Do not expose the camera to water or moisture.
- Avoid dropping the camera or subjecting it to strong impacts.
- Keep the camera away from extreme temperatures and direct sunlight.
- Do not attempt to disassemble or modify the camera. Repairs should only be performed by qualified personnel.
- Use only the specified battery type (BL-5C) and charging cable.
- Ensure proper ventilation when charging the camera.
- Keep out of reach of children.

3. Package Contents

Verify that all items are present in your package:

- 1 x Dpofirs 1080p HD Digital Camera
- 1 x USB Charging Cable
- 1 x User Manual



Image: The Dpofirs 1080p HD Digital Camera shown alongside its included USB charging cable.

4. Product Overview

Familiarize yourself with the camera's components and controls.



Image: Front view of the Dpofirs digital camera with the LCD screen folded and closed, showing the lens and branding.



Image: The Dpofirs digital camera with its rotatable LCD screen opened, providing a clear view of the camera's front and side.



Image: Close-up view of the camera's side, highlighting the control buttons, speaker grille, and USB port.

5. Setup

5.1. Battery Installation and Charging

The camera includes a built-in BL-5C lithium battery. Ensure it is charged before first use.

1. Connect the camera to a power source using the provided USB cable.
2. The charging indicator will illuminate. Once fully charged, the indicator may change color or turn off.

5.2. Memory Card Installation

This camera supports standard memory cards up to 32GB (not included).

1. Locate the memory card slot, typically on the side or bottom of the camera.
2. Insert the memory card into the slot with the correct orientation until it clicks into place.
3. To remove, gently push the card until it springs out.

5.3. Initial Power On

After installing the memory card and ensuring the battery is charged:

1. Open the LCD screen.
2. Press and hold the power button for 2-3 seconds to turn on the camera.

6. Operating Instructions

6.1. Power On/Off

- **Power On:** Open the LCD screen and press the power button.
- **Power Off:** Press and hold the power button until the camera shuts down, or close the LCD screen.

6.2. Photo Mode

1. Turn on the camera. It typically defaults to photo mode.
2. Frame your shot using the rotatable LCD screen.
3. Press the Shutter button to capture a photo.

6.3. Video Mode

1. Turn on the camera.
2. Press the Mode button to switch to video recording mode.
3. Press the Record button (often the same as Shutter) to start recording. Press again to stop.
4. The camera supports recording while charging.

6.4. Zoom Function

Use the zoom controls (usually a rocker switch) to adjust the 16x digital zoom. Zoom in to magnify subjects or zoom out for a wider field of view.

6.5. Fill Light

The camera features a built-in fill light on the front. Activate it in low-light conditions to illuminate your subject for clearer photos and videos.

6.6. Playback Mode

1. In operating mode, press the Mode button to switch to playback mode.
2. Use the navigation buttons to browse through your captured photos and videos.
3. Press the OK/Play button to view a selected item.

6.7. Connecting to a Computer (USB)

To transfer files, connect the camera to your computer using the provided USB cable.

1. Ensure the camera is powered on.

2. Connect one end of the USB cable to the camera's USB port and the other end to your computer.
3. The camera will appear as a removable disk drive on your computer, allowing you to access and transfer files.

7. Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the camera body. For the lens and LCD screen, use a specialized lens cleaning cloth and solution. Do not use abrasive cleaners.
- **Storage:** When not in use for extended periods, store the camera in a cool, dry place, away from dust and direct sunlight. Remove the memory card if not needed.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge it regularly, even if not in use.

8. Troubleshooting

Problem	Possible Cause	Solution
Camera does not power on.	Battery is depleted or not properly inserted.	Charge the battery. Ensure the battery is correctly inserted.
Cannot take photos/videos.	Memory card is full, not inserted, or corrupted.	Insert a memory card. Delete unnecessary files or format the card (this will erase all data).
Images are blurry.	Lens is dirty, insufficient light, or camera shake.	Clean the lens. Use the fill light in low light. Hold the camera steady or use electronic anti-shake.
Computer does not recognize camera.	USB cable issue or camera not in correct mode.	Try a different USB port or cable. Ensure the camera is powered on when connected.

9. Specifications

Feature	Specification
Image Resolution	1MP, 2MP, 3MP, 5MP, 12MP, 16MP
Image Format	JPG
Video Resolution	1080p (maximum)
Video Format	AVI
Screen Size	2.4 inches (Rotatable LCD)
Digital Zoom	16x
Shutter	Electronic
Storage	Supports standard memory card up to 32GB (not included)

Feature	Specification
Battery	1 x BL-5C Lithium Battery, 600 mAh (built-in)
Connectivity	USB
Special Features	Electronic Anti-shake, Loop Recording, Time Watermark, External Microphone Support, Recording Pause, Fill Light
Compatible Devices	Personal computer, laptop
Languages	17 languages

10. Warranty and Support

This Dpofirs product is covered by a standard manufacturer's warranty. For specific warranty terms and conditions, please refer to the documentation provided at the time of purchase or contact your retailer.
For technical support, troubleshooting assistance, or inquiries regarding your Dpofirs 1080p HD Digital Camera, please contact Dpofirs customer service through the retailer's platform or the official brand website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CQX5JX7S

More documents and user manuals: **https://manuals.plus/**