Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Metz 50MUD7000Z

Metz Smart TV 50MUD7000Z User Manual

Model: 50MUD7000Z | Brand: Metz

Introduction

This user manual provides comprehensive instructions for the setup, operation, maintenance, and troubleshooting of your Metz Smart TV 50MUD7000Z. Please read this manual thoroughly before using your television to ensure proper and safe operation. Keep this manual for future reference.

Safety Information

Always observe the following safety precautions to avoid electric shock, fire, or damage to the TV.

- **Power Source:** Ensure the TV is connected to an AC 100-240V, 50/60Hz power supply. Use the provided power cord.
- **Ventilation:** Do not block ventilation openings. Allow adequate space around the TV for proper airflow.
- **Water and Moisture:** Do not expose the TV to rain or moisture. Do not place objects filled with liquids, such as vases, on the TV.
- **Cleaning:** Unplug the TV before cleaning. Use a soft, dry cloth. Do not use liquid cleaners or aerosol cleaners.
- **Mounting:** When mounting the TV on a wall, ensure the wall mount is suitable for the TV's weight and that installation is performed by qualified personnel. The TV is compatible with VESA 20 x 20 cm mounts.

Package Contents

Verify that all items are included in the package:

- Metz Smart TV 50MUD7000Z
- Remote Control
- Power Cable
- TV Stands (Bases)
- User Manual (this document)

Setup

1. Attaching the Stands

Carefully place the TV face down on a soft, clean surface to prevent scratches. Align the stands with the screw holes on the bottom of the TV and secure them with the provided screws.

2. Connecting Peripherals

Connect your external devices such as set-top boxes, gaming consoles, or Blu-ray players to the appropriate ports on the TV.

- **HDMI Ports:** For high-definition video and audio. The TV features multiple HDMI inputs.
- **USB Ports:** For connecting USB storage devices (e.g., flash drives) for media playback. The TV has 2 USB ports.
- **RJ45 (Ethernet) Port:** For a wired internet connection.
- **Antenna/Cable Input:** For connecting an antenna or cable TV signal. The TV includes a DVB-T2 tuner.

3. Powering On

Plug the power cable into the TV's power input and then into a wall outlet. Press the power button on the TV or the remote control to turn on the TV.

4. Initial Setup Wizard

Upon first power-on, the TV will guide you through an initial setup wizard. This includes:

1. **Language Selection:** Choose your preferred language.
2. **Network Connection:** Connect to your Wi-Fi network or use a wired Ethernet connection. The TV supports Wi-Fi and Bluetooth connectivity.
3. **Channel Scan:** Scan for available TV channels via antenna or cable.
4. **Google Account Setup:** Sign in with your Google account to access Smart TV features, including Chromecast.



Image: Front view of the Metz Smart TV 50MUD7000Z, showcasing its slim bezels and stand.

Operating Instructions

Remote Control Functions

Familiarize yourself with the remote control buttons for easy navigation:

- **Power Button:** Turns the TV on or off.
- **Navigation Buttons (Up/Down/Left/Right):** For menu navigation.
- **OK/Enter Button:** Confirms selections.
- **Back Button:** Returns to the previous screen.
- **Home Button:** Accesses the Smart TV home screen (Google TV).
- **Volume Up/Down:** Adjusts the volume.
- **Channel Up/Down:** Changes TV channels.
- **Input/Source Button:** Selects input sources (HDMI, AV, TV).
- **Voice Control Button:** Activates hands-free voice control.

Smart TV Features (Google TV)

Your Metz Smart TV runs on Google TV, offering a personalized entertainment experience:

- **Content Aggregation:** Access movies, shows, and live TV from various streaming services in one place.
- **Personalized Recommendations:** Get suggestions based on your viewing history and subscriptions.
- **Chromecast Built-in:** Cast content from your smartphone, tablet, or computer directly to the TV.

- **Google Assistant:** Use voice commands to search for content, control smart home devices, and get answers.
- **App Store:** Download additional apps from the Google Play Store.

Picture and Sound Settings

Customize your viewing and listening experience:

- **Picture Modes:** Select from standard, vivid, movie, sport, or custom modes. The TV supports HDR LCD technology for enhanced contrast and color.
- **Sound Modes:** Choose from standard, music, movie, speech, or custom modes.
- **Eye Comfort Mode:** Reduces blue light emission for comfortable viewing, especially in low light.
- **Game Mode:** Optimizes settings for gaming, reducing input lag.



Image: The Metz Smart TV 50MUD7000Z integrated into a modern living room setup, demonstrating its aesthetic appeal.

Maintenance

Cleaning the TV

- **Screen:** Gently wipe the screen with a soft, lint-free cloth. For stubborn marks, slightly dampen the cloth with water or a specialized screen cleaner (do not spray directly on the screen).
- **Cabinet:** Wipe the TV cabinet with a soft, dry cloth.
- **Important:** Always unplug the TV before cleaning. Do not use abrasive cleaners, waxes, or solvents.

Software Updates

The TV may receive software updates to improve performance and add new features. Ensure your TV is connected to the internet to receive these updates automatically or check for them manually in the settings menu.

Troubleshooting

Refer to the following table for common issues and their solutions:

Problem	Possible Cause	Solution
No Power	Power cord not connected; outlet not working.	Check power cord connection; try a different outlet.
No Picture, Only Sound	Incorrect input source selected; external device issue.	Press the "Input" button on the remote to select the correct source; check external device connections.
No Sound, Only Picture	Volume muted or too low; external audio system issue.	Unmute volume or increase it; check audio cables to external system.
Remote Control Not Working	Batteries are dead or incorrectly inserted; obstruction.	Replace batteries; ensure correct polarity; remove obstructions between remote and TV.
Wi-Fi Connection Issues	Incorrect password; router issue; TV too far from router.	Re-enter password; restart router; move TV closer or use wired connection.
Smart TV Apps Not Loading	Internet connection issue; app cache full.	Check internet connection; clear app cache in TV settings.

If the problem persists after trying these solutions, please contact customer support.

Specifications

Feature	Detail
Model Number	50MUD7000Z
Screen Size	50 inches (127 cm diagonal)
Display Technology	4K Ultra HD HDR LCD
Resolution	3840 x 2160 pixels
Refresh Rate	60 Hz
Tuner	DVB-T2
Connectivity	Wi-Fi, Bluetooth, HDMI, RJ45, USB (2 ports)
Smart TV Platform	Google TV with Chromecast built-in
Special Features	Chromecast, Game Mode, Eye Comfort Mode, Hands-free Voice Control, Flicker Free, Low Blue Light
VESA Compatibility	20 x 20 cm

Feature	Detail
Energy Class	F
Dimensions (with stand)	Approx. 9P x 96W x 63H cm

Warranty and Support

Metz provides a standard manufacturer's warranty for this product. Please refer to the warranty card included in your product packaging for specific terms and conditions, including warranty duration and coverage.
For technical support, service, or warranty claims, please contact Metz customer service. Contact information can typically be found on the Metz official website or in the warranty documentation.
Note: Availability of spare parts and software updates beyond a certain period may vary. Please check the latest information from the manufacturer.

© 2025 Metz. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CQYLRP3Y

More documents and user manuals: **https://manuals.plus/**