Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LEXiBOOK TLN10EN

Lexibook Lexipad® 10" Edutainment Tablet User Manual

Model: TLN10EN | Brand: LEXiBOOK

Introduction

The Lexibook Lexipad® 10" is an edutainment tablet designed for family use, powered by Android™. It features a 10-inch HD touch screen, an A523 Octa-core processor, and 4 GB of RAM, offering a blend of educational content, games, and entertainment. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your Lexipad® 10" tablet.



Image: The Lexibook Lexipad 10" tablet shown with its retail packaging, highlighting its design and the included protective case.

What's in the Box

Please verify that all items are present in your package:

- 1 Lexibook Lexipad® 10" tablet
- 1 Protective case
- 1 Instruction manual (this document)

Setup

1. **Charging the Tablet:** Before first use, fully charge the tablet using the provided USB-C charging cable and power adapter. Connect the USB-C end to the tablet's charging port and the other end to a power outlet. The charging indicator will show progress.
2. **Powering On:** Press and hold the power button (usually located on the side or top edge) until the Lexibook logo appears on the screen.
3. **Initial Setup Wizard:** Follow the on-screen prompts to complete the initial setup. This typically includes selecting your language, connecting to a Wi-Fi network, accepting terms and conditions, and setting up a Google account (optional, but recommended for app access).
4. **Installing the Protective Case:** Carefully fit the protective case around the tablet. Ensure all ports and buttons are accessible and the case provides a snug fit to protect against accidental drops.
5. **Parental Control Setup:** For child users, it is highly recommended to set up parental controls. The Lexipad® 10" includes full parental control features and the Qwant Junior secure web browser. Access these settings through the tablet's system settings or dedicated parental control application to manage screen time, restrict content, and monitor usage.

Operating Instructions

Basic Navigation

- **Touch Screen:** Navigate the tablet using touch gestures such as tap, swipe, pinch-to-zoom, and long-press.
- **Home Screen:** The main screen where you can access installed applications and widgets.
- **Notification Bar:** Swipe down from the top of the screen to access notifications and quick settings.
- **Navigation Buttons:** Typically located at the bottom of the screen (Back, Home, Recent Apps).

Applications and Content

The Lexipad® 10" offers a wide range of pre-installed and downloadable content:

- **Educational Content:** Access quizzes on various themes (maths, arts, etc.), an extensive library of classics, and the "Power Academy®" app for school curriculum support.
- **Games and Apps:** Download thousands of Android™ games and apps via the Google Play Store™.
- **Entertainment:** Utilize Google Suite, YouTube®, and other entertainment applications.
- **Camera Functionality:** Use the 5MP rear camera for photos and the 2MP front camera for video conferences.



Image: A close-up view of the Lexibook Lexipad 10" screen, displaying a grid of colorful application icons, including educational apps, games, and utility tools.

Connectivity

- **Wi-Fi:** Connect to wireless networks for internet access. Go to Settings > Network & internet > Wi-Fi.
- **Bluetooth® 5.0:** Pair with Bluetooth-enabled devices like headphones or speakers. Go to Settings > Connected devices > Pair new device.
- **SD/TF Card Slot:** Insert a compatible memory card to expand storage.
- **Audio-out 3.5mm Port:** Connect wired headphones or external speakers.
- **USB-C Charging Port:** Used for charging and data transfer.



Image: A child comfortably seated on a couch, engrossed in using the Lexibook Lexipad 10" tablet, demonstrating its ease of use for young users.

Maintenance

- **Cleaning:** Use a soft, lint-free cloth to clean the screen and body of the tablet. Avoid abrasive cleaners or solvents.
- **Storage:** Store the tablet in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge it regularly and avoid leaving it plugged in for extended periods after it's fully charged.
- **Software Updates:** Periodically check for system updates to ensure optimal performance and security. Go to Settings > System > System update.
- **Protective Case:** Keep the protective case on the tablet to guard against bumps and scratches.

Troubleshooting

Problem	Possible Cause	Solution
Tablet does not turn on.	Low battery; system crash.	Charge the tablet for at least 30 minutes. Perform a forced restart by holding the power button for 10-15 seconds.
Screen is unresponsive.	Temporary software glitch.	Restart the tablet. If unresponsive, perform a forced restart.

Problem	Possible Cause	Solution
Wi-Fi connection issues.	Incorrect password; router issue; tablet Wi-Fi disabled.	Ensure Wi-Fi is enabled. Re-enter Wi-Fi password. Restart your Wi-Fi router.
Apps are crashing or freezing.	Insufficient RAM; app bug; outdated app.	Close background apps. Clear app cache (Settings > Apps > [App Name] > Storage > Clear cache). Update the app from Google Play Store.
Slow performance.	Too many apps running; low storage; outdated software.	Close unused apps. Free up storage space. Check for system updates.

Specifications

Feature	Detail
Model Name	TLN10EN
Brand	LEXiBOOK
Screen Size	10 Inches
Display Resolution Maximum	1920x1080 (HD)
Operating System	Android™
Processor	A523 Octa-core
RAM	4 GB
Connectivity	Bluetooth® 5.0, Wi-Fi
Ports	1 SD/TF card slot, 1 Audio-out 3.5mm port, 1 USB-C charging port
Cameras	5MP Rear, 2MP Front
Product Dimensions	10.24 x 0.39 x 7.09 inches
Item Weight	1.46 pounds
Recommended Age	6 years and up

Warranty and Support

Your Lexibook Lexipad® 10" is covered by a manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions, including the warranty period and coverage details.

For technical support, troubleshooting assistance, or warranty claims, please contact Lexibook customer service. Contact information can typically be found on the Lexibook official website or on the product packaging.

For additional resources and frequently asked questions, visit the official LEXiBOOK Store:LEXiBOOK Store on Amazon.

© 2024 LEXiBOOK. All rights reserved. Android and Google Play Store are trademarks of Google LLC. Bluetooth is a registered trademark of Bluetooth SIG, Inc.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CRVMWTLV

More documents and user manuals: **https://manuals.plus/**