Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Milex MCM006

Milex Fresh Coffee On The Go - Instruction Manual

Model: MCM006
Brand: Milex

Introduction

The Milex Fresh Coffee On The Go is a portable and efficient coffee maker designed to provide freshly brewed coffee. This manual provides essential information for the safe and effective operation, maintenance, and troubleshooting of your new appliance.

Important Safety Instructions

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against fire, electric shock, and injury to persons, do not immerse cord, plugs, or appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or injury to persons.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Exercise extreme caution when disposing of hot steam.
- The appliance features an automatic shut-off for safety.

Product Components





Figure 1: Overview of the Milex Fresh Coffee On The Go appliance, showing the main unit and the included travel cup.

Familiarize yourself with the various parts of your Milex Fresh Coffee On The Go:

1. **Water Tank:** Transparent reservoir for water, with clear level indicators (up to 450ml).
2. **Grinding/Brewing Chamber:** Top section containing the bean container and grinding blades.
3. **Removable Filter:** Located within the brewing chamber, for filtering coffee.
4. **Coffee Outlet:** Where brewed coffee dispenses.
5. **Control Panel:** Touch controls for operation.
6. **Drip Tray/Cup Stand:** Base for placing the coffee cup.
7. **Travel Coffee Cup:** Included 500ml capacity cup, designed to fit the appliance.
8. **Power Cord:** For connecting to an electrical outlet.

Setup

1. **Unpacking:** Carefully remove all packaging materials and inspect the appliance for any damage. Retain packaging for future storage or transport if needed.
2. **Initial Cleaning:** Before first use, wash the removable filter, travel coffee cup, and brewing chamber with warm, soapy water. Rinse thoroughly and dry. Wipe the exterior of the main unit with a damp cloth.
3. **Placement:** Place the coffee maker on a stable, flat, heat-resistant surface, away from the edge of the counter. Ensure there is adequate ventilation around the unit.
4. **Power Connection:** Plug the power cord into a standard electrical outlet.

Operating Instructions

Follow these steps to brew fresh coffee with your Milex Fresh Coffee On The Go:



Figure 2: The coffee maker in operation, dispensing freshly brewed coffee.

1. **Fill Water Tank:** Open the water tank lid and fill the water tank with fresh, cold water up to the desired level, not exceeding the 450ml MAX line. The water level indicator will assist you.
2. **Add Coffee:**
    - **For Whole Beans:** Add up to 28g of whole coffee beans into the bean container within the grinding/brewing chamber.
    - **For Ground Coffee:** If using pre-ground coffee, place the desired amount into the removable filter.
3. **Place Cup:** Position the included 500ml travel coffee cup or another suitable mug on the drip tray/cup stand directly beneath the coffee outlet.
4. **Select Brewing:** Use the touch controls on the control panel to select your desired brewing option (e.g., grind and brew, or brew only if using pre-ground coffee). Refer to the specific icons on your control panel.
5. **Start Brewing:** Press the start button. The appliance will begin the grinding process (if applicable) and then proceed with brewing.
6. **Automatic Shut-off:** Once brewing is complete, the appliance will automatically shut off for safety and energy

saving.

7. **Enjoy:** Carefully remove your freshly brewed coffee. Be cautious of hot surfaces and steam.

Cleaning and Maintenance

Regular cleaning ensures optimal performance and extends the lifespan of your coffee maker. Always unplug the appliance and allow it to cool completely before cleaning.



Figure 3: Side view highlighting the removable components for easy cleaning.

- **Removable Filter and Brewing Chamber:** After each use, remove the filter and the brewing chamber. Discard used coffee grounds. Wash these parts with warm, soapy water and rinse thoroughly. The non-stick coating facilitates easy cleaning.
- **Travel Coffee Cup:** Wash the travel cup after each use with warm, soapy water.
- **Water Tank:** The water tank can be rinsed with water. For thorough cleaning, use a bottle brush if necessary.
- **Exterior:** Wipe the exterior of the appliance with a soft, damp cloth. Do not use abrasive cleaners or scouring pads. Never immerse the main unit in water or any other liquid.

- **Descaling:** Depending on water hardness, mineral deposits may build up over time. Descale your coffee maker every 2-3 months or as needed. Use a commercial descaling solution designed for coffee makers, following the product's instructions, or a mixture of white vinegar and water (1:2 ratio). Run the solution through a brewing cycle without coffee, then run 2-3 cycles with plain water to rinse.

Troubleshooting

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outage; faulty outlet.	Ensure power cord is securely plugged in. Check circuit breaker. Try a different outlet.
Coffee is not brewing.	No water in tank; brewing chamber/filter not correctly placed.	Fill water tank to appropriate level. Ensure all removable parts are correctly assembled.
Coffee tastes weak.	Not enough coffee grounds; coffee too coarsely ground; filter clogged.	Increase amount of coffee. Use finer grind setting (if applicable) or finer pre-ground coffee. Clean filter thoroughly.
Coffee overflows.	Too much water; filter clogged; cup too small.	Do not exceed MAX fill line for water. Clean filter. Use the provided 500ml travel cup or a sufficiently large mug.
Grinder not working.	No beans; beans jammed; grinding chamber not properly closed.	Ensure beans are present. Clear any visible jams. Ensure the grinding chamber is securely locked in place.

Specifications

Model Number: MCM006

Power: 600W

Bean Container Capacity: 28g

Water Tank Capacity: 450ml

Coffee Cup Capacity: 500ml (included)

Material: Metal (main body), BPA-Free plastic (water tank, brewing chamber)

Color: Black

Dimensions (Product): 18.2 cm (D) x 29 cm (W) x 38.7 cm (H)

Item Weight: 2.38 kg

Special Features: Automatic Shut-off, Removable Filter, Non-stick Coating, Water Level Indicator, Anti-slip Feet, Touch Control.

Warranty and Support

Specific warranty details for the Milex Fresh Coffee On The Go (Model MCM006) are not provided in this manual. For information regarding warranty coverage, product support, or spare parts, please contact Milex customer service directly or refer to the warranty card included with your purchase.
You may also visit the official Milex website or the Milex store on Amazon for further assistance:

Visit the Milex Store on Amazon

© 2024 Milex. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CRZ954VM

More documents and user manuals: **https://manuals.plus/**