Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Milex MSA005

Milex 10L Digital Air Fryer User Manual

Model: MSA005

Introduction

Thank you for choosing the Milex 10L Digital Air Fryer. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read it thoroughly before first use and keep it for future reference.

Important Safety Instructions

- Always place the air fryer on a stable, heat-resistant surface, away from walls and other appliances, to allow for proper air circulation.
- Do not immerse the appliance, cord, or plug in water or any other liquid to prevent electric shock.
- Supervise children closely when the appliance is in use.
- Unplug from the outlet when not in use and before cleaning. Allow to cool before handling parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Do not use accessories not recommended by the manufacturer, as this may cause injuries.
- Do not let the cord hang over the edge of a table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Do not use the appliance for anything other than its intended use.
- Always ensure the food basket is properly inserted before operating.
- Hot steam is released through the air outlet openings during air frying. Keep your hands and face at a safe distance from the steam and the air outlet openings.
- The outer surfaces may become hot during use. Do not touch hot surfaces. Use handles or knobs.

Product Components

Familiarize yourself with the main parts of your Milex 10L Digital Air Fryer:



Image 1: Milex 10L Digital Air Fryer Overview

This image displays the front view of the Milex 10L Digital Air Fryer. Key features visible include the digital control panel at the top, which shows temperature and time settings, along with various preset icons. Below the control panel is the Milex brand logo. The lower section of the appliance features a prominent silver-colored drawer with a black handle, indicating the removable food basket. The overall design is sleek, with a black top and base contrasting with the silver body.

- **Digital Control Panel:** Features an LED display for temperature and time, touch controls for settings, and preset function icons.
- **Air Inlet:** Located at the top of the unit, where air is drawn in.
- **Food Basket/Drawer:** The main cooking compartment where food is placed. It features a non-stick coating.
- **Handle:** Ergonomically designed for safe removal and insertion of the food basket.
- **Air Outlet:** Located at the back of the unit, where hot air is expelled.

- **Power Cord:** For connecting the appliance to an electrical outlet.

Setup

1. **Unpacking:** Carefully remove all packaging materials, including any protective films or stickers.
2. **Initial Cleaning:** Before first use, wash the food basket and any removable accessories with hot water, dish soap, and a non-abrasive sponge. Rinse thoroughly and dry completely. Wipe the interior and exterior of the main unit with a damp cloth.
3. **Placement:** Place the air fryer on a stable, level, and heat-resistant surface. Ensure there is at least 10-15 cm of clear space around the back and sides of the appliance for proper ventilation. Do not place it directly under cabinets.
4. **Power Connection:** Plug the power cord into a grounded electrical outlet.

Operating Instructions

Basic Operation:

1. **Preparation:** Place the food you wish to cook into the food basket. Do not overfill the basket to ensure even cooking.
2. **Insert Basket:** Slide the food basket back into the main unit until it clicks securely into place.
3. **Power On:** Press the Power button () on the digital control panel. The display will illuminate.
4. **Set Temperature and Time:**
   - Use the temperature control buttons (**+** / **-** next to °C) to adjust the cooking temperature (50°C - 200°C).
   - Use the time control buttons (**+** / **-** next to MIN) to set the cooking time (1-60 minutes).
5. **Start Cooking:** Press the Start/Pause button (often represented by a play/pause icon or the power button again) to begin the cooking cycle. The fan and heating element will activate.
6. **Shaking/Turning Food:** For some recipes, it is recommended to shake or turn the food halfway through the cooking time. Carefully pull out the basket, shake or turn the food, and then reinsert the basket. The air fryer will resume cooking automatically.
7. **End of Cooking:** The air fryer will beep when the set cooking time has elapsed. The heating element will turn off, and the fan may continue to run for a short period to cool down the unit.
8. **Remove Food:** Carefully pull out the food basket using the handle. Use heat-resistant tongs to remove the cooked food.
9. **Power Off:** Press and hold the Power button to turn off the appliance, or simply unplug it from the wall socket.

Using Preset Functions:

The Milex 10L Digital Air Fryer comes with 10 preset functions for common dishes. To use a preset:

1. Follow steps 1-3 from Basic Operation.
2. Press the Menu/Preset button (often represented by a 'M' or a series of icons) repeatedly to cycle through the available preset functions. Each press will display a different icon and its corresponding default time and temperature.
3. Once you have selected your desired preset, you can optionally adjust the time and temperature using the respective control buttons if needed.
4. Press the Start/Pause button to begin cooking.

The 10 preset functions are designed for convenience and include settings for items such as fries, chicken, fish, steak, shrimp, cake, pizza, vegetables, and more. Refer to the icons on your control panel for specific representations.

Cleaning and Maintenance

Regular cleaning ensures optimal performance and extends the lifespan of your air fryer.

1. **Unplug and Cool:** Always unplug the air fryer from the power outlet and allow it to cool down completely before cleaning.
2. **Clean the Food Basket and Tray:**
   - Remove the food basket and tray. They are non-stick and can be washed with hot water, dish soap, and a non-abrasive sponge.
   - For stubborn food residue, soak the basket and tray in warm soapy water for about 10-15 minutes before cleaning.
   - Do not use metal utensils or abrasive cleaning materials, as they can damage the non-stick coating.
   - Rinse thoroughly and dry completely before reassembling.
3. **Clean the Interior:** Wipe the interior of the appliance with a damp cloth. If necessary, use a mild dish soap. Avoid getting water into the heating element area.
4. **Clean the Exterior:** Wipe the exterior surface with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
5. **Heating Element:** If necessary, gently clean the heating element with a soft brush to remove any food particles. Do not use water or liquid cleaners directly on the heating element.
6. **Storage:** Ensure all parts are clean and dry before storing the air fryer in a cool, dry place.

Troubleshooting

Problem	Possible Cause	Solution
Air fryer does not turn on.	Appliance not plugged in; Basket not inserted correctly.	Ensure the power cord is securely plugged into a grounded outlet. Push the food basket firmly into the unit until it clicks.
Food is not cooked evenly.	Basket is overloaded; Food not shaken/turned.	Do not overload the basket. Cook in smaller batches if necessary. Shake or turn food halfway through cooking.
White smoke coming from the appliance.	Greasy residue from previous use; High fat content food.	Clean the basket and interior thoroughly after each use. For high-fat foods, drain excess oil from the basket during cooking.
French fries are not crispy.	Incorrect potato type; Not properly prepared; Too much oil.	Use fresh potatoes suitable for frying. Soak potato sticks in water for 30 minutes, then dry thoroughly before adding a small amount of oil.

Specifications

Brand: Milex

Model Number: MSA005

Capacity: 9.5 Liters

Power / Wattage: 1800 Watts

Voltage: 220-240V, 50Hz

Temperature Range: 50°C - 200°C

Adjustable Cooking Timer: 1-60 minutes

Material: Alloy Steel (body), Non-Stick (food tray & pot)

Colour: Silver / Black

Special Features: Programmable, LED Display with Touch Screen, Rapid Air Circulation Technology, Over-Heat Protection, Anti-Slip Feet

Product Dimensions: 42.5D x 37.5W x 39.5H centimetres

Item Weight: 5.4 kg

Warranty and Support

Milex products are manufactured to the highest quality standards. For information regarding warranty coverage, product support, or spare parts, please refer to the warranty card included with your purchase or visit the official Milex website. Keep your proof of purchase for any warranty claims.
For further assistance, please contact Milex customer service.

© 2024 Milex. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CRZCPM6K

More documents and user manuals: **https://manuals.plus/**