Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LEXiBOOK BTD80HP

LEXiBOOK Harry Potter Luminous Bluetooth Speaker BTD80HP - Instruction Manual

Introduction

This manual provides essential information for the safe and efficient operation of your LEXiBOOK Harry Potter Luminous Bluetooth Speaker, model BTD80HP. Please read these instructions carefully before using the device and retain them for future reference.

Package Contents

Verify that all items are present in the package:

- 1 x Harry Potter Luminous Bluetooth Speaker
- 1 x USB-C Charging Cable
- 1 x Instruction Manual (this document)

Product Overview

Familiarize yourself with the components of your speaker.



Figure 1: Front view of the speaker, showing the Harry Potter figurine and the speaker grille.



Figure 2: Side view illustrating the control buttons (Power, Play/Pause, Skip) located on the base.



Figure 3: Rear view displaying the USB-A port for media playback and the USB Type-C port for charging.



Figure 4: The Harry Potter figurine illuminated, demonstrating the luminous feature.

Setup

1. Charging the Speaker

1. Connect the provided USB Type-C cable to the charging port on the back of the speaker (refer to Figure 3).
2. Connect the other end of the USB Type-C cable to a compatible USB power adapter (not included) or a computer's USB port.
3. The charging indicator light will illuminate. Allow approximately 2-3 hours for a full charge. The indicator light will change or turn off once fully charged.

2. Power On/Off

- To power on, press and hold the Power button (refer to Figure 2) for a few seconds until you hear an audible prompt or see an indicator light.
- To power off, press and hold the Power button again for a few seconds.

Operating Instructions

1. Bluetooth Pairing

1. Ensure the speaker is powered on and in Bluetooth pairing mode (an indicator light may flash, and an audible prompt may sound).
2. On your mobile device (smartphone, tablet, computer), enable Bluetooth and search for available devices.
3. Select "BTD80HP" or a similar name from the list of devices.
4. Once paired, the speaker will confirm with an audible prompt, and the indicator light will become solid.

2. USB Playback

1. Insert a USB flash drive containing MP3 audio files into the USB-A port on the back of the speaker (refer to Figure 3).
2. The speaker should automatically detect the USB drive and begin playing music.
3. Use the Play/Pause and Skip buttons to control playback.

3. Luminous Figurine Feature

The Harry Potter figurine on top of the speaker is designed to light up, often synchronizing with the rhythm of the music being played. This feature activates automatically when the speaker is in operation.

4. Control Buttons

- **Power Button:** Press and hold to turn the speaker on or off.
- **Play/Pause Button:** Press once to play or pause audio.
- **Skip Forward Button:** Press once to skip to the next track.
- **Skip Backward Button:** Press once to go to the previous track.

Maintenance

- Clean the speaker with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Keep the speaker away from water, moisture, and extreme temperatures.
- Avoid dropping the speaker or subjecting it to strong impacts.
- When not in use for extended periods, store the speaker in a cool, dry place and ensure it is fully charged periodically to maintain battery health.

Troubleshooting

Problem	Possible Solution
Speaker does not turn on.	Ensure the battery is charged. Connect the USB-C cable and charge for at least 30 minutes before attempting to power on again.
No sound from the speaker.	Check the volume level on both the speaker and your connected device. Ensure the device is properly paired via Bluetooth or the USB drive is correctly inserted and contains playable files.

Problem	Possible Solution
Bluetooth pairing fails.	Make sure the speaker is in pairing mode. Disable and re-enable Bluetooth on your device. Move the speaker closer to your device. Disconnect from other Bluetooth devices.
Figurine light is not working.	Ensure the speaker is powered on and playing audio. If the issue persists, contact customer support.

Specifications

- **Model Number:** BTD80HP
- **Bluetooth Version:** 5.0
- **Connectivity:** Bluetooth, USB-A (for media playback), USB Type-C (for charging)
- **Power Source:** Rechargeable Battery
- **Product Dimensions:** 5.55 x 5.55 x 7.68 inches
- **Item Weight:** 14.2 ounces
- **Manufacturer:** Lexibook
- **Recommended Age:** 3 years and up

Warranty and Support

This LEXiBOOK product is covered by a**3-month warranty** from the date of purchase. This warranty covers manufacturing defects under normal use. Please retain your proof of purchase for warranty claims.
For technical support, troubleshooting assistance, or warranty inquiries, please contact LEXiBOOK customer service through their official website or the retailer where the product was purchased. Refer to the packaging or LEXiBOOK's official website for contact details.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CS35JRXW

More documents and user manuals: **https://manuals.plus/**