vimitty OTH-AB403

vimitty Magnetic Selfie Stick Tripod with Remote (Model OTH-AB403) - User Manual

Comprehensive instructions for setup, operation, and maintenance.

1. Introduction

Thank you for choosing the vimitty Magnetic Selfie Stick Tripod with Remote. This versatile device combines a selfie stick and a tripod, offering magnetic phone attachment, adjustable height, and a detachable Bluetooth remote for enhanced photography and videography. This manual provides detailed instructions to help you get the most out of your product.

Figure 1: vimitty Magnetic Selfie Stick Tripod (Model OTH-AB403) - Folded and Extended Views.

2. Package Contents

Please verify that all items are present in your package:

- vimitty Magnetic Selfie Stick Tripod
- Detachable Bluetooth Remote Control
- USB Charging Cable (for remote)

- Metal Ring (for non-MagSafe compatible phones/cases)
- User Manual (this document)

3. Setup Instructions

3.1 Attaching Your Phone

The tripod features a strong magnetic mount for secure phone attachment.

1. **For MagSafe Compatible Devices (iPhone 12/13/14/15 Series or MagSafe Cases):**

   Simply align your phone's MagSafe area with the magnetic ring on the tripod mount. The magnets will securely snap into place.

Figure 2: Magnetic Phone Attachment.

2. **For Other Phones or Non-MagSafe Cases:**

   Use the included metal ring. Peel off the adhesive backing and carefully center the metal ring on the back of your phone or phone case. Ensure it is firmly pressed for optimal adhesion. Once the metal ring is attached, your phone can be magnetically mounted to the tripod.

Figure 3: Using the Metal Ring for Non-MagSafe Devices.

3.2 Pairing the Bluetooth Remote

The detachable Bluetooth remote allows for convenient photo and video capture from a distance.

1. Ensure the remote control is charged.
2. Press and hold the button on the remote until the indicator light flashes, indicating it's in pairing mode.
3. On your smartphone, go to **Settings** > **Bluetooth** and turn Bluetooth on.
4. Look for "vimitty" or a similar device name in the list of available devices and select it to pair.
5. Once paired, the indicator light on the remote will stop flashing.

Figure 4: Bluetooth Remote Pairing.

4. Operating Instructions

4.1 Using as a Selfie Stick

1. Ensure the tripod legs are folded and secured.
2. Extend the telescopic pole to your desired length.
3. Attach your phone to the magnetic mount.
4. Adjust the phone's angle using the 210° flip and 360° rotation features.
5. Use the Bluetooth remote to capture photos or start/stop video recording.

Figure 5: Using the Selfie Stick Function.

4.2 Using as a Tripod

1. Locate the "PUSH" button at the base of the handle. Press it to release and unfold the tripod legs.
2. Ensure the legs are fully extended and stable on a flat surface.
3. Extend the telescopic pole to your desired height (from 15.7 inches to 54 inches).
4. Attach your phone to the magnetic mount.
5. Adjust the phone's orientation (horizontal or vertical) and tilt using the 360° rotation and 210° flip mechanisms.
6. Use the Bluetooth remote for hands-free capture.

Figure 6: Tripod in Extended Position.

Figure 7: Outdoor Use with Remote.

4.3 Adjusting Angle and Orientation

The tripod head offers flexibility for various shooting angles:

- **360° Rotation:** Rotate your phone horizontally or vertically without re-mounting.
- **210° Tilt:** Adjust the vertical angle of your phone to capture high or low shots.

Figure 8: Angle Adjustment Features.

5. Maintenance

- **Cleaning:** Wipe the tripod with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Store the tripod in a cool, dry place when not in use. Ensure the legs are folded and the telescopic pole is retracted to prevent damage.
- **Remote Battery:** The Bluetooth remote has a built-in rechargeable battery. Charge it using the provided USB cable when the battery is low. A full charge provides approximately 45,000 photos.

6. Troubleshooting

Problem	Possible Cause	Solution
Phone not attaching magnetically.	Not a MagSafe compatible device/case, or metal ring not properly attached.	Ensure your phone is MagSafe compatible or that the metal ring is securely and correctly placed on your phone/case.
Bluetooth remote not pairing.	Remote battery low, Bluetooth off on phone, or remote not in pairing mode.	Charge the remote. Ensure Bluetooth is enabled on your phone. Press and hold the remote button until the indicator light flashes to enter pairing mode.
Tripod unstable when fully extended.	Legs not fully spread, uneven surface, or excessive weight.	Ensure tripod legs are fully extended and locked. Place on a flat, stable surface. Avoid attaching heavy accessories that could unbalance the tripod.
Remote not taking photos.	Not paired, out of range, or camera app not active.	Verify pairing. Ensure you are within the 33ft (10m) range. Open your phone's camera application.

7. Specifications

- **Model:** OTH-AB403
- **Material:** Aviation-grade Aluminum Alloy (pole), ABS (handle/base)
- **Folded Length:** 9.64 inches (24.5 cm)
- **Minimum Height (Tripod):** 15.7 inches (40 cm)
- **Maximum Height (Tripod/Selfie Stick):** 54 inches (136 cm)
- **Weight:** 0.6 lbs (9.6 ounces)
- **Rotation:** 360° (phone mount)
- **Tilt:** 210° (phone mount)
- **Bluetooth Remote Range:** Up to 33 ft (10 m)
- **Remote Battery:** Built-in 50mAh rechargeable battery
- **Compatibility:** iPhone 12/13/14/15 Series, MagSafe Cases, and other phones with metal ring attachment. Compatible with iOS 7.0+, Android 5.0+.

8. Warranty and Support

For warranty information or technical support, please refer to the official vimitty website or contact our customer service team. Keep your purchase receipt for warranty claims.
Website: vimitty Official Store

© 2024 vimitty. All rights reserved.