Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Billboard BB-S60440

Billboard Soul Wide Wireless Speaker User Manual

Model: BB-S60440

Introduction

Welcome to the user manual for your new Billboard Soul Wide Wireless Speaker. This guide provides detailed instructions on how to set up, operate, and maintain your speaker to ensure optimal performance and longevity. The Billboard Soul Wide speaker offers immersive sound and vibrant RGB LED lighting, designed to enhance your audio experience.



Front view of the Billboard Soul Wide Wireless Speaker showcasing its RGB LED lights and dual speaker design.

What's Included

Please check the package contents to ensure all items are present:

- Billboard Soul Wide Wireless Speaker
- Power Cable
- User Manual (this document)



The Billboard Soul Wide speaker packaged in its retail box, indicating included accessories.

Features Overview

The Billboard Soul Wide speaker is designed with a range of features to enhance your audio experience and provide versatile connectivity.



Key features of the Billboard Soul Wide speaker, including wireless audio, RGB lighting, rechargeable battery, and multiple input options.

- **Wireless Audio:** Enjoy seamless music streaming via Bluetooth.
- **Vibrant RGB LED Lights:** Dynamic lighting effects to match your mood or music.
- **Rechargeable Battery:** Portable design with long-lasting battery life for on-the-go entertainment.
- **Multiple Connectivity Options:** Supports USB, Micro SD, and 3.5mm AUX input for versatile playback.
- **True Wireless (TWS) Function:** Pair two Soul Wide speakers for an immersive stereo sound experience.



Visual representation of the Billboard Soul Wide's diverse connectivity ports, including USB, 3.5mm AUX, and Micro SD.

Setup

1. Charging the Speaker

Before first use, fully charge the speaker. Connect the included power cable to the speaker's charging port and plug the other end into a suitable power outlet. The charging indicator light will show the charging status.

- A full charge typically takes approximately [X] hours (*Note: Specific charging time not provided in data, so using placeholder*).
- The rechargeable battery allows for portable use.

2. Powering On/Off

To power on the speaker, press and hold the Power button located on the control panel. You will hear an audible prompt, and the RGB lights will illuminate. To power off, press and hold the Power button again.

Operating Instructions

1. Bluetooth Pairing

The Billboard Soul Wide speaker supports wireless audio streaming via Bluetooth.

1. Ensure the speaker is powered on and in Bluetooth pairing mode (indicated by a flashing Bluetooth light or audible prompt).
2. On your device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.
3. Select "Billboard Soul Wide" from the list of devices.
4. Once paired, the speaker will indicate a successful connection, and you can begin playing audio wirelessly.

2. Using USB and Micro SD Playback

The speaker supports direct audio playback from USB drives and Micro SD cards.

- Insert a USB drive into the USB port or a Micro SD card into the Micro SD slot.
- The speaker will automatically switch to the corresponding mode and begin playing compatible audio files.
- Use the speaker's control buttons to navigate tracks (play/pause, next/previous).

3. Using AUX Input (3.5mm)

For devices without Bluetooth, use the 3.5mm AUX input.

- Connect one end of a 3.5mm audio cable (not included) to your audio device's headphone jack.
- Connect the other end to the AUX input port on the speaker.
- The speaker will automatically switch to AUX mode.

4. True Wireless Function (TWS)

The True Wireless feature allows you to pair two Billboard Soul Wide speakers together for a stereo sound experience.

1. Ensure both speakers are powered on and not connected to any Bluetooth device.
2. On one speaker (this will be the primary speaker), press and hold the TWS button (if available, or a specific pairing button).
3. The primary speaker will search for the secondary speaker.
4. Once connected, you will hear a confirmation sound. Both speakers will now play audio in stereo.
5. Connect your device to the primary speaker via Bluetooth as described in step 1.

5. Controlling RGB LED Lights

The speaker features dynamic RGB LED lighting to enhance your listening experience.

- Press the Light Mode button (if available, or a dedicated button for lights) to cycle through different light patterns and colors.
- Press and hold the Light Mode button to turn the lights off or on.



The Billboard Soul Wide speaker displaying its vibrant RGB LED lighting, creating a festive atmosphere.

Maintenance

Cleaning

Wipe the speaker with a soft, dry cloth. Do not use abrasive cleaners or solvents, as they may damage the surface. Avoid exposing the speaker to excessive dust or dirt.

Storage

When not in use for extended periods, store the speaker in a cool, dry place away from direct sunlight and extreme temperatures. It is recommended to charge the battery at least once every three months to maintain its health.

Battery Care

To prolong battery life, avoid fully discharging the speaker frequently. Charge the speaker when the battery low indicator appears. Do not attempt to replace the battery yourself.

Troubleshooting

Problem	Possible Cause	Solution
Speaker does not power on.	Battery is depleted.	Connect the speaker to a power source and charge it.
No sound.	Volume is too low; Incorrect input mode; Device not paired.	Increase volume on speaker and connected device; Ensure correct input mode (Bluetooth, USB, AUX); Re-pair Bluetooth device.
Bluetooth pairing fails.	Speaker is too far from device; Speaker already paired to another device; Device's Bluetooth is off.	Move speaker closer to device; Disconnect from other devices; Ensure Bluetooth is enabled on your device.
RGB lights not working.	Lights are turned off; Malfunction.	Press the Light Mode button to cycle through modes or turn on; If issue persists, contact support.

Specifications

Feature	Detail
Brand	Billboard
Model Name	Soul Wide
Product Model Number	BB-S60440
Speaker Type	Atmospheric
Special Features	Wireless, Bluetooth, RGB light up
Compatible Devices	Smartphone, Tablet, Laptop, Gaming Console
Controller Type	Voice Control
Surround Sound Channel Configuration	2.0
Included Components	Power cable
Product Dimensions	26D x 15W x 47H centimeters
Power Source	Battery
Connectivity Technology	USB, Bluetooth, 3.5mm AUX, Micro SD
Audio Output Mode	Stereo

Feature	Detail
Mounting Type	Tabletop Mount

Warranty and Support

For warranty information and customer support, please refer to the official Billboard website or contact your retailer. Keep your purchase receipt as proof of purchase for any warranty claims.
For further assistance, you may visit the Billboard Store on Amazon.

© 2024 Billboard. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CTJCC4DC

More documents and user manuals: **https://manuals.plus/**