Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

WEN PW2200

WEN 2200 PSI Electric Pressure Washer

Model: PW2200

Introduction

Thank you for choosing the WEN 2200 PSI Electric Pressure Washer. This manual provides important information for the proper assembly, operation, and maintenance of your pressure washer. Please read this manual thoroughly before using the product to ensure safe and efficient operation. Keep this manual for future reference.
This electric pressure washer is designed to effectively clean various surfaces such as walkways, patios, furniture, and decks by blasting water at high pressure. Its compact design and portability make it suitable for a wide range of household cleaning tasks.

Safety Information

WARNING: Read all safety warnings and instructions. Failure to follow the warnings and instructions may result in electric shock, fire, and/or serious injury.

- Always wear appropriate personal protective equipment, including eye protection, when operating the pressure washer.
- Ensure the power cord is connected to a GFCI-protected outlet.
- Do not direct the water stream at people, pets, or electrical devices.
- Keep the operating area clear of bystanders and children.
- Before performing any maintenance or cleaning, always unplug the pressure washer from the power source.
- Do not operate the pressure washer if any parts are damaged or missing.
- Use only WEN recommended accessories and replacement parts.

Package Contents

Carefully unpack all items and ensure you have received everything listed below. If any items are missing or damaged, please contact WEN customer support.

- WEN 2200 PSI Electric Pressure Washer Unit
- High-Pressure Hose (20-foot reinforced)
- Spray Gun with Wand
- Nozzles: 0° (Red), 15° (Yellow), 40° (White)

- Detergent Tank (Onboard)
- Water Filter
- User Manual



Image: WEN 2200 PSI Electric Pressure Washer with its components, including the main unit, spray gun, high-pressure hose, and various nozzles, laid out for inspection.

Setup

1. **Attach Wheels and Casters:** If not pre-assembled, attach the 6.5-inch never-flat wheels and 2.75-inch casters to the base of the unit. Ensure they are securely fastened for easy transportation.





Image: A close-up view of the pressure washer's durable wheels and the convenient onboard storage for the different spray nozzles.

2. **Connect High-Pressure Hose:** Connect one end of the 20-foot reinforced high-pressure hose to the outlet on

the pressure washer unit and the other end to the spray gun. Hand-tighten securely.

3. **Attach Spray Nozzle:** Select the desired nozzle (0°, 15°, or 40°) and attach it to the end of the spray gun wand. Push it firmly into place until it clicks.



Image: A detailed view of the three color-coded quick-connect nozzles (red 0°, yellow 15°, white 40°) that come with the pressure washer, designed for various cleaning intensities.

4. **Connect Water Supply:** Connect a standard garden hose (not included) to the water inlet on the pressure washer. Ensure the water filter is in place. Turn on the water supply completely.
5. **Purge Air from System:** Before plugging in the unit, squeeze the trigger on the spray gun to allow water to flow through the system and purge any air. Continue until a steady stream of water emerges from the nozzle.
6. **Connect Power:** Plug the 35-foot GFCI-protected power cord into a suitable electrical outlet. Ensure the GFCI plug is reset if necessary.

Operating Instructions

General Operation

1. Ensure all connections are secure and the water supply is fully open.
2. Turn on the pressure washer by pressing the ON/OFF switch. The motor will start.

3. Point the spray gun at the surface to be cleaned, keeping a safe distance.
4. Squeeze the trigger on the spray gun to begin spraying. Release the trigger to stop the flow.
5. Always start with the 40° (white) nozzle and increase pressure by switching to a narrower angle nozzle (15° yellow, 0° red) if needed, to avoid damaging the surface.
6. When finished, turn off the pressure washer, turn off the water supply, and squeeze the trigger to release any remaining pressure in the system.

Using the Detergent Tank

1. Open the cap of the onboard detergent tank.
2. Pour up to 33.8 fluid ounces (1L) of pressure washer safe detergent into the tank. Do not use bleach or abrasive cleaners.
3. Close the detergent tank cap securely.
4. For detergent application, use the 40° (white) nozzle or a dedicated soap nozzle if available. High-pressure nozzles (0°, 15°) are not suitable for detergent application.
5. The pressure washer will automatically draw detergent when operating at low pressure (e.g., with the 40° nozzle).
6. After applying detergent, switch to a high-pressure nozzle and rinse the surface thoroughly.

Maintenance

Regular maintenance will ensure the longevity and optimal performance of your WEN pressure washer.

- **After Each Use:**
  - Disconnect power and water supply.
  - Drain all water from the pump, hose, and spray gun to prevent freezing in cold weather.
  - Clean the water inlet filter to remove any debris.
  - Rinse the detergent tank with clean water if detergent was used.
  - Wipe down the unit with a damp cloth.
- **Nozzle Cleaning:** If nozzles become clogged, use a small pin or wire to clear the opening. Rinse thoroughly with water.
- **Storage:** Store the pressure washer in a dry, frost-free area. Utilize the onboard accessory attachment points for convenient, compact storage of the hose, power cord, and nozzles.



Image: An overhead view of the WEN pressure washer, highlighting its integrated storage solutions for the high-pressure hose and electrical cord, ensuring a tidy and compact footprint when not in use.

Troubleshooting

Problem	Possible Cause	Solution
Motor does not start.	No power supply; GFCI tripped; ON/OFF switch off.	Check power connection; Reset GFCI; Turn ON/OFF switch to ON.
Low pressure or no pressure.	Insufficient water supply; Air in pump; Clogged nozzle; Kinked hose.	Ensure water supply is fully open; Purge air from system; Clean nozzle; Straighten hose.
Motor stops during operation.	Thermal overload activated; Low voltage.	Allow motor to cool down; Check power source for adequate voltage.
Water leaks.	Loose connections; Damaged O-rings.	Tighten all connections; Inspect and replace O-rings if damaged.

Specifications

Feature	Detail
Model	PW2200
Brand	WEN
Power Source	Electric
Motor	13-amp
Maximum Pressure	2200 PSI (Pounds per Square Inch)
Maximum Flow Rate	1.65 GPM (Gallons Per Minute)

Feature	Detail
Hose Length	20 feet (reinforced)
Power Cord Length	35 feet (GFCI-protected)
Detergent Tank Capacity	33.8 fluid ounces (1L)
Nozzles Included	0°, 15°, 40°
Wheels	6.5-inch never-flat wheels, 2.75-inch casters
Item Weight	27.8 pounds (12.66 kg)
Product Dimensions (L x W x H)	22.4" x 12.87" x 13.82"
Certifications	CSA
Country of Origin	China

Warranty and Support

The WEN 2200 PSI Electric Pressure Washer comes backed by a two-year warranty. This warranty covers defects in material and workmanship under normal use.
For warranty claims, replacement parts, or technical assistance, please contact WEN customer support. Have your model number (PW2200) and purchase information ready when contacting support.
For more information, visit the official WEN website or refer to the contact details provided with your product packaging.

© 2024 WEN Products. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CVNLJ7RZ

More documents and user manuals: **https://manuals.plus/**