Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Paladone 12710

Paladone Minecraft Panda Light - Portable LED Night Light User Manual

Model: 12710

Introduction

This manual provides essential instructions for the safe and effective use of your Paladone Minecraft Panda Light. Please read this guide thoroughly before operating the device and retain it for future reference.



Image: Front view of the Paladone Minecraft Panda Light, depicting its blocky panda design with a green bamboo stick.

The Paladone Minecraft Panda Light is a portable LED night light designed to provide a comforting glow. Its design is inspired by the Minecraft Panda mob, making it a decorative item suitable for various indoor spaces.

Setup

1. **Unboxing:** Carefully remove the Panda Light from its packaging. Inspect for any damage.
2. **Battery Installation:**
   - Locate the battery compartment on the underside of the Panda Light.

- Open the battery compartment cover.
- Insert 3x AAA batteries (not included), ensuring correct polarity (+/-) as indicated inside the compartment.
- Close the battery compartment cover securely.

3. **Placement:** Place the Panda Light on a stable, flat surface in your desired indoor location. Ensure it is away from direct sunlight, heat sources, and moisture.



Image: The Paladone Minecraft Panda Light in its retail packaging, showing the product and branding.

Operating Instructions

The Paladone Minecraft Panda Light features a simple touch-activated switch for operation.

1. **Turning On:** Gently press the designated touch switch on the light. The LED light will illuminate, providing a soft glow.
2. **Turning Off:** Press the touch switch again to turn the light off.



Image: The Paladone Minecraft Panda Light glowing softly while placed on a shelf, demonstrating its illuminated state.

Note: This light is designed as a night light and decorative item. It does not offer adjustable brightness settings.

Maintenance

- **Cleaning:** To clean the Panda Light, gently wipe its surface with a soft, dry cloth. Do not use abrasive cleaners, solvents, or immerse the unit in water.
- **Battery Replacement:** When the light dims or stops functioning, replace all three AAA batteries with new ones. Refer to the "Battery Installation" step in the Setup section.
- **Storage:** If storing the light for an extended period, remove the batteries to prevent leakage and potential damage.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Light does not turn on.	• Batteries are not installed. • Batteries are inserted incorrectly. • Batteries are depleted.	• Install 3x AAA batteries. • Check battery polarity and reinsert correctly. • Replace with new AAA batteries.
Light is dim.	Batteries are low.	Replace with new AAA batteries.
Light flickers.	Loose battery connection or low batteries.	Check battery compartment for secure connection. Replace with new AAA batteries if necessary.

Specifications

- **Model:** 12710
- **Brand:** Paladone
- **Product Dimensions:** 3.54"D x 5.12"W x 5.91"H (9cm D x 13cm W x 15cm H)
- **Item Weight:** 8 ounces (226 Grams)
- **Power Source:** 3x AAA Batteries (not included)
- **Light Source Type:** Light Emitting Diode (LED)
- **Voltage:** 4.5 Volts (DC)
- **Brightness:** 3 Lumen
- **Material:** Plastic
- **Control Method:** Touch
- **Indoor/Outdoor Usage:** Indoor
- **Special Feature:** Portable

Warranty and Support

Specific warranty information for the Paladone Minecraft Panda Light is not provided in this manual. For details regarding warranty coverage, please refer to the product packaging or contact Paladone directly.
For further assistance or support, please visit the official Paladone website or contact their customer service department. You may also refer to the Paladone store on Amazon: Paladone Amazon Store.

© 2025 Paladone. All rights reserved. Minecraft is a trademark of Mojang Synergies AB.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CVR13JYQ

More documents and user manuals: **https://manuals.plus/**