Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Kiss the Water ZER006WT-MC-VC-G

Kiss the Water 8 Quart Electric Roaster Oven Instruction Manual

Model: ZER006WT-MC-VC-G | Brand: Kiss the Water

1. Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions before using the roaster oven.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse the main unit, cord, or plug in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to 'off', then remove plug from wall outlet.
- Do not use appliance for other than intended use.

2. Product Overview

Components

The Kiss the Water 8 Quart Electric Roaster Oven includes several key components designed for versatile cooking:

- **Roaster Body:** The main heating unit.
- **Removable Enamel-on-Steel Pan:** For easy cooking and cleaning.

- **Self-Basting Lid:** Designed to continually recirculate moisture, keeping food tender and juicy.
- **Roasting Rack:** To elevate food for even cooking and to prevent sticking.


KEEP WARM
150
200
250
DEFROST
300
350
400 °F
Min
CAUTION: HOT SURFACE

Figure 1: Exploded view showing the roaster body, removable pan, and roasting rack.

Key Features

- **8 Quart Capacity:** Ideal for roasting turkeys, baking, slow cooking, and preparing dips for family dinners or parties.
- **Powerful 1450W Heating:** Ensures efficient cooking.
- **Full-Range Temperature Control:** Adjustable from 150°F to 400°F to suit various cooking needs.
- **Self-Basting Lid:** Recirculates moisture to keep meat tender and juicy, preventing food from sticking.
- **Defrost Setting:** Allows thawing of frozen items like turkey in hours.
- **Keep Warm Setting:** Maintains food at an ideal serving temperature.
- **Durable Construction:** Made of reinforced stainless steel for rust resistance.
- **Easy to Clean:** Features a removable insert pot for convenient cleaning.

---

3. Setup

1. **Unpacking:** Carefully remove all packaging materials, including any labels or stickers. Retain packaging for future storage or shipping.
2. **Initial Cleaning:** Before first use, wash the removable enamel-on-steel pan, roasting rack, and lid in warm, soapy water. Rinse thoroughly and dry completely. Wipe the exterior of the roaster body with a damp cloth. Do not immerse the roaster body in water.
3. **Placement:** Place the roaster body on a stable, heat-resistant surface, away from walls or other appliances to allow for proper ventilation. Ensure the power cord is not obstructed.
4. **Assembly:** Insert the clean removable pan into the roaster body. Place the roasting rack inside the removable pan. Position the self-basting lid securely on top.

---

4. Operating Instructions

Temperature Control

The roaster oven features a knob control for precise temperature adjustments and specific functions:

- The temperature range is from 150°F to 400°F.
- An indicator light illuminates when the roaster is heating and turns off once the set temperature is reached.
- Settings include 'KEEP WARM' and 'DEFROST'.



Figure 2: The control knob allows selection of temperature and functions.

General Roasting

1. Place the roasting rack inside the removable pan.
2. Place your food (e.g., turkey, chicken, roast) on the roasting rack.
3. Cover with the self-basting lid.
4. Plug the roaster oven into a standard electrical outlet.
5. Turn the temperature control knob to the desired temperature. The indicator light will turn on.
6. Cook until the food reaches the appropriate internal temperature. The self-basting lid will help maintain moisture.
7. Once cooking is complete, turn the knob to 'OFF' and unplug the unit.



Figure 3: The roaster oven is suitable for cooking large items like turkey.

Defrost Function

The unique Defrost setting allows you to thaw frozen items efficiently:

- Place the frozen item in the roaster oven.
- Turn the control knob to the 'DEFROST' setting.
- Follow recipe guidelines for defrosting times, then adjust to the desired cooking temperature.



Figure 4: Defrost and Keep Warm settings are available on the control panel.

Keep Warm Function

To keep cooked food at an ideal serving temperature without overcooking:

- After cooking, turn the control knob to the 'KEEP WARM' setting.
- Ensure the lid remains on to retain heat and moisture.

Official Product Videos

8qt Electric Roaster Oven Overview

▶ **Watch video online**
8qt electric roaster oven

Video 1: This video provides a brief overview of the 8-quart electric roaster oven, demonstrating its use for various dishes and highlighting its features.

Sunvivi Electric Roaster, White - General Use

▶ **Watch video online**
Sunvivi Electric Roaster, White

Video 2: This video showcases the general operation of the white Sunvivi electric roaster, including preparing ingredients, setting the temperature, and serving cooked meals.

5. Maintenance and Cleaning

Proper cleaning and maintenance will ensure the longevity and optimal performance of your roaster oven.

1. **Always unplug** the roaster oven from the electrical outlet and allow it to cool completely before cleaning.
2. **Removable Pan and Roasting Rack:** These components can be washed in warm, soapy water. They are also dishwasher safe. Rinse thoroughly and dry completely before reassembling or storing.
3. **Lid:** The self-basting lid can be washed in warm, soapy water. Rinse and dry thoroughly.
4. **Roaster Body:** Wipe the exterior of the roaster body with a damp cloth. Do not use abrasive cleaners or scouring pads. Never immerse the roaster body in water or any other liquid.
5. **Storage:** Ensure all parts are clean and dry before storing. Store the roaster oven in a cool, dry place.

▶ **Watch video online**
Sunvivi Roaster Oven 8 white

Video 3: This video demonstrates the ease of cleaning the removable inner pot of the Sunvivi 8-quart roaster oven.

6. Troubleshooting

If you encounter issues with your roaster oven, please refer to the following table for common problems and solutions:

Problem	Possible Cause	Solution
Roaster not heating	Not plugged in; power outlet malfunction; temperature knob set to 'OFF'.	Ensure unit is properly plugged in. Check power outlet with another appliance. Turn temperature knob to a desired setting.
Food cooking unevenly	Lid not properly sealed; too much food in the pan; incorrect temperature setting.	Ensure lid is securely placed. Do not overfill the pan. Verify temperature setting matches recipe. Use the roasting rack for better air circulation.
Food sticking to the pan	Insufficient liquid; pan not greased; food cooked too long at high heat.	Add more liquid if necessary. Lightly grease the pan before adding food. Adjust cooking time and temperature. The self-basting lid helps prevent sticking.
Indicator light not working	Light bulb failure; unit not heating.	If the unit is heating correctly, the light bulb may need replacement (contact customer service). If not heating, refer to 'Roaster not heating' solution.

7. Specifications

Specification	Detail
Brand	Kiss the Water
Model Name	8qt electric roaster white
Item Model Number	ZER006WT-MC-VC-G
Capacity	8 Quart
Color	White
Material	Stainless Steel
Product Dimensions	17.5"D x 24.1"W x 8.2"H
Item Weight	13.6 pounds
Power Source	Electric
Control Type	Knob
Temperature Range	150°F - 400°F
UPC	745978355157

8. Warranty and Customer Support

Kiss the Water provides a one-year warranty service for this 8 Quart Electric Roaster Oven.

If you have any questions about your slow cooker or require assistance, please do not hesitate to contact our customer service. We are committed to solving your problems quickly and efficiently.

- For support, please refer to the contact information provided in your product packaging or visit the official Kiss the Water website.

© 2024 Kiss the Water. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CWLBKC17

More documents and user manuals: **https://manuals.plus/**