Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ARREGUI Logica10 610170

ARREGUI Logica10 Safe User Manual

Model: Logica10 (610170)

1. Introduction

This manual provides detailed instructions for the installation, operation, and maintenance of your ARREGUI Logica10 electronic safe. Please read this manual thoroughly before using the safe to ensure proper function and security. Keep this manual for future reference.

The ARREGUI Logica10 safe is designed to provide high security for your valuables in home or office environments. It features a robust steel construction, an electronic keypad for access, and an emergency override system.

2. Safety Information

- Do not store the emergency keys or the master code inside the safe.
- Ensure the safe is securely mounted to prevent unauthorized removal.
- Replace batteries promptly when the low battery indicator appears.
- Keep the safe away from excessive moisture or extreme temperatures.
- This safe is not waterproof. Protect it from water exposure.

3. Package Contents

Verify that all components are present:

- ARREGUI Logica10 Safe Unit
- 2 Emergency Override Keys
- Fixing Screws (for mounting)
- User Manual (this document)



Image 1: The ARREGUI Logica10 safe in its closed state, showing the electronic keypad and the ARREGUI brand logo.

4. Setup

4.1 Battery Installation

1. Locate the battery compartment, typically on the inside of the safe door.
2. Insert 4 AA 1.5V alkaline batteries (not included), ensuring correct polarity.
3. Close the battery compartment cover. The safe will emit a beep, indicating successful power-up.

4.2 Initial Code Setting

Upon first use, or after battery replacement, you will need to set your personal access codes.

1. Open the safe using the emergency key. Insert the key into the lock, turn it, and then turn the handle to open the door.
2. With the door open, locate the red reset button on the inside of the door, near the hinge.
3. Press the reset button. The keypad will beep, and the indicator light will illuminate.
4. Enter your desired 3 to 8 digit code on the keypad.
5. Press the "#" key to confirm. The safe will beep twice, indicating the code has been successfully set.
6. Test the new code with the door open before closing it.



Image 2: The interior of the ARREGUI Logica10 safe with the door open, showing the internal shelf and the red reset/program button on the inside of the door.

4.3 Mounting the Safe

For enhanced security, it is recommended to fix the safe to a wall, shelf, or floor.

1. Choose a suitable location that is discreet and structurally sound.
2. The safe has pre-drilled holes: two in the base and two at the rear, each 9mm in diameter.
3. Position the safe and mark the drilling points through the pre-drilled holes.
4. Drill pilot holes in the wall/floor/shelf using an appropriate drill bit.

5. Align the safe with the drilled holes and secure it using the provided fixing screws. Ensure the safe is firmly attached.

5. Operating Instructions

5.1 Opening the Safe with Code

1. Enter your 3 to 8 digit code on the keypad.
2. Press the "#" key. The green indicator light will illuminate, and the safe will beep.
3. Within 5 seconds, turn the handle clockwise to open the door.



Image 3: The ARREGUI Logica10 safe with its door slightly ajar, revealing the robust locking bolts that secure the door when closed.

5.2 Closing the Safe

1. Close the safe door firmly.
2. Turn the handle counter-clockwise to engage the locking bolts. The safe is now secured.



Image 4: The interior of the ARREGUI Logica10 safe, demonstrating its capacity with various items placed on the adjustable shelf.

5.3 Changing the User Code

To change the user code:

1. Open the safe using the current code.
2. Press the red reset button on the inside of the door.
3. Enter your new 3 to 8 digit code.
4. Press the "#" key to confirm.
5. Test the new code with the door open.

5.4 Emergency Opening

In case of forgotten code or depleted batteries, the safe can be opened using the emergency key or external power.

Using the Emergency Key:

1. Locate the emergency keyhole, usually hidden behind a small cover on the keypad panel.
2. Insert one of the provided emergency keys and turn it.
3. While the key is turned, rotate the handle to open the safe door.

Using External Power:

1. Locate the external power socket on the keypad panel.
2. Connect a 9V battery (not included) to the external power terminals.
3. While holding the 9V battery in place, enter your code on the keypad and press "#".
4. Turn the handle to open the safe.

5.5 Low Battery Indicator

The safe features a red LED light that will illuminate to warn you when the batteries are running low. Replace the batteries as soon as this indicator appears to ensure continuous operation.

6. Maintenance

- **Battery Replacement:** Replace all four AA batteries annually or when the low battery indicator appears. Always use new alkaline batteries.
- **Cleaning:** Clean the exterior of the safe with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Inspection:** Periodically check the mounting bolts for tightness and ensure the door mechanism operates smoothly.

7. Troubleshooting

Problem	Possible Cause	Solution
Safe does not open with code.	Incorrect code entered. Batteries are low or dead. Code not confirmed with "#" key.	Re-enter code carefully. Replace batteries or use external power. Ensure "#" is pressed after code.
Keypad is unresponsive.	Batteries are completely dead. Keypad malfunction.	Use emergency key or external power to open and replace batteries. Contact customer support if issue persists.
Red LED indicator is on.	Low battery warning.	Replace all four AA batteries immediately.
Safe door does not close properly.	Obstruction in the door frame. Locking bolts not retracting fully.	Check for any items blocking the door. Ensure handle is turned fully to retract bolts.

8. Specifications

Feature	Detail
Model	Logica10 (610170)
Dimensions (H x W x D)	45 x 38 x 33 cm
Internal Capacity	44 Liters
Weight	52 Kilograms
Material	Laser-cut steel (10mm door, 6mm body)

Feature	Detail
Lock Type	Electronic Keypad with Emergency Key Override
Code Length	3 to 8 digits
Batteries Required	4 x AA 1.5V Alkaline (not included)
Locking Bolts	22mm diameter anti-saw rotating bolts
Mounting	Pre-drilled holes (base and rear), fixing screws included
Water Resistance	Not waterproof

9. Warranty and Support

ARREGUI products are manufactured to high-quality standards. For information regarding warranty coverage, technical support, or spare parts, please refer to the warranty card included with your purchase or visit the official ARREGUI website. Please have your model number (Logica10 / 610170) available when contacting support.

For further assistance, please contact your retailer or ARREGUI customer service.

© ARREGUI. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CWLVQ4H3

More documents and user manuals: **https://manuals.plus/**