Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Yalissey 3seat-B

Yalissey 3-in-1 Outdoor Porch Swing with Adjustable Canopy

Model: 3seat-B Wine Red

Introduction

Thank you for choosing the Yalissey 3-in-1 Outdoor Porch Swing. This manual provides essential information for the safe assembly, operation, and maintenance of your new porch swing. Please read all instructions carefully before use and retain this manual for future reference.

Safety Information

Always prioritize safety during assembly and use. Ensure all components are securely fastened before sitting on the swing. Do not exceed the maximum weight capacity of 750 pounds. Supervise children when they are using the swing. Avoid using the swing during strong winds or severe weather conditions.

Setup and Assembly

Detailed installation instructions are provided with your product. It is recommended that two adults assemble this porch swing. Ensure all parts are present and undamaged before beginning assembly.



Image: The Yalissey 3-in-1 Outdoor Porch Swing in Wine Red, shown with a family enjoying it. The image highlights the 750 lbs maximum load capacity and powder-coated steel frame.

Follow the step-by-step guide to connect the frame, attach the swing seat, and install the adjustable canopy. Verify all bolts and nuts are tightened securely.

Operating Instructions

Adjusting the Canopy

The canopy can be adjusted up to 135 degrees to provide optimal shade and protection from UV rays and light rain. Use the sturdy knobs on either side of the canopy to loosen, adjust the angle, and then tighten to secure it in place.



Image: A woman adjusting the canopy of the Yalissey porch swing, demonstrating the 60-degree adjustment range to shield from glare.

Adjusting the Backrest (3-Position)

The backrest offers three adjustable positions to suit your activity:

1. **105° (Swing Chair):** Standard upright position for comfortable seating.
2. **135° (Chaise Lounge):** A unique reclining position for relaxed lounging.
3. **180° (Porch Swing Bed):** Fully flat position to convert the swing into a comfortable bed for napping.

To adjust, pull out the pin mechanism on the side of the backrest, move to the desired angle, and ensure it locks securely into place.



Image: A woman comfortably lying flat on the Yalissey 3-in-1 Outdoor Porch Swing, demonstrating its conversion into a bed. The image also shows the locking mechanism for adjustment.

Using the Foldable Side Tables

Each side of the swing is equipped with a foldable cup holder table. Simply pull the table up and secure it in place when needed. Fold it down when not in use to save space.



Image: A close-up view of the foldable side table on the Yalissey porch swing, showing its convenient design for holding drinks and phones.

Smooth Swinging Motion

The swing is designed with robust springs for a smooth and quiet gliding experience. Ensure the area around the swing is clear of obstructions before use.



Image: A detailed view of the weather-resistant, updated, and thick spring swing lock, indicating a 750 lbs weight capacity.

Maintenance

Cushion Care

The seat cushions are upholstered in 180G polyester fabric with PA coating, making them splash-proof, water-repellent, and fade-resistant. The non-slip dotted fabric base keeps cushions securely in place. For cleaning, simply wipe spills with a damp cloth. Cushion covers are removable and washable for deeper cleaning.



Image: A close-up of the thickened seat cushion, highlighting its high-density foam, splash-proof, water-repellent, and fade-resistant properties.

Frame Care

The frame is made of galvanized steel with a powder-coated finish, providing rust resistance. Clean the frame periodically with mild soap and water. Avoid abrasive cleaners that could damage the finish. Inspect all bolts and connections regularly and tighten as needed.

Troubleshooting

Swing not gliding smoothly

Check the suspension springs for any debris or damage. Ensure all frame connections are tight. Apply a silicone-based lubricant to moving parts if necessary.

Canopy not staying in position

Ensure the adjustment knobs are fully tightened after setting the desired angle. Check for any wear on the canopy fabric or frame.

Cushions sliding

The cushions feature a non-slip base. If sliding occurs, ensure the cushions are properly aligned on the seat. Consider adding additional non-slip pads if needed.

Specifications

Feature	Detail
Product Dimensions	19"D x 77"W x 71"H
Frame Material	Alloy Steel (Metal)
Finish Type	Powder Coated
Color	Wine Red
Seat Depth	19 inches
Item Weight	83 pounds
Weight Capacity	750 pounds
Assembly Required	Yes



Image: A diagram illustrating the product dimensions of the Yalissey 3-in-1 Outdoor Porch Swing, including width, height, and seat depth.

Official Product Video

▶ **Watch video online**

Yalissey 3-Seat Outdoor Swing with Canopy

Video: An official product video from Yalissey (XINSHENGA) showcasing the features and versatility of the 3-Seat Outdoor Swing with Canopy.

Warranty and Support

For any issues or assistance, please refer to the contact information provided with your purchase or visit the Yalissey store on Amazon. Our customer service team is available to provide prompt and satisfactory support.

© 2024 Yalissey. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CWNPTH3H

More documents and user manuals: **https://manuals.plus/**