Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Yalissey B0CWP77TP3

Yalissey 3 Seat Hanging Porch Swing Instruction Manual

Model: B0CWP77TP3

1. Product Overview

The Yalissey 3 Seat Hanging Porch Swing is designed for outdoor relaxation, offering a spacious and comfortable seating solution for your patio, garden, or backyard. This swing features a robust metal frame, thick cushioning, and convenient cup holders, ensuring durability and user comfort.



Image: The Yalissey 3 Seat Hanging Porch Swing in a beige color, showcasing its design and cushions.

Key Features:

- **Extra-Wide 60-Inch Seat:** Provides ample space for comfortable seating.
- **Solid Metal Construction:** Crafted with a pure metal frame for maximum strength, stability, and a weight capacity of 800 LBS.
- **3.9-inch Thickened Cushion:** Features high-rebound padding for luxurious and supportive seating.
- **Upgraded 1.5-inch Deep Cup Holders:** Securely holds beverages to prevent spills.
- **Triple-Layer Protection:** Powder coating, galvanized layer, and metal frame for rust and corrosion resistance.

2. Setup and Installation

The Yalissey Porch Swing is designed for quick and convenient assembly. Follow the detailed, easy-to-follow

instructions provided with illustration steps for a 15-minute installation process.

Components:

- Swing Frame (Metal Seat, Backrest, Armrests)
- Hanging Chains (2 chains, 45.6 inches per chain)
- Seat Cushion (3.9-inch thick)
- Back Cushions (3 included)
- Round Pillows (2 included)
- Side Tables with Cup Holders (2 included)
- Assembly Tools (Included)



Image: Diagram illustrating product dimensions, including 60-inch width, 45.6-inch chain length, and 3.9-inch cushion thickness. Shows metal seat, 2 chains, and seating for up to 3 people.

Installation Steps:

1. Unpack all components and verify against the parts list.
2. Assemble the metal swing frame according to the provided diagrams.

3. Attach the hanging chains securely to the swing frame and your chosen sturdy overhead structure. Ensure the structure can support a minimum of 800 lbs.
4. Place the main seat cushion onto the swing.
5. Arrange the three back cushions and two round pillows for comfort.
6. Ensure side tables are properly installed and can be folded out or tucked away as needed.

▶ **Watch video online**
Yalissey 3 Seat Hanging Porch Swing

Video: An overview of the Yalissey 3 Seat Hanging Porch Swing, demonstrating its features and ease of use. This video is provided by the seller.

3. Operating Instructions

The Yalissey Porch Swing is designed for ease of use and maximum comfort. Once installed, it is ready for immediate enjoyment.

Seating and Capacity:

- The 60-inch wide seat comfortably accommodates up to three adults.
- The robust metal frame supports a maximum weight of 800 LBS.



Image: A family of three (two adults and one child) comfortably seated on the Yalissey Porch Swing, highlighting its reinforced steel frame and extra-wide seat.

Cup Holders:

- The swing features two upgraded 1.5-inch deep cup holders on the side tables.
- To use, simply pull out the side table from beneath the armrest.
- To store, push the side table back into its concealed position under the armrest.



Image: A close-up view of the upgraded 1.5-inch deep cup holder, demonstrating its secure design compared to shallower older models.

Cushion Comfort:

- The 3.9-inch thick seat cushion with high-rebound padding provides lasting support and comfort.
- The cushions are designed to be durable and quick-rebounding, preventing sagging.



Image: A person enjoying the Yalissey Porch Swing, highlighting the plump and comfortable 3.9-inch cushions and pillows.

4. Maintenance

Proper maintenance ensures the longevity and continued enjoyment of your Yalissey Porch Swing.

General Care:

- Regularly inspect the swing for any signs of wear or damage, especially the chains and frame connections. Do not use if damaged.
- Clean the metal frame with a damp cloth and mild soap. Avoid harsh chemicals.
- The cushion covers are removable and can be unzipped for washing. Follow fabric care instructions on the label.
- Store the swing in a dry place when not in use for extended periods to prevent mold or mildew growth.
- Keep the swing away from open flames or high heat sources.

5. Troubleshooting

If you encounter any issues with your Yalissey Porch Swing, refer to the following common troubleshooting tips:

Swing Instability:

- Ensure all bolts and screws are tightened securely during assembly.
- Verify that the overhead structure from which the swing is hung is stable and capable of supporting the swing's weight capacity.
- Check that the hanging chains are evenly adjusted and free from twists or kinks.

Cushion Flattening:

- While cushions are designed for high rebound, occasional fluffing can help maintain their shape.
- Ensure cushions are not exposed to prolonged heavy moisture, which can affect foam integrity.

Side Table Issues:

- If side tables do not extend or retract smoothly, check for any obstructions or misalignments in their tracks.
- Ensure the support bars for the side tables are correctly engaged when extended.

6. Specifications

Feature	Detail
Brand	Yalissey
Model Number	B0CWP77TP3
Product Dimensions	19"D x 60"W x 11.9"H
Item Weight	72 Pounds
Weight Limit	800 Pounds
Seating Capacity	3
Color	Beige
Frame Material Type	Metal (Alloy Steel)
Upholstery Fabric Type	Polyester
Seat Fill Material	Foam (High Density Foam)
Number of Cup Holders	2
Assembly Required	Yes
Includes All Assembly Tools	Yes
Indoor Outdoor Usage	Outdoor

7. Warranty and Support

Warranty Information:

This Yalissey Porch Swing comes with a Limited Warranty. For specific details regarding coverage and duration, please refer to the warranty documentation included with your purchase or contact Yalissey customer support.

Return Policy:

The product is eligible for a 30-day refund/replacement return policy. Please consult the retailer's return policy for full terms and conditions.

Customer Support:

For further assistance, technical support, or to inquire about replacement parts, please visit the official Yalissey website or contact their customer service department. Contact information can typically be found on the product packaging or the brand's online store.

© 2026 Yalissey. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CWP77TP3

More documents and user manuals: **https://manuals.plus/**