Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Yalissey YS231102-RD

Yalissey 3-Seat Outdoor Patio Porch Swing Instruction Manual

Model: YS231102-RD

Introduction

This manual provides essential instructions for the safe assembly, operation, and maintenance of your Yalissey 3-Seat Outdoor Patio Porch Swing. Please read this guide thoroughly before assembly and use to ensure proper function and longevity of your product. Keep this manual for future reference.

Safety Information

WARNING: Failure to follow these safety instructions may result in serious injury or property damage.

- Ensure all parts are present and undamaged before assembly. Do not use if any parts are missing or broken.
- Assemble the swing on a flat, stable surface.
- Tighten all bolts and nuts securely. Recheck tightness periodically, especially after initial use.
- Do not exceed the maximum weight capacity of 750 lbs.
- Keep children and pets away from the assembly area.
- Do not stand on the swing or use it as a ladder.
- Avoid using the swing in strong winds or severe weather conditions. Secure or store the canopy during such conditions.
- Regularly inspect the swing for signs of wear, damage, or loose components.

Parts List

Before beginning assembly, verify that all components listed below are present. If any parts are missing or damaged, contact customer service.

Part	Description	Quantity
A	Main Frame (Left)	1
B	Main Frame (Right)	1

Part	Description	Quantity
C	Seat Frame	1
D	Backrest Frame	1
E	Adjustable Hardtop Canopy (PVC)	1
F	Seat Cushions (3.6-inch thick, Polyester)	3
G	Cylindrical Pillows	2
H	Cup Holders (Foldable Side Tables)	2
I	Suspension Springs	2
J	Hardware Pack (Bolts, Nuts, Washers, Wrench)	1

Setup and Assembly

Assembly typically requires two adults and takes approximately 2-3 hours. Follow the numbered steps carefully.

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a clean, soft surface to prevent scratches. Verify all parts against the Parts List.
2. **Assemble Main Frame:** Connect the left (A) and right (B) main frames using the provided hardware. Ensure all connections are secure but do not fully tighten bolts until all frame components are in place.
3. **Attach Seat and Backrest:** Secure the seat frame (C) and backrest frame (D) to the main frame. Pay attention to the orientation for proper 3-position adjustment.
4. **Install Suspension Springs:** Attach the suspension springs (I) to the main frame and the seat assembly. These springs allow for the swinging motion.
5. **Mount Hardtop Canopy:** Secure the adjustable hardtop canopy (E) to the top of the main frame. Ensure the adjustment mechanism is functional.



Image: The adjustable hardtop canopy provides protection from sun and rain. It can be adjusted to various angles using the side knobs.

6. **Attach Cup Holders:** Install the foldable cup holders (H) on both sides of the swing.



Image: A close-up of the foldable side table with integrated cup holders, designed to hold beverages and small items.

7. **Place Cushions and Pillows:** Position the thick seat cushions (F) and cylindrical pillows (G) on the swing.



Image: The 3.6-inch thick seat cushions and cylindrical pillows provide enhanced comfort and support.

8. **Final Tightening:** Once all components are assembled, go back and fully tighten all bolts and nuts. Do not overtighten.

For visual guidance, refer to the assembly video below:

▶ **Watch video online**
Yalissey Outdoor Porch Swing with Hardtop

Video: This video demonstrates the assembly process and key features of the Yalissey Outdoor Porch Swing with Hardtop.

Operating Instructions

Adjusting the Backrest (3-Position Convertible)

The swing features a 3-position adjustable backrest, allowing conversion between a swing chair, chaise lounge, and flat bed.

1. **To Adjust:** Locate the adjustment pins on both sides of the backrest. Pull out the pins, adjust the backrest to the

desired angle (105° for sitting, 135° for chaise lounge, 180° for flat bed), and re-insert the pins securely to lock the position.
2. Ensure both sides are adjusted to the same position for stability.

Adjusting the Hardtop Canopy

The hardtop canopy can be adjusted to provide optimal shade or protection from light rain.

1. **To Adjust:** Loosen the knobs on both sides of the canopy frame. Adjust the canopy to the desired angle and tighten the knobs firmly to secure it.

Using the Foldable Cup Holders

The swing includes two foldable side tables with cup holders.

1. **To Use:** Gently pull the side table upwards until it locks into a horizontal position.
2. **To Fold:** Press the release mechanism (if present) or gently push the table downwards until it folds flat against the frame.

Maintenance

Regular maintenance ensures the longevity and safe operation of your porch swing.

- **Cleaning the Frame:** Wipe the alloy steel frame with a damp cloth and mild soap. Rinse thoroughly and dry completely to prevent rust.
- **Cleaning Cushions:** The polyester cushions are splash-water proof. For spills, blot immediately with a clean cloth. For general cleaning, use a mild soap solution and a soft brush, then rinse and air dry. Do not machine wash or tumble dry.
- **Canopy Care:** Clean the PVC hardtop canopy with water and a soft cloth. Avoid abrasive cleaners.



Image: The cushions are designed to be splash-water resistant, allowing for easy cleaning of minor spills.

- **Hardware Check:** Periodically check all bolts, nuts, and screws to ensure they are tight. Tighten as needed.
- **Winter Storage:** During winter months or prolonged periods of non-use, it is recommended to store the cushions indoors and cover the swing to protect it from harsh weather.

Troubleshooting

Problem	Possible Cause	Solution
Swing feels unstable or wobbly.	Loose hardware; uneven ground.	Check and tighten all bolts and nuts. Ensure the swing is placed on a level surface.
Backrest adjustment is difficult.	Pins are stuck or misaligned.	Ensure the pins are fully pulled out before attempting to adjust. Apply a small amount of lubricant if necessary.
Canopy does not stay in position.	Adjustment knobs are loose.	Tighten the canopy adjustment knobs firmly after setting the desired angle.

Problem	Possible Cause	Solution
Squeaking noise during swinging.	Dry or worn springs/joints.	Apply a silicone-based lubricant to the suspension springs and moving joints.

Specifications

- **Model:** YS231102-RD
- **Brand:** Yalissey
- **Product Dimensions:** 19"D x 77"W x 68"H
- **Seat Depth:** 19 inches
- **Frame Material:** Alloy Steel (Powder Coated)
- **Canopy Material:** PVC Hardtop
- **Cushion Material:** Polyester (3.6-inch thick, pure sponge filling)
- **Weight Capacity:** 750 lbs
- **Item Weight:** 84.9 pounds
- **Assembly Required:** Yes
- **Color:** Wine Red (for this variant)



Image: Diagram illustrating the overall dimensions of the Yalissey 3-Seat Outdoor Patio Porch Swing.

Warranty and Support

For warranty information, please refer to the documentation included with your purchase or contact Yalissey customer service directly. If you encounter any problems or require assistance, please reach out to our support team.
Customer Service: We provide 7/24H after-sales service. If you have any questions or need help, please contact us through the retailer's platform or the official Yalissey website.

© 2024 Yalissey. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the

question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CWP77ZYM

More documents and user manuals: **https://manuals.plus/**