Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

MERACH S19

MERACH S19 Recumbent Exercise Bike User Manual

Introduction

This manual provides essential information for the safe and effective use of your MERACH S19 Recumbent Exercise Bike. Please read these instructions thoroughly before assembly and operation. Retain this manual for future reference.

Safety Information

Before beginning any exercise program, consult with your physician. It is important to ensure you are physically able to perform the exercises. Improper or excessive training can result in health injury.

- Always place the exercise bike on a flat, stable surface.
- Keep children and pets away from the equipment during use.
- Ensure all bolts and nuts are securely tightened before each use.
- The maximum user weight capacity for this bike is **330 pounds (150 kg)**.
- Recommended user height is between **5'2" and 5'10" (157 cm - 178 cm)**
- Wear appropriate exercise clothing and footwear.
- Stop exercising immediately if you feel faint, dizzy, or experience pain.

Product Overview

The MERACH S19 Recumbent Exercise Bike is designed for home fitness, offering a comfortable and effective workout experience.

Key Features

- **8-Level Magnetic Resistance System:** Adjust resistance with a simple twist for varied workout intensity.
- **Ergonomic Thicker Seat & Backrest:** Features 8 seat positions, a breathable mesh backrest, and thick padding for comfort.
- **Silent Dual-Belt Drive System:** High-speed, high-inertia design with a 6.6lb perimeter-weighted flywheel for quiet operation.
- **LCD Display:** Tracks time, distance, speed, calories burned, and heart rate.

- **MERACH App Connectivity:** Connects via Bluetooth to the MERACH app for guided workouts and progress tracking.
- **Heart Rate Tracking:** Integrated sensors in the handlebars monitor heart rate during exercise.
- **Frosted Handlebar:** Provides a secure, non-slip grip and helps manage sweat.



The MERACH S19 Recumbent Exercise Bike in use, demonstrating its ergonomic design and comfortable seating position.



A user adjusting the 8-level resistance system using the 'DriveFeel' knob on the MERACH S19 Recumbent Exercise Bike.



An illustration highlighting the breathable mesh backrest and thick, comfortable seat padding of the MERACH S19 Recumbent Exercise Bike.



An exploded view illustrating the silent dual-belt drive system and 6.6lb perimeter-weighted flywheel, responsible for smooth and quiet operation.

The LCD display showing workout metrics and a smartphone screen demonstrating the MERACH app's connectivity and data tracking features.

Assembly Instructions

The MERACH S19 Recumbent Exercise Bike arrives 80% pre-assembled to simplify setup. Most users can complete assembly within 30 minutes by following the included instructions and installation video.

Assembly Steps Overview:

1. Unpack all components and verify against the parts list.
2. Attach the front and rear stabilizers to the main frame.
3. Install the pedals, ensuring they are tightened correctly (left pedal is reverse threaded).
4. Mount the seat and backrest assembly onto the frame.

5. Connect the handlebar post and attach the LCD console.
6. Connect any necessary sensor cables.

Refer to the detailed graphical instructions provided in the packaging for specific steps and diagrams. An installation video is also available to guide you through the process.



Components of the MERACH S19 Recumbent Exercise Bike displayed before final assembly, emphasizing its 90% pre-assembled status for quick setup.

Operating Instructions

Adjusting Resistance

The MERACH S19 features an 8-level magnetic resistance system. To adjust the resistance, locate the 'DriveFeel' knob on the main console. Turn the knob clockwise to increase resistance and counter-clockwise to decrease it. Start with a lower resistance and gradually increase as your fitness improves.

Seat Adjustment

The seat can be adjusted to 8 different positions to accommodate various leg lengths. Locate the adjustment lever beneath the seat. Pull the lever to unlock the seat, slide it to your desired position, and release the lever to lock it in place. Ensure the seat is securely locked before beginning your workout.

Using the LCD Display

The integrated LCD display provides real-time workout data:

- **Time:** Duration of your workout.
- **Distance:** Total distance covered.
- **Speed:** Current cycling speed.
- **Calories Burned:** Estimated calories expended.
- **Heart Rate:** Your pulse, measured via the handlebar sensors.

Use the 'MODE' button to cycle through display modes and 'RESET' to clear current workout data. The 'SET' button may be used for specific settings or target goals if available.

MERACH App Connectivity

The MERACH S19 bike can connect to the MERACH app via Bluetooth for an enhanced workout experience:

1. Download the MERACH app from your device's app store.
2. Enable Bluetooth on your smartphone or tablet.
3. Open the MERACH app and follow the on-screen instructions to pair with your S19 bike.
4. Access various courses, training modes, and track your progress within the app.



A user enjoying an 'immersive ride' experience on the MERACH S19, with a tablet or screen displaying virtual routes.

Maintenance and Care

Regular maintenance ensures the longevity and optimal performance of your MERACH S19 Recumbent Exercise Bike.

- **Cleaning:** Wipe down the bike with a damp cloth after each use to remove sweat and dust. Avoid abrasive cleaners.
- **Inspection:** Periodically check all bolts, nuts, and moving parts for tightness and wear. Tighten any loose fasteners.
- **Lubrication:** The magnetic resistance system is generally maintenance-free. Do not apply lubricants to the belt drive system unless specifically instructed by customer support.

- **Storage:** Store the bike in a dry, cool place away from direct sunlight and extreme temperatures.

Troubleshooting

If you encounter issues with your MERACH S19 Recumbent Exercise Bike, refer to the following common solutions:

Problem	Possible Cause	Solution
LCD display not working	Batteries are dead or incorrectly installed. Loose cable connection.	Replace AAA batteries (2 required). Check that all display cables are securely connected.
No resistance change	Resistance cable disconnected or damaged.	Inspect the resistance cable connection to the 'DriveFeel' knob and the flywheel mechanism. Contact customer support if damaged.
Unusual noise during operation	Loose components. Friction from moving parts.	Check all assembly bolts and nuts for tightness. Ensure no foreign objects are near the flywheel or pedals.
Cannot connect to MERACH App	Bluetooth is off. App not updated. Bike not powered on.	Ensure Bluetooth is enabled on your device. Update the MERACH app. Ensure the bike's console is active.

If the problem persists after attempting these solutions, please contact MERACH customer service for further assistance.

Product Specifications

Feature	Detail
Model Number	MR-S19
Product Dimensions (L x W x H)	122 x 60 x 118 cm (48.03L x 23.62W x 46.46H inches)
Item Weight	43.54 kg (57.32 Pounds)
Maximum Weight Capacity	330 Pounds
Recommended Height	5'2" - 5'10" (Inseam Length: 28.35-35.43 in)
Resistance Mechanism	Magnetic
Resistance Levels	8-Level Car-Style Adjustment
Drive System	Dual-Belt
Flywheel Weight	6.6 lbs (Perimeter-weighted)
Display Type	LCD
Metrics Tracked	Calories Burned, Distance, Heart Rate, Speed, Time
Connectivity	Bluetooth (MERACH App)

Feature	Detail
Power Source	Battery Powered (2 AAA batteries included)
Material	Metal
Color	Black



A visual guide to the physical dimensions of the MERACH S19 Recumbent Exercise Bike, including length, width, height, and recommended user height range.

Warranty and Customer Support

MERACH is committed to product quality and customer satisfaction. Your MERACH S19 Recumbent Exercise Bike comes with a **one-year manufacturer's warranty**.
For any issues, questions, or assistance, please contact our customer service team. We aim to provide swift support and are available to assist you.

- **Warranty Period:** One year manufacturer's warranty.

- **Customer Service Response:** Replies typically within 24 hours.
- **Returns:** 30-day free return policy.



An overview of MERACH's commitment to customer service, detailing warranty periods, response times, and return policy.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CWRXTLWN

More documents and user manuals: **https://manuals.plus/**