Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

NEBO NEB-ZAP-0001

NEBO Mini Bug Zapper & Lantern

User Manual

Model: NEB-ZAP-0001

Introduction

The NEBO Mini Bug Zapper & Lantern is a compact and versatile device designed to provide both insect control and illumination. Featuring a powerful 700-volt electrical grid for zapping insects and a dual-band UV light, it also functions as a lantern with adjustable brightness. Its portable design makes it suitable for various outdoor activities such as hiking, camping, hunting, and fishing.

Setup

Charging the Device

Before first use, fully charge the NEBO Mini Bug Zapper & Lantern. The device is equipped with a rechargeable Lithium Ion battery and charges via a USB-C port.

- Locate the USB-C charging port on the device.
- Connect the included USB-A to USB-C charging cable to the device and a compatible USB power source (e.g., wall adapter, power bank, computer USB port).
- An indicator light will show the charging status. Refer to the indicator light behavior for full charge confirmation.
- Charging typically takes approximately one hour for a full charge.



Image: The NEBO Mini Bug Zapper & Lantern connected to a USB-C charging cable, showing the charging port and indicator light.

Operating Instructions

Powering On/Off and Mode Selection

The device features a single power button for controlling both the lantern and bug zapper functions. Press the button to cycle through the available modes.





Image: A close-up view of the NEBO Mini Bug Zapper & Lantern, highlighting its design and power button.

Available Modes and Run Times

The NEBO Mini Bug Zapper & Lantern offers several operational modes, each with different light outputs and battery run times:

Modes	Output (Lumens)	Run Time (Hours)
Lantern High	150	5
Lantern Low	50	15
Zapper	-	16
Lantern High + Zap	150	4
Lantern Low + Zap	50	8



Image: A visual representation of the operational modes, their light output in lumens, and approximate run times in hours.

Bug Zapper Function

When the zapper function is active, the device emits a dual-band UV light to attract insects, which are then eliminated by the powerful 700-volt electrical grid. This function can be used independently or in conjunction with the lantern modes.



Image: The NEBO Mini Bug Zapper & Lantern with its internal 700-volt electrical grid visible, designed to zap insects.

Portability and Usage

The compact and lightweight design, comparable in size to a 12-oz soda can, makes the device easy to carry and hang. It is ideal for use in tents, on patios, or during outdoor activities.



Image: A person holding the NEBO Mini Bug Zapper & Lantern at night, demonstrating its compact size and portability.

Maintenance

Cleaning the Zapper Grid

Over time, dead insects may accumulate on the electrical grid, reducing its effectiveness. Use the included cleaning brush to gently remove any debris.

- Ensure the device is turned **OFF** before cleaning.
- Use the small brush to carefully sweep away any insect remains from the electrical grid.
- Do not use water or any liquid cleaners directly on the electrical grid.

Battery Care and Storage

To prolong the life of the Lithium Ion battery:

- Avoid completely draining the battery before recharging.
- If storing the device for an extended period, charge it to approximately 50% every few months.
- Store the device in a cool, dry place away from direct sunlight and extreme temperatures.

Troubleshooting

If you encounter issues with your NEBO Mini Bug Zapper & Lantern, refer to the following common troubleshooting steps:

- **Device not turning on:**
  - Ensure the battery is charged. Connect the device to a power source using the USB-C cable and allow it to charge for at least 30 minutes.
  - Verify the charging cable and power adapter are functioning correctly.
- **Zapper not working:**
  - Check if the zapper mode is activated according to the operating instructions.
  - Clean the electrical grid using the provided brush to remove any accumulated debris that might be preventing proper function.
  - Ensure the battery has sufficient charge.
- **Lantern light is dim or not working:**
  - Confirm the device is in a lantern mode (Lantern High, Lantern Low, or combined modes).
  - Recharge the battery. Low battery levels can result in reduced light output.
- **Short battery life:**
  - Ensure the device is fully charged before use.
  - Operating in "Lantern High" or "Lantern High + Zap" modes will consume battery faster than "Lantern Low" or "Zapper only" modes. Refer to the run time table.
  - Battery performance can degrade over time with extensive use.

If these steps do not resolve the issue, please contact NEBO customer support for further assistance.

Specifications

Feature	Detail
Brand	NEBO
Model Number	NEB-ZAP-0001
Style	Compact
Item Weight	0.42 Pounds (6.7 ounces)
Product Dimensions	5.99 x 2.76 x 5.99 inches

Feature	Detail
Recommended Uses	Hiking, Camping, Hunting, Fishing
Is Electric	Yes
Target Species	Bug
Unit Count	1.0 Count
UPC	645397942160
Batteries	1 Lithium Ion battery required (included)
Battery Cell Type	Lithium Ion
Electrical Grid Voltage	700-volt

Warranty and Support

For information regarding product warranty, please refer to the warranty card included with your purchase or visit the official NEBO website. NEBO is committed to providing high-quality products and customer satisfaction.
If you require technical support, have questions about your product, or need to inquire about repairs, please contact NEBO customer service through their official channels. You can often find contact information on the NEBO website or within the product packaging.
Visit the official NEBO Store for more information and product registration: NEBO Official Store

© 2024 NEBO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CX3QMVXF

More documents and user manuals: **https://manuals.plus/**