Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

DeLUX KF18

DeLUX KF18 Foldable Keyboard User Manual

Model: KF18 | Brand: DeLUX

1. Product Overview

The DeLUX KF18 is a versatile, foldable keyboard designed for portability and multi-device compatibility. It features a unique 2-in-1 touchpad that functions as both a mouse and a numeric keypad, enhancing productivity on the go. With support for 2.4G wireless and Bluetooth dual channels, it can connect to up to three devices simultaneously.



Image: The DeLUX KF18 Foldable Keyboard shown in both its unfolded, ready-to-use state and its compact, folded state.

Key Features:

- **2-in-1 Sensitive Touchpad:** Combines mouse functionality and a numeric keypad for versatile input.
- **Mini and Elegant Design:** Lightweight, tri-fold design with a durable PU leather cover, ideal for travel.

- **Stable Multi-Device Connection:** Supports 2.4G wireless and Bluetooth (BT1, BT2) for connecting up to 3 devices.
- **Built-in Rechargeable Battery:** Offers up to 40 hours of use or 90 days of standby on a 1.5-hour charge.
- **Scissor Switches and Quiet Typing:** Provides a silent and responsive typing experience, reducing fatigue.

2. What's in the Box

Upon opening your DeLUX KF18 package, please ensure all the following items are present:



Image: All components included in the DeLUX KF18 package: the foldable keyboard, 2.4G receiver, stand holder, Type-C charging cable, and user manual.

- DeLUX KF18 Foldable Keyboard
- 2.4G Receiver (magnetically attached to the keyboard)
- Stand Holder
- Type-C Charging Cable
- User Manual (this document)

3. Setup

3.1 Charging the Keyboard

Before initial use, fully charge the keyboard. Connect the provided Type-C charging cable to the keyboard's charging port and the other end to a USB power source (e.g., computer USB port, USB wall adapter).



Image: The DeLUX KF18 keyboard connected to a laptop via its USB-C charging cable, illustrating the charging process.

- Charging Time: Approximately 1.5 hours for a full charge.
- Battery Life: Up to 40 hours of continuous use or 90 days of standby.

3.2 Power On/Off

To power on the keyboard, simply unfold it. The keyboard will automatically power on. To power off, fold the keyboard back into its compact form. This action automatically turns off the device to conserve battery.

3.3 Connecting to Devices

The DeLUX KF18 supports connection to up to three devices via 2.4G wireless or Bluetooth (BT1, BT2). You can easily switch between connected devices.



Image: A diagram illustrating the DeLUX KF18 keyboard's ability to connect to multiple devices (smartphone, monitor, tablet) via 2.4G and Bluetooth (BT1, BT2).

3.3.1 2.4G Wireless Connection (for PC/Laptop)

1. Locate the 2.4G USB receiver, which is magnetically stored within the keyboard.
2. Plug the 2.4G receiver into an available USB port on your computer.
3. Unfold the keyboard to power it on.
4. Press **Fn + D** (or the key with the 2.4G icon) to switch to 2.4G mode. The indicator light will confirm the connection.

3.3.2 Bluetooth Connection (for iOS, Android, Windows, Mac)

The keyboard supports two Bluetooth channels (BT1 and BT2).

1. Unfold the keyboard to power it on.
2. Press **Fn + A** for BT1 or **Fn + S** for BT2 to select the desired Bluetooth channel.
3. Press **Fn + C** (Pairing key) to enter pairing mode. The indicator light will blink rapidly.
4. On your device (smartphone, tablet, computer), go to Bluetooth settings and search for new devices.
5. Select "DELUX KF18" from the list of available devices to connect. The indicator light will stop blinking once connected.
6. To switch between connected Bluetooth devices, simply press **Fn + A** (BT1) or **Fn + S** (BT2).

▶ **Watch video online**
DELUX KF18 Foldable Keyboard with 2-in-1 Touchpad

Video: An official product video demonstrating the features and connectivity of the DELUX KF18 Foldable Keyboard with its 2-in-1 Touchpad.

4. Operating the Keyboard

4.1 2-in-1 Touchpad Functionality

The integrated touchpad can function as a standard mouse trackpad or a numeric keypad. This dual functionality provides flexibility for different tasks.



Image: The DeLUX KF18 keyboard highlighting its 2-in-1 sensitive touchpad, which combines numeric pad and mouse functions.

- **Mouse Function (Trackpad Mode):** By default, the touchpad operates as a mouse trackpad, supporting gestures like two-finger scrolling.
- **Numeric Keypad Mode:** To switch the touchpad to a numeric keypad, press **Fn + Spacebar**. The numbers on the touchpad will illuminate, indicating numeric keypad mode. Press **Fn + Spacebar** again to revert to trackpad mode.

4.2 Multimedia Shortcuts

The keyboard includes various multimedia shortcuts accessible via the **Fn** key in combination with the F1-F12 keys. These shortcuts allow for quick control of media playback, volume, and other system functions.



Image: A diagram illustrating the multimedia shortcuts on the DeLUX KF18 keyboard, activated by pressing the Fn key in combination with F1-F12 keys.

Refer to the key labels for specific functions (e.g., volume up/down, play/pause, previous/next track, home, end, page up/down).

4.3 Compatibility

The DeLUX KF18 keyboard is compatible with a wide range of operating systems and devices:

- iOS (iPhones, iPads)
- Android (Smartphones, Tablets)
- Windows (PCs, Laptops, Tablets)
- Mac (MacBooks, iMacs)

5. Maintenance

To ensure the longevity and optimal performance of your DeLUX KF18 keyboard, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe down the keyboard surface. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid excessive moisture.
- **PU Leather Cover:** The PU leather cover is designed to be scratch and water resistant. Clean it with a damp cloth as needed.
- **Storage:** When not in use, fold the keyboard to protect the keys and touchpad. Store it in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Liquids:** Do not expose the keyboard to liquids. In case of accidental spills, immediately power off the keyboard (by folding it) and allow it to dry completely before reuse.
- **Handle with Care:** While durable, avoid dropping the keyboard or applying excessive force to the keys or hinges.

6. Troubleshooting

If you encounter issues with your DeLUX KF18 keyboard, please refer to the following common problems and

solutions:

6.1 Keyboard Not Connecting/Pairing

- **Check Power:** Ensure the keyboard is unfolded and powered on.
- **Battery Level:** A low battery can prevent connection. Charge the keyboard fully.
- **Correct Mode:** Verify you are in the correct connection mode (2.4G, BT1, or BT2) by pressing **Fn + D**, **Fn + A**, or **Fn + S**.
- **Pairing Mode:** For Bluetooth, ensure the keyboard is in pairing mode (**Fn + C**, indicator light blinking).
- **Device Bluetooth:** Make sure Bluetooth is enabled on your device and it's discoverable.
- **Forget Device:** If previously paired, try removing/forgetting the keyboard from your device's Bluetooth list and re-pairing.
- **Interference:** Move away from other wireless devices that might cause interference.

6.2 Keys Not Responding or Typing Incorrectly

- **Connection Stability:** Reconnect the keyboard to your device.
- **Battery Level:** Low battery can cause erratic behavior. Charge the keyboard.
- **Dust/Debris:** Check for any dust or debris under the keys. Gently clean the keyboard.
- **Operating System Mode:** Ensure the keyboard is set to the correct operating system mode (e.g., **Fn + Q** for iOS, **Fn + W** for Android, **Fn + E** for Windows, **Fn + R** for Mac).

6.3 Touchpad Not Working or Responding

- **Mode Switch:** Ensure the touchpad is in mouse mode and not numeric keypad mode. Press **Fn + Spacebar** to toggle.
- **Clean Touchpad:** Ensure the touchpad surface is clean and free of obstructions.
- **Reconnection:** Disconnect and reconnect the keyboard.

6.4 Short Battery Life

- **Full Charge:** Ensure the keyboard is fully charged (1.5 hours).
- **Usage Patterns:** Heavy usage, especially with constant typing or touchpad use, will consume battery faster.
- **Power Off:** Always fold the keyboard when not in use to automatically power it off and conserve battery.

7. Specifications

Feature	Detail
Brand	DeLUX
Model Number	KF18
Connectivity Technology	Bluetooth, 2.4G Wireless
Compatible Devices	PC, Tablet, Smartphone (iOS, Android, Windows, Mac)

Feature	Detail
Keyboard Description	Multimedia
Special Features	Portable, Foldable, Rechargeable, Trackpad (2-in-1)
Number of Keys	64
Style	3-fold
Product Dimensions (Unfolded)	13.46"L x 4.25"W x 0.37"H (342mm x 108mm x 9.5mm)
Product Dimensions (Folded)	7.17"L x 4.25"W x 0.63"H (182mm x 108mm x 16mm)
Item Weight	8.5 ounces (240g)
Material	Acrylonitrile Butadiene Styrene (ABS) with PU Leather Cover
Battery Type	1 Lithium Ion battery (included)
Manufacturer	DELUX
Country of Origin	China

8. Warranty and Support

DeLUX products are manufactured with high-quality standards. For information regarding warranty coverage, technical support, or replacement parts, please visit the official DeLUX store or contact customer service through the details provided on the product packaging or the retailer's website.
You can find more information and support resources at theDeLUX Amazon Store.

© 2024 DeLUX. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CXH7ZNP7

More documents and user manuals: **https://manuals.plus/**