Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Geepas GTR56032

Geepas Digital Hair Clipper GTR56032 User Manual

1. Introduction

This manual provides essential instructions for the safe and effective use of your Geepas Digital Hair Clipper GTR56032. Please read this manual thoroughly before first use and retain it for future reference. This device is designed for personal hair and beard trimming.

2. Safety Instructions

To reduce the risk of electric shock, injury, or fire, always follow these basic safety precautions:

- Keep the appliance dry. Do not immerse the clipper in water, despite its waterproof design, especially during charging.
- Do not use the appliance with a damaged cord or plug.
- Keep the appliance away from children.
- Unplug the appliance before cleaning or performing maintenance.
- Use only the charging cable provided or a compatible Type-C cable with DC5V 1A input.
- Avoid placing the appliance on hot surfaces.
- Do not disassemble the appliance. For repairs, contact qualified service personnel.
- Ensure the blades are properly attached and not damaged before use to prevent skin irritation or injury.

3. Package Contents

Verify that all items are present in the package:

- Geepas Digital Hair Clipper GTR56032
- Four Comb Guides (various lengths)
- Cleaning Brush
- Lubricating Oil
- Type-C Charging Cable



This image displays the complete Geepas Digital Hair Clipper GTR56032 package. It includes the main clipper unit, four different sized comb guides for varying hair lengths, a small cleaning brush for maintenance, and a bottle of lubricating oil to keep the blades in optimal condition.

4. Product Overview

The Geepas Digital Hair Clipper GTR56032 features a high-performance titanium-coated blade, a digital display for battery status, and an ergonomic design for comfortable handling.

Key Features:

- **Digital Display:** Clearly indicates battery charge level.
- **Sharp Blade:** Titanium coating with a 45-degree acute angle design for precise and skin-friendly trimming.
- **Waterproof Design:** Allows for use in wet conditions and easy cleaning.
- **Rechargeable Battery:** Provides 4 hours of operating time after a 3-hour charge via Type-C port.
- **Ergonomic Design:** Compact and lightweight for comfortable and anti-slip grip.



This image illustrates the ergonomic design of the Geepas Digital Hair Clipper GTR56032 as it is held in a hand. The digital display, which indicates battery status, is clearly visible on the lower part of the clipper body.

5. Setup

5.1 Initial Charging

1. Before first use, fully charge the clipper for approximately 3 hours.
2. Connect the Type-C charging cable to the port at the bottom of the clipper and plug the other end into a compatible USB power adapter (DC5V 1A).
3. The digital display will show charging progress. A full charge provides up to 4 hours of cordless operation.

5.2 Attaching Comb Guides

1. Ensure the clipper is turned off.
2. Select the desired comb guide for your preferred hair length.
3. Align the comb guide with the clipper blade and push it firmly until it clicks into place.
4. To remove, gently pull the comb guide away from the blade.

6. Operating Instructions

6.1 Turning On/Off

Press the power button located on the clipper body to turn the device on or off.

6.2 Adjusting Cutting Length

The clipper features an adjustable blade lever for fine-tuning cutting length without a comb guide, and four comb guides for longer lengths.

- **Blade Adjustment Lever:** Use the lever on the side of the clipper to adjust the blade's cutting length for precise detailing or blending.
- **Comb Guides:** Attach one of the four provided comb guides for uniform cutting lengths across larger areas.



A detailed view of the Geepas Digital Hair Clipper GTR56032's blade adjustment lever. This lever allows users to fine-tune the cutting

length of the blade for precise grooming without a comb guide.

6.3 Hair and Beard Trimming

1. Ensure hair is clean and dry before trimming.
2. Select the appropriate comb guide or adjust the blade lever for your desired length.
3. Start trimming from a longer setting and gradually reduce the length if needed.
4. Move the clipper against the direction of hair growth for an even cut.
5. For detailing, remove the comb guide and use the adjustable blade directly.

7. Maintenance

7.1 Cleaning the Blades

1. Turn off the clipper and disconnect it from the power source.
2. Remove any attached comb guides.
3. Use the provided cleaning brush to remove loose hairs from the blades.
4. Since the clipper is waterproof, you can rinse the blades under running water. Ensure the clipper is completely dry before storage or next use.



This close-up image focuses on the sharp, titanium-coated blade of the Geepas Digital Hair Clipper GTR56032, highlighting its precision cutting edge designed for efficient and safe hair trimming.

7.2 Oiling the Blades

Regular oiling ensures optimal performance and extends blade life.

1. After cleaning and drying the blades, apply 1-2 drops of the lubricating oil (or a similar light machine oil) to the teeth of the blades.
2. Turn on the clipper for a few seconds to distribute the oil evenly.
3. Wipe off any excess oil with a soft cloth.

7.3 Storage

Store the clipper in a cool, dry place, away from direct sunlight and out of reach of children.

8. Troubleshooting

If you encounter issues with your Geepas Digital Hair Clipper, refer to the following common solutions:

Problem	Possible Cause	Solution
Clipper does not turn on.	Battery is depleted.	Charge the clipper for 3 hours. Check the digital display for battery status.
Poor cutting performance or pulling hair.	Blades are dull, dirty, or not oiled.	Clean the blades thoroughly and apply lubricating oil. If blades are dull, consider professional sharpening or replacement.
Clipper stops during use.	Battery is low.	Recharge the clipper.
Digital display not working.	Device malfunction or battery issue.	Ensure the device is charged. If the issue persists, contact customer support.

9. Specifications

Feature	Detail
Model Number	GTR56032
Brand	Geepas
Power Source	Battery Powered (Rechargeable)
Charging Input	DC5V 1A (Type-C)
Charging Time	3 Hours
Operating Time	Up to 4 Hours
Blade Material	Titanium
Special Features	Easy to Clean, USB Rechargeable, Waterproof, Digital Display
Color	Black
Item Weight	0.45 Kilograms
Package Dimensions	26.5 x 14.9 x 6.7 cm

10. Warranty and Support

The Geepas Digital Hair Clipper GTR56032 comes with a**2-year manufacturer's warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use.

For warranty claims, technical support, or service inquiries, please refer to the contact information provided with your purchase documentation or visit the official Geepas website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CY4HDR2M

More documents and user manuals: **https://manuals.plus/**