Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Skullcandy S2PPW-S749

Skullcandy Push Play Active Wireless Earbuds

Model: S2PPW-S749
Brand: Skullcandy

Introduction

The Skullcandy Push Play Active earbuds are engineered for an active lifestyle, providing a secure and comfortable fit for any activity. They are built to withstand sweat, water, dust, and dirt, ensuring durability in various conditions. With an extended battery life, these earbuds are designed to keep up with your longest adventures.

Key Features:

- **34 Hours of Playtime:** Enjoy extended listening with combined earbud and charging case battery life.
- **IP55 Rating:** Resistant to sweat, water, dust, and dirt for reliable performance in any environment.
- **Comfortably Secure:** Flexible over-ear hangers ensure the earbuds stay in place during intense physical activity.
- **Stay-Aware Mode:** Remain connected to your surroundings while enjoying your audio.
- **Intuitive Controls:** Easily manage your music and calls directly from the earbuds.



Figure 1: Skullcandy Push Play Active Earbuds and Charging Case.



Figure 2: User wearing Skullcandy Push Play Active Earbuds, demonstrating secure fit during activity.

What's in the Box

Your Skullcandy Push Play Active earbuds package includes the following items:

- Skullcandy Push Play Active Earbuds
- Charging Case
- USB-C Charging Cable
- User Manual
- Multiple Pairs of Eartips (various sizes for optimal fit)

▶ **Watch video online**

Skullcandy Push Play Active Unboxing!

Video 1: Unboxing the Skullcandy Push Play Active Earbuds, showing all included components.

Setup

Initial Charge:

1. Place both earbuds into the charging case.
2. Connect the USB-C charging cable to the case and a power source.
3. Allow the earbuds and case to fully charge before first use (approximately 1.5 hours). The LED indicators on the case will show charging status.

Bluetooth Pairing:

1. Ensure your earbuds are in the charging case and the lid is open.
2. On your device (smartphone, tablet, etc.), go to Bluetooth settings and turn Bluetooth ON.
3. Select "Push Play Active" from the list of available devices.
4. Once connected, you will hear an audible confirmation.

Optimal Fit:

Selecting the correct eartip size is crucial for sound quality and secure fit. Experiment with the different sizes provided to find the best seal for your ears.

Operating Instructions

Controls:

The Push Play Active earbuds feature intuitive physical buttons for controlling various functions:

- **Play/Pause:** Press the button on either earbud once.
- **Track Forward:** Press the button on the right earbud twice.
- **Track Back:** Press the button on the left earbud twice.
- **Volume Up:** Press the button on the right earbud three times.
- **Volume Down:** Press the button on the left earbud three times.
- **Answer/End Call:** Press the button on either earbud once.
- **Reject Call:** Press and hold the button on either earbud for 2 seconds.
- **Activate Voice Assistant:** Press and hold the button on either earbud for 1 second.

Stay-Aware Mode:

Stay-Aware Mode allows you to hear your surroundings while listening to audio. This feature is ideal for outdoor activities or when you need to be aware of your environment.

- **Toggle Stay-Aware Mode:** Press and hold the button on either earbud for 1 second.

EQ Modes:

The earbuds come with three built-in EQ modes to optimize your listening experience:

- **Music Mode:** Balanced sound for general listening.
- **Podcast Mode:** Emphasizes vocals for clear dialogue.
- **Bass Boost Mode:** Enhanced bass for a more powerful sound.

To cycle through EQ modes, tap the right earbud four times.

Solo Use:

Both earbuds can be used independently. Simply leave one earbud in the charging case and use the other for mono listening.

Charging & Battery

The Skullcandy Push Play Active earbuds offer impressive battery life to keep your music going:

- **Total Playtime:** Up to 34 hours with the charging case.
- **Earbud Playtime:** Approximately 10 hours on a single charge.

Charging the Earbuds and Case:

1. Place the earbuds into the charging case. Ensure they are properly seated.
2. Connect the provided USB-C cable to the charging port on the case and to a USB power adapter (not included).
3. The LED indicators on the case will illuminate to show charging progress.

Rapid Charging:

The earbuds support rapid charging, providing approximately 2 hours of playtime from just a 10-minute charge.



Figure 3: Earbuds being placed into the charging case.

Maintenance

Cleaning:

- Regularly clean your earbuds and charging case with a soft, dry, lint-free cloth.
- Remove eartips and clean them separately with mild soap and water if necessary. Ensure they are completely dry before reattaching.
- Avoid using abrasive cleaners or solvents.

Storage:

When not in use, store the earbuds in their charging case to protect them from dust and damage.

Troubleshooting

No Audio/Connectivity Issues:

- Ensure earbuds are charged.
- Verify Bluetooth is enabled on your device and the earbuds are paired.
- Try unpairing and re-pairing the earbuds with your device.
- If only one earbud is working, ensure both are out of the case and connected.

Charging Problems:

- Check the USB-C cable and power adapter for damage.
- Ensure the charging contacts on the earbuds and in the case are clean and free of debris.

Sound Quality Issues:

- Ensure eartips provide a good seal in your ear canal.
- Clean any earwax buildup from the eartips and speaker mesh.
- Try different EQ modes to see if it improves the sound.

Specifications

Feature	Detail
Model Name	Push Play Active
Model Number	S2PPW-S749
Connectivity Technology	Wireless (Bluetooth)
Water Resistance Level	IP55 (Sweat, Water, Dust Resistant)
Battery Life (Total)	34 Hours
Battery Life (Earbuds)	10 Hours
Charging Time	1.5 Hours
Control Method	Physical Buttons
Ear Placement	In Ear with Over-Ear Hanger
Item Weight	2.12 ounces (60 Grams)
Product Dimensions	5.83 x 4.09 x 1.61 inches

Warranty & Support

Warranty Information:

The Skullcandy Push Play Active earbuds come with a 1-year US warranty. Please retain your proof of purchase for warranty claims.

Customer Support:

For further assistance, troubleshooting, or warranty inquiries, please visit the official Skullcandy support website or contact their customer service team. Refer to the packaging or Skullcandy's official website for the most up-to-date contact information.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question