Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Sweetcrispy ELTP40-BK

Sweetcrispy Electric Adjustable Height Standing Desk 40x24 inch - User Manual

Model: ELTP40-BK

Introduction

This manual provides essential instructions for the assembly, operation, maintenance, and troubleshooting of your Sweetcrispy Electric Adjustable Height Standing Desk (Model ELTP40-BK). Please read this manual thoroughly before assembly and use to ensure safe and efficient operation.

Safety Information

- Ensure all components are present and undamaged before assembly.
- Do not exceed the maximum weight capacity of **176 lbs (80 kg)**.
- Keep children and pets away from the desk during operation to prevent injury.
- Ensure there are no obstructions in the desk's path during height adjustment.
- Only use the provided power adapter and control panel.
- If the desk exhibits unusual behavior or noise, disconnect power and contact support.

Package Contents

Verify that all parts listed below are included in your package. Refer to the assembly diagram for visual identification.

- Desktop (2 spliced panels)
- Desk Legs (2)
- Crossbar/Frame components
- Control Panel with LED display
- Power Adapter and Cable
- Assembly Tools
- Wire Holes (2)
- Sturdy Hooks (2)
- All necessary screws and fasteners

Setup and Assembly

Assembly typically takes less than 30 minutes. Follow the detailed instructions provided in the included installation manual. Ensure you have adequate space for assembly.

1. Unpack all components and verify against the package contents list.
2. Assemble the desk frame according to the visual guide in the separate instruction manual.
3. Attach the two spliced desktop panels securely to the frame.
4. Install the control panel on the underside of the desktop in a convenient location.
5. Connect the motor and control panel cables to the power adapter.
6. Attach the wire holes and hooks as desired for cable management and accessory storage.
7. Place the desk in its desired location, ensuring it is level and stable. Adjust the leveling feet if necessary.



Figure 1: Product dimensions and key features including wire holes, hooks, and desktop splicing.



Figure 2: Fully assembled Sweetcrispy standing desk with accessories.

Operating Instructions

Control Panel Overview



Figure 3: Electric Standing Desk Smart Control Panel.

- **LED Digital Display:** Shows the current desk height.
- **Up (▲) / Down (▼) Buttons:** Press and hold to adjust the desk height continuously. Release to stop.
- **Memory Presets (1, 2, 3):**One-press buttons to move the desk to a saved height.
- **Save (S) Button:** Used to store current height settings into memory presets.

Adjusting Height

Use the Up (▲) and Down (▼) buttons to manually adjust the desk to your desired sitting or standing position. The desk smoothly adjusts between 28.7 inches and 46.5 inches.



Figure 4: Wide height range demonstration (28.7" to 46.5").

Setting Memory Presets

1. Adjust the desk to your desired height using the Up/Down buttons.
2. Press the "S" (Save) button. The LED display will show "S-".
3. Within 3 seconds, press the desired memory button (1, 2, or 3). The LED display will show "S-1", "S-2", or "S-3" to confirm the setting.

To use a preset, simply press the corresponding number button (1, 2, or 3). The desk will automatically move to the saved height.

Anti-Collision Feature

The desk is equipped with an anti-collision system. If the desk encounters an obstruction during height adjustment, it will automatically stop and reverse slightly to prevent damage. Ensure the area around the desk is clear before operation.



Figure 5: Anti-Collision and Quiet Lift Design.

Maintenance

- **Cleaning:** Wipe the desk surface and frame with a dry cloth. Avoid abrasive cleaners or harsh chemicals.
- **Weight Capacity:** Do not place items exceeding **176 lbs (80 kg)** on the desk.
- **Cable Management:** Regularly check and organize cables to prevent entanglement or damage. Utilize the integrated wire holes and hooks.
- **Inspection:** Periodically check all screws and fasteners to ensure they are tight.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Desk does not move or respond to controls.	Power cable disconnected, control panel error, or motor overload.	Check if the power cable is securely plugged into the wall outlet and the desk. Unplug the desk from the power source for 10 seconds, then plug it back in to reset the system. Reduce the weight on the desk if it exceeds the maximum capacity.
Desk moves unevenly or makes unusual noise.	Uneven load, loose fasteners, or obstruction.	Ensure weight is evenly distributed on the desktop. Check and tighten all assembly screws. Inspect for any obstructions under or around the desk.
Anti-collision feature triggers frequently.	Obstruction in the desk's path.	Clear the area around the desk of any objects that might interfere with its movement.

If the problem persists after attempting these solutions, please contact Sweetcrispy customer support.

Specifications

Feature	Detail
Brand	Sweetcrispy
Model Number	ELTP40-BK
Product Dimensions (D x W x H)	24"D x 40"W x 48"H
Desktop Size	40 x 24 inches (spliced design)
Height Adjustment Range	28.7 inches to 46.5 inches
Maximum Weight Capacity	176 lbs (80 kg)
Lifting Mechanism	Electric
Noise Level	Less than 50 decibels (dB)
Material	Wood (desktop), Stainless Steel (base)
Color	Black
Included Components	Assembly Tools, Instruction Manual, Standing Desk

Warranty Information

The Sweetcrispy Electric Adjustable Height Standing Desk comes with a **Limited Warranty**. For specific details regarding warranty coverage, terms, and conditions, please refer to the warranty card included with your product or contact Sweetcrispy customer support.

Customer Support

For further assistance, technical support, or warranty claims, please refer to the contact information provided in your product packaging or visit the official Sweetcrispy website.
You can also find the comprehensive User Manual (PDF) here.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CZNJBDGF

More documents and user manuals: **https://manuals.plus/**