Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

METZ MQD7500Z

METZ MQD7500Z Smart TV User Manual

Model: MQD7500Z | 50" (126 cm) QLED 4K UHD Google TV

Important Safety Information

Please read all safety and operating instructions carefully before using this television. Keep these instructions for future reference. Adhere to all warnings on the appliance and in the operating instructions.

- **Power Source:** Operate this product only from the type of power source indicated on the marking label.
- **Ventilation:** Slots and openings in the cabinet are provided for ventilation. Do not block or cover these openings.
- **Water and Moisture:** Do not use this product near water, such as a bathtub, wash bowl, kitchen sink, or laundry tub.
- **Cleaning:** Unplug this product from the wall outlet before cleaning. Use a damp cloth for cleaning. Do not use liquid cleaners or aerosol cleaners.
- **Lightning:** For added protection during a lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet and disconnect the antenna or cable system.

Setup Guide

1. Unboxing and Assembly

Carefully remove the TV from its packaging. It is recommended that two people handle the TV to prevent damage. Ensure all components listed in the packing list are present.

Attaching the Stand:

1. Place the TV face down on a soft, flat surface (e.g., a blanket or foam) to prevent screen scratches.
2. Align the stand bases with the corresponding slots on the bottom of the TV.
3. Secure the stands using the provided screws. Ensure they are tightened firmly.

(Image Placeholder: Illustration of attaching the TV stand. Alt-text: "Diagram showing the process of attaching the two stand feet to the base of the METZ MQD7500Z Smart TV using screws." Description: This image would depict the

underside of the television with clear indications of where the stand components connect and how the screws are inserted to secure them.)

2. Initial Connections

Before plugging in the TV, connect all necessary external devices.

- **Power Cable:** Connect the power cable to the TV's power input and then to a wall outlet.
- **Antenna/Cable:** For terrestrial or cable TV, connect an RF coaxial cable to the "ANTENNA IN" port.
- **HDMI Devices:** Connect Blu-ray players, game consoles, or set-top boxes to the HDMI ports. This TV supports HDMI 2.0 for 4K content.
- **USB Devices:** For media playback or software updates, connect USB drives to the USB ports.
- **Network Connection:** For Smart TV features, connect an Ethernet cable to the LAN port or connect wirelessly via Wi-Fi during the initial setup.

(Image Placeholder: Rear view of the TV showing various input ports. Alt-text: "Rear panel of the METZ MQD7500Z Smart TV highlighting HDMI, USB, Antenna, and LAN ports." Description: This image would provide a clear view of the TV's back panel, labeling each input port (HDMI, USB, Antenna, LAN, Optical Audio Out) to guide users in connecting their devices correctly.)
(Video Placeholder: Official video demonstrating initial TV setup and connections. Alt-text: "Video tutorial on connecting power, antenna, and HDMI devices to a METZ Smart TV." Description: This video would visually guide users through the process of unboxing, attaching the stand, and connecting essential cables like power, antenna, and various HDMI devices to the television. Max width: 420px.)

3. First-Time Setup Wizard

Upon first power-on, the TV will guide you through the initial setup process.

1. **Language Selection:** Choose your preferred language.
2. **Network Setup:** Connect to your Wi-Fi network or confirm Ethernet connection.
3. **Google Account Sign-in:** Sign in with your Google account to access Google TV features, apps, and personalized recommendations.
4. **Channel Scan:** Perform an automatic channel scan for terrestrial or cable TV.
5. **Privacy Settings:** Review and adjust privacy settings as desired.

Operating Instructions

Remote Control Overview

Familiarize yourself with the functions of the supplied remote control.
(Image Placeholder: Layout of the METZ Smart TV remote control with labeled buttons. Alt-text: "Diagram of the METZ Smart TV remote control, showing buttons for power, volume, channel, navigation, Google Assistant, and app shortcuts." Description: This image would display the remote control, clearly labeling each button and its primary function, such as power, input, volume up/down, channel up/down, navigation pad, Google Assistant button, and dedicated app buttons.)

- **Power Button (●):** Turns the TV on or off.
- **Input Button (↳):** Selects input sources (HDMI 1, HDMI 2, TV, etc.).
- **Volume Up/Down (+/-):** Adjusts the sound level.

- **Channel Up/Down (CH+/-):** Changes TV channels.
- **Navigation Pad (▲ ▼ ◄ ►):** Navigates through menus and options.
- **OK Button:** Confirms selections.
- **Back Button:** Returns to the previous screen.
- **Home Button:** Accesses the Google TV home screen.
- **Google Assistant Button:** Activates voice control.
- **App Shortcut Buttons:** Direct access to popular streaming services.

Basic TV Functions

- **Turning On/Off:** Press the Power button on the remote or the TV.
- **Changing Channels:** Use CH+/- buttons or enter channel numbers directly.
- **Adjusting Volume:** Use VOL+/- buttons.
- **Selecting Input Source:** Press the Input button and select the desired source from the on-screen menu.

Google TV Features

Your METZ MQD7500Z Smart TV runs on Google TV, offering a personalized and intuitive entertainment experience.

- **Home Screen:** Provides access to your favorite apps, movies, shows, and personalized recommendations.
- **Apps:** Download and install apps from the Google Play Store.
- **Google Assistant:** Press the Google Assistant button on your remote and speak commands to search for content, control smart home devices, or get information.
- **Chromecast Built-in:** Cast content from your compatible smartphone, tablet, or computer directly to the TV.

(Video Placeholder: Official video demonstrating Google TV interface navigation and features. Alt-text: "Video guide to navigating the Google TV interface on a METZ Smart TV, including app access and voice commands." Description: This video would showcase the user interface of Google TV, demonstrating how to browse content, launch applications, use the Google Assistant for voice commands, and utilize the Chromecast built-in feature. Max width: 420px.)

Picture and Sound Settings

Access the settings menu to customize your viewing and listening experience.

- **Picture Modes:** Select from various preset modes (Standard, Vivid, Movie, Sport, Game) or customize settings like Brightness, Contrast, Color, and Sharpness.
- **Sound Modes:** Choose from preset sound modes (Standard, Music, Movie, Speech) or adjust Bass, Treble, and Balance.
- **Advanced Settings:** Explore options for HDR, motion smoothing, and digital audio output.

Maintenance

Cleaning Your TV

- **Screen:** Gently wipe the screen with a soft, lint-free cloth. For stubborn marks, slightly dampen the cloth with water or a specialized screen cleaner. Never spray cleaner directly onto the screen.

- **Cabinet:** Use a soft, dry cloth to wipe the TV cabinet. Avoid using abrasive cleaners or solvents.
- **Before Cleaning:** Always unplug the TV from the power outlet before cleaning.

Software Updates

Regularly check for and install software updates to ensure optimal performance and access to the latest features.

1. Go to *Settings* on the Google TV home screen.
2. Select *System* > *About* > *System update*.
3. Follow the on-screen prompts to check for and install any available updates.

TROUBLESHOOTING

If you encounter issues with your TV, refer to the following common solutions before contacting support.

Problem	Possible Cause	Solution
No Power	Power cable not connected; Wall outlet not working; Remote control batteries low.	Ensure power cable is securely connected. Test the outlet with another device. Replace remote control batteries.
No Picture, but Sound is Present	Incorrect input source selected; External device not powered on or connected properly.	Press the Input button on the remote and select the correct source. Check connections and power of external devices.
No Sound, but Picture is Present	Volume muted or too low; Incorrect audio output settings; External audio system issues.	Unmute volume or increase level. Check TV audio output settings. Verify external audio system connections and power.
Wi-Fi Connection Issues	Incorrect Wi-Fi password; Router issues; TV too far from router.	Re-enter Wi-Fi password. Restart your router and TV. Move TV closer to router or use an Ethernet cable.
Remote Control Not Responding	Low batteries; Obstruction between remote and TV; Remote not paired (for Bluetooth remotes).	Replace batteries. Remove obstructions. Re-pair the remote control if it's a Bluetooth model (refer to TV settings for pairing instructions).

If the problem persists after trying these solutions, please contact METZ customer support.

SPECIFICATIONS

Feature	Detail
Model Name	MQD7500Z

Feature	Detail
Display Size	50 inches (126 cm)
Display Technology	QLED
Resolution	4K UHD (3840 x 2160)
HDR Support	HDR 10
Operating System	Google TV
Connectivity	HDMI (multiple ports), USB (multiple ports), Ethernet (LAN), Wi-Fi, Bluetooth
Audio Output	Optical Digital Audio Out, HDMI ARC/eARC
Dimensions (W x H x D)	*(Specific dimensions not provided in input, placeholder)*Approx. 111.2 cm x 64.5 cm x 7.5 cm (without stand)
Weight	*(Specific weight not provided in input, placeholder)*Approx. 10.5 kg (without stand)
Power Consumption	*(Specific consumption not provided in input, placeholder)*Standard operation: 75W, Standby: <0.5W

Warranty and Support

METZ provides a limited warranty for this product. Please refer to the warranty card included in your product packaging for specific terms and conditions, including the warranty period and coverage details. Keep your proof of purchase for warranty claims.

Customer Support

For technical assistance, troubleshooting beyond this manual, or warranty inquiries, please contact METZ customer support through their official website or the contact information provided in your product documentation.
Online Resources: Visit the official METZ website for FAQs, software downloads, and additional support resources.
Contact Information: *(Specific contact details not provided in input, placeholder)*Refer to your product's quick start guide or the METZ official website for regional contact numbers and email addresses.

© 2024 METZ. All rights reserved. Google TV is a trademark of Google LLC.
This manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CZRX2CLC

More documents and user manuals: **https://manuals.plus/**