Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

briidea LD-119

briidea Wireless Dump Trailer Remote Control (Model LD-119) User Manual

Your guide to safe and efficient operation

1. Introduction

Thank you for choosing the briidea Wireless Dump Trailer Remote Control, Model LD-119. This device provides a convenient and efficient way to operate your dump trailer wirelessly, enhancing safety and flexibility. Please read this manual thoroughly before installation and operation to ensure proper use and to prevent damage.



Figure 1: briidea Wireless Dump Trailer Remote Control and its key features.

2. Product Features

- **Wireless Operation:** Eliminates the need for wired connections, offering greater freedom of movement and control.
- **Extended Control Range:** Operates effectively up to 100 feet (approximately 30 meters), allowing control from a safe distance.
- **High Compatibility:** Supports one-to-one control and can be configured for up to eight remote controls to operate a single receiver, facilitating collaborative work.
- **Memory Function:** Retains the last paired status even after power loss or low battery, ensuring quick reconnection.
- **Easy Installation:** Designed for quick setup with included tools.



Figure 2: Remote control dimensions (2.7 inches by 1.5 inches) and memory function indicator.

3. Package Contents

Please check the package for the following items:

- 1 x briidea Wireless Dump Trailer Remote Control
- 1 x Battery (may be pre-installed)
- 1 x Small Screwdriver

4. Setup and Installation

The remote control is designed for easy setup. Follow these steps to install or replace the battery:

1. Locate the small screw on the back cover of the remote control.
2. Use the provided screwdriver to carefully remove the screw.
3. Gently pry open the back cover to access the battery compartment.

4. Insert the battery, ensuring the correct polarity (+/-) as indicated inside the compartment.
5. Replace the back cover and secure it with the screw.

Note: The remote control typically comes with a battery pre-installed. This procedure is also for battery replacement.



Figure 3: Step-by-step guide for battery installation.

5. Operation

Once the remote control is powered and paired with your dump trailer's receiver (refer to your trailer's receiver manual for pairing instructions if needed), you can operate it as follows:

- **Up Arrow Button (▲):** Press and hold to raise the dump trailer bed.
- **Down Arrow Button (▼):** Press and hold to lower the dump trailer bed.
- **Square Button (■):** This typically acts as a stop or neutral button, releasing the other functions.

Ensure you are within the 100ft operating range for reliable control. Always maintain a clear line of sight to the trailer and

be aware of your surroundings.



Figure 4: Operating the remote control from a safe distance of up to 100 feet.

6. Compatibility and Multi-Remote Use

The briidea LD-119 remote control offers flexible compatibility:

- **One-to-One Control:** A single remote control operates a single trailer receiver.
- **Eight-to-One Control:** Up to eight remote controls can be paired and used simultaneously to control the same trailer receiver. This feature is ideal for situations requiring multiple operators or backup remotes. Refer to your trailer receiver's manual for specific instructions on pairing multiple remotes.



Figure 5: Illustration of single remote control versus multiple remote controls operating one trailer.

7. Maintenance

- **Battery Replacement:** Replace the battery when the remote's performance degrades or it stops responding. Refer to Section 4 for battery installation steps.
- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use abrasive cleaners or immerse it in water.
- **Storage:** Store the remote control in a dry place, away from extreme temperatures and direct sunlight, when not in use.

8. Troubleshooting

- **Remote not responding:**
    - Check the battery. Replace if necessary.

- Ensure you are within the 100ft operating range.
- Verify that the trailer's receiver is powered on and functioning correctly.
- Re-pair the remote with the receiver if connection issues persist (refer to your receiver's manual).

- **Intermittent control:**
  - Ensure there are no major obstructions between the remote and the receiver.
  - Check for sources of strong electromagnetic interference.
  - Battery may be low; replace it.

9. Specifications

Model Number	LD-119
Brand	briidea
Control Distance	Up to 100 ft (30 meters)
Dimensions (L x W)	2.7 x 1.5 inches (approximate)
Item Weight	1.44 ounces
Compatibility	Up to 8 remotes per receiver

10. Warranty and Support

For warranty information and technical support, please refer to the documentation provided with your purchase or visit the official briidea website. If you encounter any issues not covered in this manual, please contact briidea customer service for assistance.

© 2024 briidea. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D1CKFCNZ

More documents and user manuals: **https://manuals.plus/**