Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Skullcandy S2PAW-S749

Skullcandy Push ANC Active Wireless Earbuds User Manual

Model: S2PAW-S749

Introduction

The Skullcandy Push ANC Active Wireless Earbuds are designed for active users who demand high-quality audio and robust features. These earbuds offer a zero-compromise experience, combining comfortable ear hangers, fully waterproof construction, adjustable Stay-Aware Mode, and 4-Mic Active Noise Canceling to immerse you in your audio or keep you aware of your surroundings.
Key features include:

- Up to 58 hours of total battery life with the charging case, ensuring long listening sessions.
- IP67 rating for dust, sweat, and waterproof durability, making them suitable for any adventure.
- Adjustable Stay-Aware Mode to control how much of your environment you hear.
- Wireless charging capability for convenient power-ups, plus Rapid Charge for quick boosts.
- Customizable settings via the Skullcandy App for a personalized audio experience.



Image: Skullcandy Push ANC Active Earbuds shown with their charging case.

Setup

What's in the Box

Before you begin, ensure all components are present:

- Push® ANC Active True Wireless Earbuds
- Wireless Charging Case
- Ear Gels (S, M, L)
- USB-C Charging Cable
- Quick Start & User Guides

Initial Charge

It is recommended to fully charge your earbuds and charging case before first use. Place the earbuds into the charging case. Connect the USB-C charging cable to the case and a power source, or place the case on a wireless charging pad. The indicator lights on the case will show charging status.

Pairing with Your Device

To pair your Skullcandy Push ANC Active Earbuds:

1. Ensure the earbuds are charged and inside the charging case.
2. Open the charging case. The earbuds will automatically enter pairing mode.
3. On your device (smartphone, tablet, etc.), go to Bluetooth settings and turn Bluetooth on.
4. Select "Push ANC Active" from the list of available devices.
5. Once connected, you will hear an audio prompt, and the earbuds will be ready for use.

For Android devices, Google Fast Pair may automatically prompt you to connect when the case is opened near your device.



Image: Side view of the Skullcandy Push ANC Active Earbuds, highlighting the ear hanger design.

Operating Your Earbuds

Controls

The Skullcandy Push ANC Active Earbuds feature both physical buttons and touch controls for managing your audio and calls. Refer to the Quick Start Guide for detailed button functions.

Active Noise Canceling (ANC) and Stay-Aware Mode

These earbuds offer advanced noise control features:

- **Active Noise Canceling (ANC):** Reduces ambient noise for an immersive listening experience. Ideal for travel or noisy environments.
- **Adjustable Stay-Aware Mode:** Allows you to hear your surroundings while still enjoying your audio. This mode is adjustable, giving you control over the level of environmental sound you wish to let in.

Switching between ANC and Stay-Aware modes can typically be done via the earbuds' controls or through the Skullcandy App.

Skullcandy App Customization

Download the Skullcandy App to unlock full customization options for your earbuds. The app allows you to:

- Adjust equalizer settings to fine-tune your sound profile.
- Customize button functions for personalized control.
- Manage ANC and Stay-Aware Mode levels.
- Access user guides and firmware updates.



Image: A graphic illustrating key features of the Skullcandy Push ANC Active, including battery life, ANC, fit, waterproofing, Stay-Aware mode, and app customization.

Maintenance

Cleaning Your Earbuds

To ensure optimal performance and hygiene, regularly clean your earbuds. Use a soft, dry, lint-free cloth to wipe down the exterior. For the ear gels, you can gently remove them and clean with a mild soap and water solution, ensuring they are completely dry before reattaching.
Periodically clean the charging contacts on both the earbuds and inside the charging case to maintain reliable charging. A dry cotton swab can be used for this purpose.

Water and Dust Resistance

The Skullcandy Push ANC Active Earbuds are rated IP67, meaning they are dust, sweat, and waterproof. This rating allows for immersion in up to 1 meter of water for 30 minutes. While they are highly durable, it is recommended to dry them thoroughly after exposure to water or sweat before placing them back in the charging case to prevent damage to the charging contacts.

Troubleshooting

Problem	Possible Cause	Solution
Earbuds not pairing or connecting.	Low battery, out of range, or previous pairing issue.	Ensure earbuds are charged. Place them back in the case, close, then reopen to re-enter pairing mode. Forget the device in your phone's Bluetooth settings and re-pair.
Sound cutting in and out.	Interference, distance from device, or earbud placement.	Reduce distance between earbuds and device. Avoid areas with strong Wi-Fi or other wireless interference. Ensure a secure fit in your ears.
ANC/Stay-Aware mode not functioning as expected.	Incorrect mode selection or environmental factors.	Verify the correct mode is selected via controls or the Skullcandy App. Ensure earbuds are properly seated in your ears for optimal seal. Check for app updates.
Charging case not holding charge or earbuds not charging.	Dirty charging contacts, faulty cable/charger, or fully discharged case.	Clean charging contacts on earbuds and case. Try a different USB-C cable or power source. Ensure the case itself is charged.

If issues persist, consult the full user guide available through the Skullcandy App or contact Skullcandy customer support.

Specifications

Feature	Detail
Model Name	Push ANC Active
Model Number	S2PAW-S749
Connectivity Technology	Wireless, Bluetooth 5.3

Feature	Detail
Noise Control	Active Noise Cancellation
Battery Life	Up to 58 Hours (with charging case)
Water Resistance Level	IP67 (Dust, Sweat, and Waterproof)
Frequency Response	20Hz – 20KHz
Impedance	16 Ohm
Sensitivity	99 dB
Control Method	Touch, Voice, Physical Buttons
Material	Plastic
Item Weight	105 Grams / 3.7 ounces
Product Dimensions	5.98 x 4.13 x 1.81 inches
Included Components	Ear Gels (S, M, L), USB-C Charging Cable, Push® ANC Active True Wireless Earbuds, Quick Start & User Guides, Wireless Charging Case

Warranty and Support

Warranty Information

The Skullcandy Push ANC Active Wireless Earbuds come with a**Skullcandy 1-Year USA Limited Warranty**. Please retain your proof of purchase for warranty claims. For full details on warranty coverage and terms, refer to the official Skullcandy website or the included user guides.

Customer Support

For further assistance, technical support, or warranty claims, please visit the official Skullcandy support website or contact their customer service department. Contact information can typically be found in the Quick Start Guide or on the Skullcandy website.

© 2024 Skullcandy. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D23S3N5B

More documents and user manuals: **https://manuals.plus/**