Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

MERACH MR-E32

MERACH MR-E32 Under Desk Elliptical Exercise Machine User Manual

Model: MR-E32 | Brand: MERACH

Introduction

This manual provides essential information for the safe and effective operation of your MERACH MR-E32 Under Desk Elliptical Exercise Machine. Please read it thoroughly before initial use and retain it for future reference. The MR-E32 is designed to offer a low-impact leg exercise experience, suitable for various users including seniors and individuals undergoing rehabilitation.

Important Safety Information

To reduce the risk of serious injury, please observe the following safety precautions:

- Consult a physician before starting any new exercise program, especially if you have pre-existing medical conditions.
- Use the machine on a flat, stable surface.
- Ensure adequate space around the elliptical during use.
- Keep children and pets away from the machine during operation.
- Do not stand on the elliptical. It is designed for seated use only.
- Stop exercising immediately if you feel pain, dizziness, or nausea.
- Always ensure the power cord is securely connected and not a tripping hazard.
- Do not attempt to modify or repair the machine yourself. Contact customer support for assistance.
- Maximum user weight recommendation: 250 Pounds.

Package Contents

Verify that all items are present in the package:

- MERACH MR-E32 Under Desk Elliptical Exercise Machine x1
- Remote Control x1
- AAA Batteries x2 (for remote control)
- Power Cord x1
- PVC Anti-slip Pad x1

- Foot Straps x2
- Resistance Bands x2
- User Manual x1 (this document)



Image: The MERACH MR-E32 Under Desk Elliptical, shown with its remote control, power cord, anti-slip pad, foot straps, and resistance bands.



Image: A visual representation of the package contents, including the elliptical, remote, batteries, power cord, PVC pad, foot straps, and resistance bands.

Setup Instructions

1. **Placement:** Place the MERACH MR-E32 on a flat, stable surface. For optimal stability and to prevent movement during use, place the included PVC anti-slip pad underneath the elliptical.
2. **Power Connection:** Connect the power cord to the elliptical and then plug it into a standard electrical outlet.
3. **Remote Control Batteries:** Open the battery compartment on the remote control and insert the two AAA batteries, ensuring correct polarity.
4. **Foot Straps (Optional):** If desired, attach the foot straps to the pedals for added foot security during exercise. These are particularly useful for maintaining foot position during higher speeds or for users who prefer a more secure fit.
5. **Resistance Bands (Optional):** The resistance bands can be used for upper body exercises while seated. Attach them to the designated points on the elliptical if you plan to use them.



Image: A user demonstrating the elliptical placed under a desk, highlighting the use of the anti-slip pad and foot straps for stability and comfort.

Operating Instructions

Control Panel and Remote Control

The MERACH MR-E32 can be operated using either the integrated LED touch panel or the wireless remote control.



Image: Detailed view of the elliptical's control panel and the remote control, showing buttons for start/stop, mode, speed, and direction.



Image: A visual guide demonstrating the dual control options: remote control for convenience and direct button interaction on the device.

Powering On/Off

- Press the **POWER** button on the remote or the **START/STOP** button on the control panel to turn the machine on.
- Press and hold the **START/STOP** button to turn the machine off. The machine will also automatically power off after 15 minutes of continuous operation in Manual mode.

Workout Modes

The MR-E32 offers two primary workout modes:

- **Manual Mode (HR Mode):** Allows you to manually adjust the speed from levels 1 to 12. Use the **SPEED +/-** buttons on the remote or the **+/-** buttons on the control panel to change the speed.
- **Auto Mode (P1-P12):** Features 12 pre-programmed exercise routines that automatically adjust speed and intensity over a 15-minute cycle. Select an auto program using the **MODE** button.



Image: An overview of the elliptical's core features, including motion direction, workout modes, motor quality, and control options.

Direction of Motion

The pedals can move both forward and backward. Use the **DIRECTION** button on the remote or control panel to switch the direction of pedal rotation. This allows for targeting different muscle groups in the legs.



Image: A visual explanation of the elliptical's forward and reverse motion, indicating how each direction engages different leg and core muscles.

Digital Monitor Display

The integrated digital monitor displays various exercise metrics:

- **TIME:** Duration of your current exercise session.
- **DISTANCE:** Total distance covered (in meters).
- **SPEED:** Current speed level.
- **COUNT:** Number of pedal rotations.
- **CALORIES:** Estimated calories burned.
- **SCAN:** Cycles through all metrics automatically.

Note: Distance is displayed in meters. For conversion to miles, 1 meter is approximately 3.28 feet or 0.000621 miles.

Usage Guidelines

The MERACH MR-E32 is designed for versatile, low-impact exercise in various settings:

- **Under Desk Use:** Position the elliptical under your desk while working to incorporate physical activity into your routine. Ensure sufficient clearance for your knees.
- **Leisure Activities:** Use while watching television, reading, or relaxing on a sofa.
- **Rehabilitation:** Its low-impact motion is beneficial for leg rehabilitation, promoting blood circulation and muscle recovery.



Image: Examples of the elliptical being used in various environments, including under a desk, during leisure time, and for rehabilitation purposes.

The quiet motor (<15dB) ensures minimal disturbance to others, making it suitable for shared spaces.



Image: An illustration emphasizing the quiet operation of the elliptical, showing a user exercising discreetly in a shared living space.

Maintenance

- **Cleaning:** Wipe the machine with a soft, damp cloth after each use. Avoid abrasive cleaners or solvents.
- **Storage:** Store the elliptical in a cool, dry place away from direct sunlight and extreme temperatures.
- **Lubrication:** The MERACH MR-E32 is designed for smooth operation. If you notice any unusual noises or friction, contact customer support for guidance on lubrication. Do not apply lubricants unless instructed by customer service.
- **Inspection:** Periodically check all components for wear and tear. Ensure all connections are secure.

Troubleshooting

Problem	Possible Cause	Solution
Machine does not power on.	Power cord not connected; outlet not working; remote batteries dead.	Ensure power cord is securely plugged in. Test the outlet with another device. Replace remote control batteries.
Pedals are not moving smoothly.	Obstruction; internal issue.	Check for any obstructions around the pedals. If the issue persists, contact customer support.
Remote control is unresponsive.	Dead batteries; remote out of range; signal obstruction.	Replace remote batteries. Ensure remote is pointed towards the elliptical's sensor. Remove any objects blocking the signal.
Unusual noise during operation.	Loose component; internal friction.	Stop use and inspect for any loose parts. If the noise continues, contact customer support.

Specifications

Feature	Detail
Model Name	MR-E32

Feature	Detail
Brand	MERACH
Color	White
Product Dimensions (LxWxH)	17.9"D x 9.64"W x 15.43"H
Material	Alloy Steel
Resistance Mechanism	Magnetic
Maximum Weight Recommendation	250 Pounds
Number of Resistance Levels	12 (Manual Mode)
Workout Modes	12 Manual Speeds, 12 Auto Programs (P1-P12)
Noise Level	Less than 15dB
Power Consumption	Less than 1 kWh per day



Image: Visual representation of the elliptical's dimensions (17.9 inches deep, 9.6 inches wide, 15.4 inches high) and weight (15.43 lbs).



Image: An illustration of the internal motor mechanism, emphasizing its smooth, silent operation and low power consumption.

Warranty and Support

Your MERACH MR-E32 Under Desk Elliptical Exercise Machine comes with a**1-Year Manufacturer Warranty**.
For any questions, concerns, or technical support, please contact MERACH customer service. Have your order number and product model (MR-E32) ready when contacting support.

- **Customer Service:** Available via email or phone (refer to product packaging or MERACH official website for contact details).
- **Response Time:** 24-hour after-sales support is typically provided.

Additional Information

No official product videos were available for embedding based on the provided data.

© 2025 MERACH. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D3DYC5HQ

More documents and user manuals: **https://manuals.plus/**