Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Fujifilm X-T50

Fujifilm X-T50 Mirrorless Digital Camera User Manual

Model: X-T50

1. Overview

The Fujifilm X-T50 is a compact mirrorless digital camera designed for image makers seeking advanced features and portability. It incorporates a 40.2-megapixel X-Trans CMOS 5 HR sensor, offering high-resolution imaging. A dedicated Film Simulation dial provides quick access to Fujifilm's unique color profiles, including the new REALA ACE mode. The camera supports video recording up to 6.2K/30P and features up to 7.0 stops of in-body image stabilization for steady shots. Its advanced autofocus system utilizes Deep Learning AI for subject tracking, ensuring sharp results across various subjects. The X-T50 also includes native Frame.io Camera to Cloud connectivity for efficient workflow integration.

Key Features:

- Dedicated Film Simulation dial for quick access to 20 Film Simulations (including REALA ACE mode).
- 40.2-megapixel X-Trans CMOS 5 HR sensor for high-resolution images.
- Compatibility with all X Series lenses, featuring 1.4x and 2x Digital Teleconverter options.
- Video recording capabilities: 6.2K/30P, 4K/60P, FHD/240P, 4:2:2 10-Bit.
- Native Frame.io Camera to Cloud integration for seamless content sharing.
- Up to 7.0 stops of in-body image stabilization.

2. Setup

2.1. Inserting the Battery and Memory Card

Locate the battery and memory card compartment on the bottom of the camera. Open the cover, insert the battery with the correct orientation, and then insert a compatible SD card. Close the compartment cover securely.



Image: Bottom view of the Fujifilm X-T50 camera with the battery and memory card compartment open, showing the battery slot and SD card slot.

2.2. Attaching a Lens

Align the red dot on the lens with the red dot on the camera body's lens mount. Gently twist the lens clockwise until it clicks into place. Ensure the lens is securely attached before use.



Image: Front view of the Fujifilm X-T50 camera body, showcasing the lens mount without a lens attached.

2.3. Initial Charging

Connect the camera to a power source using the provided USB-C cable for initial battery charging. The charging indicator will show the charging status.

3. Operating the Camera

3.1. Power On/Off

To power on the camera, rotate the ON/OFF switch located on the top plate. To power off, rotate it back to the OFF position.



Image: Top view of the Fujifilm X-T50, highlighting the ON/OFF switch, shutter speed dial, exposure compensation dial, and Film Simulation dial.

3.2. Adjusting Settings with Dials

The camera features several physical dials for quick adjustments:

- **Shutter Speed Dial:** Adjusts the shutter speed.
- **Exposure Compensation Dial:** Modifies exposure levels.
- **Film Simulation Dial:** Selects from various film simulation modes (e.g., Standard, Vivid, Soft, Custom).

3.3. Using the Viewfinder and LCD Screen

The X-T50 is equipped with an electronic viewfinder (EVF) and a tilting LCD touchscreen monitor. The EVF provides a clear view of your scene, while the LCD screen can be tilted for easier viewing from different angles, useful for low-angle or high-angle shots.



Image: Rear view of the Fujifilm X-T50, displaying the LCD screen, electronic viewfinder, and control buttons.

3.4. Focus Mode Selector

The focus mode selector is located on the front of the camera, allowing you to switch between Manual (M), Continuous (C), and Single (S) autofocus modes.

3.5. Built-in Flash

To activate the built-in flash, press the lever located near the hot shoe. The flash will pop up, ready for use. Refer to the camera's menu for flash mode settings (Auto, On, Off, High-Speed Sync).

4. Maintenance

4.1. Cleaning the Camera

Use a soft, lint-free cloth to clean the camera body. For the lens and sensor, use specialized cleaning tools and

solutions to avoid damage. Never use harsh chemicals or abrasive materials.

4.2. Battery Care

To prolong battery life, avoid exposing it to extreme temperatures. Store the battery in a cool, dry place when not in use. Fully charge the battery before extended periods of storage.

5. Troubleshooting

5.1. Camera Not Powering On

Ensure the battery is fully charged and correctly inserted. Check if the ON/OFF switch is in the 'ON' position. If the issue persists, try using a different charged battery.

5.2. Image Quality Issues

Check lens cleanliness and ensure it is properly attached. Verify exposure settings (shutter speed, aperture, ISO) are appropriate for the lighting conditions. For blurry images, ensure image stabilization is active if shooting handheld.

5.3. Memory Card Errors

Ensure the memory card is correctly inserted and not locked. Try formatting the card (this will erase all data, so back up first). If errors persist, try a different compatible memory card.

6. Specifications

Feature	Detail
Model Name	X-T50
Sensor Type	40.2 MP X-Trans CMOS 5 HR
Image Stabilization	Sensor-shift (up to 7.0 stops)
Video Resolution	Up to 6.2K/30P, 4K/60P, FHD/240P
Display Type	Tilting LCD Touchscreen
Viewfinder	Electronic
Compatible Mountings	Fujifilm X
Connectivity	Bluetooth, Wi-Fi, USB-C, HDMI
Item Weight	438 Grams
Color	Charcoal Silver

7. What's in the Box

- Fujifilm X-T50 Camera Body

- Battery
- USB-C Cable
- Shoulder Strap

8. Warranty and Support

8.1. Manufacturer's Warranty

The Fujifilm X-T50 Mirrorless Digital Camera comes with a**1-year manufacturer's warranty**. Please retain your proof of purchase for warranty claims.

8.2. Customer Support

For technical assistance, troubleshooting, or service inquiries, please visit the official Fujifilm support website or contact their customer service department. Contact information can typically be found on the Fujifilm website or in the packaging materials.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D3X6N68G

More documents and user manuals: **https://manuals.plus/**