Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Minolta MNB10Z-BK

Minolta ProShot 64MP Digital Camera User Manual

Model: MNB10Z-BK | Brand: Minolta

Introduction

This manual provides comprehensive instructions for the Minolta ProShot 64MP Digital Camera (Model: MNB10Z-BK). It covers setup, operation, maintenance, and troubleshooting to help you maximize your camera's performance and capture high-quality photos and videos. Please read this manual thoroughly before using your camera.

What's in the Box

Upon unboxing your Minolta ProShot 64MP Digital Camera, verify that all the following components are included:

- Minolta ProShot 64MP Digital Camera Body
- 32GB SD Card
- USB Cable
- Rechargeable Lithium Battery (NP-120)
- Battery Charger
- Carrying Case
- User Manual (this document)



Image: All components included with the Minolta ProShot 64MP Digital Camera.

Setup

1. Charging the Battery

Before initial use, fully charge the provided lithium battery. Insert the battery into the charger, then connect the charger to a power outlet. The indicator light on the charger will show charging status and turn off or change color when fully charged.

2. Installing the Battery and SD Card

1. Locate the battery and SD card compartment on the camera.
2. Open the compartment cover.
3. Insert the fully charged battery, ensuring it clicks into place.
4. Insert the 32GB SD card into the designated slot until it locks. Ensure the card is inserted in the correct orientation.
5. Close the compartment cover securely.



Image: Minolta ProShot camera and its accessories, showing the battery and SD card.

Operating the Camera

Basic Controls

- **Power Button:** Located on the top of the camera. Press to turn the camera on or off.
- **Shutter Button:** Press halfway to focus, press fully to capture a photo.
- **Zoom Lever:** Adjusts the 10x optical zoom.
- **LCD Screen:** The 3.0-inch LCD screen is used for framing shots, reviewing images, and navigating menus.

Photography Modes and Features

64MP High-Resolution Photos

The camera's 64-megapixel CMOS sensor captures images with exceptional detail and clarity, suitable for large prints and extensive cropping. This mode is ideal for capturing landscapes, detailed portraits, and any scene where maximum image fidelity is desired.



Image: Example of 64MP detail, highlighting clarity.

10x Optical Zoom and Macro Shooting

Utilize the 10x optical zoom to bring distant subjects closer without compromising image quality. For extreme close-ups, switch to macro mode to capture intricate details of small objects like flowers or insects.



Image: Demonstrating 10x optical zoom capability.

4K Ultra HD Video Recording

Record smooth, cinematic 4K Ultra HD videos at 60 frames per second. This high-resolution video capability is suitable for vlogging, capturing events, or documenting travel.

Burst Mode

Capture fast-moving action sequences with burst mode, which takes multiple photos in rapid succession. This feature is ideal for sports, wildlife, or capturing fleeting moments.



Image: Burst mode capturing a sequence of movement.

Anti-Shake Stabilization

The camera features digital and optical anti-shake stabilization to minimize blur caused by camera movement, ensuring sharp images even in challenging conditions or when shooting handheld.



Image: Anti-shake technology comparison.

Smart Features and Scene Modes

The camera includes intelligent auto mode, face detection, and various scene selection modes (e.g., Night, Portrait, Macro) to optimize settings for different shooting scenarios, simplifying the photography process.

Time-Lapse Video

Create captivating time-lapse videos by capturing a series of still images over an extended period and then playing them back as a sped-up video. Ideal for capturing sunsets, cloud movements, or urban activity.



Image: Examples of various scene modes.

Wi-Fi Connectivity

Connect your camera to a smartphone via Wi-Fi to transfer photos and videos wirelessly or to control the camera remotely using a dedicated application. Refer to the camera's on-screen menu for Wi-Fi setup instructions.



Image: Wi-Fi connectivity for photo transfer.

Maintenance

- **Cleaning the Camera Body:** Use a soft, dry cloth to wipe the camera body. For stubborn dirt, slightly dampen the cloth with water. Avoid harsh chemicals.
- **Cleaning the Lens:** Use a lens brush or a blower to remove dust. For smudges, use a specialized lens cleaning solution and a microfiber cloth. Do not touch the lens surface with your fingers.
- **Battery Care:** Store the battery in a cool, dry place when not in use. Avoid fully discharging the battery frequently to prolong its lifespan.
- **Storage:** When storing the camera for extended periods, remove the battery and SD card. Store the camera in its carrying case in a dry, dust-free environment.

Troubleshooting

Problem	Possible Cause	Solution
Photos are blurry.	Insufficient light, camera shake, incorrect focus, or subject movement.	Ensure adequate lighting. Activate anti-shake stabilization. Use autofocus correctly. For moving subjects, use burst mode or a faster shutter speed.
Short battery life.	Frequent use of LCD screen, Wi-Fi, or video recording. Battery degradation.	Reduce LCD brightness. Turn off Wi-Fi when not in use. Carry a spare charged battery. Replace old batteries if necessary.
Cannot transfer files via Wi-Fi.	Incorrect Wi-Fi settings, app issues, or distance from device.	Ensure camera Wi-Fi is enabled and correctly connected to your smartphone. Restart both devices. Check the camera's Wi-Fi setup guide. Ensure the companion app is updated.
SD card error.	Card not inserted correctly, corrupted card, or incompatible card.	Reinsert the SD card. Try formatting the card (this will erase all data). Use a compatible SD card (32GB max, Class 10/UHS-I recommended).

Specifications

Feature	Detail
Model Name	ProShot
Model Number	MNB10Z-BK
UPC	084438962895
Photo Sensor Resolution	64 MP
Video Resolution	4K Ultra HD (4320p) at 60 FPS
Optical Zoom	10x
Image Stabilization	Digital, Optical
Screen Size	3 Inches (LCD)
Connectivity	Wi-Fi
Supported File Format	JPEG (Photos)
Memory Storage Capacity	32 GB (SD Card included)
Battery Type	Lithium Ion (NP-120)
Item Weight	2.5 Pounds
Dimensions (Height)	5.3 inches
Flash Modes	Auto, Macro (No built-in flash)
Continuous Shooting	10 fps
Focus Type	Auto Focus (Contrast Detection, Multi area, sensor)

Feature	Detail
Warranty	1 year manufacturer

Warranty and Support

Manufacturer's Warranty

The Minolta ProShot 64MP Digital Camera comes with a **1-year manufacturer's warranty**. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims.

Protection Plans

Extended protection plans may be available for purchase separately to provide additional coverage beyond the standard manufacturer's warranty. These plans typically offer:

- 2-Year Protection Plan
- 3-Year Protection Plan

For details on purchasing or activating these plans, please refer to the retailer's information at the time of purchase.

Customer Support

For further assistance, technical support, or warranty inquiries, please visit the official Minolta support website or contact their customer service department. Contact information can typically be found on the Minolta brand website or within the product packaging.
You can also visit the Minolta Store on Amazon for product information and updates.

© 2025 Minolta. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D523M57B

More documents and user manuals: **https://manuals.plus/**