Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Eureka NEW430BL

Eureka Rapidwash NEW430 Cordless Vacuum Cleaner and Mop

Model: NEW430BL

Introduction

The Eureka Rapidwash NEW430 is a revolutionary cordless vacuum cleaner and mop designed to simplify the cleaning of hard floors and pet hair. With a powerful 15000 Pa suction and a 30-minute cleaning autonomy, it offers complete freedom of movement. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance.

Important Safety Information

Please read all safety warnings and instructions before using this appliance. Failure to follow the warnings and instructions may result in electric shock, fire, and/or serious injury.

- Do not use outdoors or on wet surfaces.
- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not use with damaged cord or plug. If appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.
- Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Do not run appliance over cord. Keep cord away from heated surfaces.
- Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- Do not handle plug or appliance with wet hands.
- Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce air flow.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Turn off all controls before unplugging.
- Use extra care when cleaning on stairs.
- Do not use to pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Use only Eureka cleaning solution designed for this appliance.

- Do not immerse the appliance in water or other liquids.

Package Contents

Please check the box contents carefully to ensure all items are present and in good condition.

- Main Unit (Cordless Vacuum Cleaner and Mop)
- Accessory Holder
- Roller Brush
- Cleaning Solution
- Charging Base
- Filter Set (with 2 sponges)
- User Manual



Image: The Eureka Rapidwash NEW430 main unit, along with its charging base, cleaning solution bottle, cleaning brush, and spare filter sponge.

Setup

1. Assembly

1. Carefully remove all components from the packaging.
2. Attach the handle to the main unit until it clicks into place.
3. Ensure the clean water tank and dirty water tank are correctly seated.

2. Charging the Battery

- Place the charging base on a flat, stable surface near a power outlet.
- Connect the power adapter to the charging base and plug it into the outlet.
- Place the main unit onto the charging base. The indicator lights will show the charging status. Allow for a full charge before first use (approximately 4-5 hours).

3. Filling the Clean Water Tank

- Remove the clean water tank (800 ml capacity) from the main unit.
- Open the tank cap and fill with clean water up to the MAX line. For enhanced cleaning and odor neutralization, add the recommended amount of Eureka cleaning solution.
- Securely close the cap and reinsert the tank into the main unit.



Image: The Eureka Rapidwash NEW430 showing the separate clean water tank (800ml) and dirty water tank (450ml) for hygienic cleaning.

Operating Instructions

Powering On and Mode Selection

- Press the power button to turn on the appliance. The LED display will illuminate.
- Use the mode selection button to cycle through the available cleaning modes:
  - **Turbo Mode:** For heavy-duty cleaning and stubborn messes.
  - **Eco Mode:** For light cleaning and extended battery life.
  - **Dry Mode:** Collects dirty water without dispensing clean water, ideal for spills or drying floors.

Image: The Eureka Rapidwash NEW430 demonstrating its three cleaning modes: Turbo for intense cleaning, Eco for everyday use, and Dry for spills or drying.

Cleaning Operation

- The appliance features self-propulsion, making it easy to maneuver across floors.
- Its lightweight design (3.7 kg) and flexible swivel head allow for effortless cleaning in tight spaces and around furniture.
- The "edge-to-edge" roller brush design ensures thorough cleaning along walls and baseboards.
- The anti-tangle technology prevents hair and pet fur from wrapping around the brush, ensuring continuous and effective cleaning.



Image: The Eureka Rapidwash NEW430 demonstrating its innovative edge cleaning capability, reaching close to walls and corners.



Image: A close-up of the Eureka Rapidwash NEW430's powerbrush, highlighting its anti-tangle features designed to prevent hair and pet fur from wrapping around the roller.

Smart Features

- The appliance provides voice navigation and LED display for intuitive use, indicating battery level and selected mode.
- Intelligent technology automatically alerts you when the dirty water tank is full, preventing overflows and contamination.
- The unit automatically stops operating if left in an upright position during cleaning, enhancing safety and efficiency.

Maintenance

1. Self-Cleaning Function

- After each use, place the appliance on its charging base.

- Press and hold the self-cleaning button for 3 seconds to activate the automatic cleaning cycle.
- The system will rinse the roller brush with clean water and evacuate dirty water, ensuring a thorough clean of the brush.



Image: A detailed view of the Eureka Rapidwash NEW430's active brush cleaning system, showing how water and debris are scraped and expelled to keep the roller clean.

2. Automatic Drying

- After the self-cleaning cycle, the appliance will initiate an automatic drying process for the roller brush. This hands-free drying ensures hygiene and prevents odors.



Image: The Eureka Rapidwash NEW430's automatic drying function in action, ensuring the roller brush is hygienically dried after cleaning.

3. Emptying and Cleaning the Dirty Water Tank

- Regularly empty the dirty water tank (450 ml capacity) after each use to prevent odors and maintain hygiene.
- Rinse the tank thoroughly with clean water.

4. Filter Maintenance

- Periodically remove and clean the filter (sponges) to ensure optimal suction performance. Rinse with water and allow to air dry completely before reinserting.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Appliance does not turn on.	Battery is not charged; Power button not pressed correctly.	Ensure battery is fully charged; Press the power button firmly.
Poor suction or cleaning performance.	Dirty water tank is full; Roller brush is tangled or dirty; Filter is clogged; Clean water tank is empty.	Empty and clean the dirty water tank; Clean the roller brush and remove any tangles; Clean or replace the filter; Refill the clean water tank.
Water leakage.	Water tanks not properly installed; Tank caps not securely closed.	Ensure both clean and dirty water tanks are correctly seated and their caps are tightly closed.
Appliance stops unexpectedly.	Dirty water tank is full; Appliance is left upright during operation.	Empty the dirty water tank; Resume operation by tilting the appliance.

Specifications

Feature	Detail
Brand	Eureka
Model Number	NEW430BL
Color	Black and Grey
Dimensions (Package)	54.7 x 41.4 x 32.7 cm
Weight	3.7 Kilograms
Power	150 Watts
Voltage	3.6 Volts
Noise Level	80 dB
Runtime	Up to 25 minutes (up to 30 minutes based on Eureka Lab tests)
Clean Water Tank Capacity	800 ml
Dirty Water Tank Capacity	450 ml
Special Features	Portable, Lightweight, Cordless, Wet/Dry, Self-Propelled, Edge Cleaning, Anti-Tangle, Voice Navigation, Auto-Cleaning, Auto-Drying
Recommended Surface	Hard Floors, Parquet, Marble, Upholstery



Image: The Eureka Rapidwash NEW430 highlighting its extended battery life, providing up to 30 minutes of continuous cleaning.

Warranty and Support

Eureka stands by the quality of its products. For warranty information and customer support, please refer to the official Eureka website or contact their customer service department. Keep your purchase receipt as proof of purchase.
For further assistance, visit the Eureka official website or contact their support team.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D537KTKN

More documents and user manuals: **https://manuals.plus/**