Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Melnor 65139AMZ

Melnor AquaTimer Digital Hose Timer

Model: 65139AMZ

Brand: Melnor

Product Overview

The Melnor AquaTimer Digital Hose Timer automates watering for two separate areas of your yard. This programmable timer allows you to set precise watering schedules, including duration and frequency, for different zones. It features a manual watering option for immediate needs and a rain delay function to conserve water during wet weather. The included Quick Connect set simplifies hose and accessory connections, making your watering routine effortless.



Image: The Melnor AquaTimer Digital Hose Timer, showcasing its two outlets and the included Quick Connect accessories.

Key Features

- **Two Independent Zones:** Allows separate watering schedules for different areas.
- **Flexible Scheduling:** Water as often as every hour (up to 24 times a day) or as little as once a week per valve.
- **Rain Delay:** Pause watering for up to 7 days to avoid overwatering during rain.
- **Manual Watering Option:** Easily activate water flow for immediate needs.
- **Quick Connect Bundle:** Facilitates easy attachment and detachment of hoses and accessories.
- **Clear Digital Display:** Easy-to-read screen for programming and monitoring.
- **Durable Construction:** Designed for outdoor use.

Setup Guide

1. Battery Installation

The Melnor AquaTimer requires 2 x AA batteries (not included). Locate the battery compartment on the back of the unit, open it, insert the batteries according to the polarity indicators, and securely close the compartment.

2. Attaching to Faucet

Screw the timer onto your outdoor faucet. Ensure a snug fit to prevent leaks. It is recommended to turn on the faucet very slowly after installation to avoid damaging the timer.



Image: The Melnor AquaTimer securely attached to a garden faucet, ready for use.



Image: A detailed view of the Melnor AquaTimer highlighting its filter washer, large LCD screen, and easy-touch buttons for scheduling.

3. Connecting Hoses with Quick Connect

The included Quick Connect set allows for easy attachment of hoses, nozzles, and sprinklers. Attach the Quick Connect adapter to your hose and the Quick Connect end connector to the timer's outlets. This enables quick snap-on and snap-off connections.



Image: An illustration demonstrating the simple snap-on, snap-off mechanism of the Quick Connect system.

4. Setting the Clock

Rotate the dial to 'SET CLOCK'. Use the arrow buttons to adjust the current time (AM/PM) and press the center button to confirm. This sets the internal clock for accurate scheduling.

▶ **Watch video online**
Melnor AquaTimer Digital Water Timer

Video: A demonstration of setting the clock and programming watering schedules on the Melnor AquaTimer.

Operating Instructions

1. Programming Watering Schedules

The timer allows you to set three main parameters for each zone: 'START WATER', 'HOW LONG', and 'HOW OFTEN'.

- **START WATER:** Rotate the dial to 'START WATER'. Use the arrow buttons to select the desired start time for watering.
- **HOW LONG:** Rotate the dial to 'HOW LONG'. Use the arrow buttons to set the duration of each watering cycle (e.g., 5 minutes, 30 minutes).
- **HOW OFTEN:** Rotate the dial to 'HOW OFTEN'. Use the arrow buttons to specify the frequency of watering (e.g., every 12 hours, every 2 days, once a week).

After setting your desired schedule, rotate the dial to 'AUTO' to activate the programmed watering. The timer will display the next scheduled start time.

2. Manual Watering

To manually water, press the 'MANUAL ON/OFF' button. The display will show options for manual watering duration. Use the arrow buttons to select the desired time and press the center button to start. To stop manual watering, press 'MANUAL ON/OFF' again.

3. Rain Delay Feature

If rain is expected or has occurred, you can pause your watering schedule. While in 'AUTO' mode, press and hold the 'RAIN DELAY' button (usually the center button) to activate the rain delay. Use the arrow buttons to select the number of days you wish to delay watering (up to 7 days). The timer will automatically resume its programmed schedule after the delay period.

Maintenance

1. Cleanable Filter Washer

The timer is equipped with a cleanable filter washer at the inlet connection. Regularly check and clean this filter to prevent clogs and ensure smooth operation. Remove the timer from the faucet, unscrew the inlet connection, and rinse the filter under running water to remove any debris.

▶ **Watch video online**
Melnor AquaTimer Digital Water Timer

Video: This video demonstrates the cleanable filter washer, which helps prevent clogs and ensures the timer runs smoothly.

2. Winterization

To prevent damage from freezing temperatures, it is crucial to remove the timer from the faucet before the first frost. Store the timer indoors in a dry, protected area. It is also recommended to remove the batteries during storage to prevent corrosion.

Troubleshooting

- **Timer not watering:** Check battery levels. Ensure the faucet is fully open. Verify that the timer is in 'AUTO' mode and a schedule is set.
- **Leaking from connections:** Ensure all connections are tight. Check the rubber washers for proper seating and damage. Replace washers if necessary.
- **Incorrect watering times:** Re-check the 'SET CLOCK' time. Review your 'START WATER', 'HOW LONG', and 'HOW OFTEN' settings for each zone.
- **Manual mode not working:** Ensure the timer is not in 'OFF' mode. Re-attempt activating manual mode by pressing the

'MANUAL ON/OFF' button.

Specifications

Model Number	65139AMZ
Brand	Melnor
Color	Black, Yellow
Material	Plastic
Product Dimensions	5.19"D x 2.44"W x 5.11"H
Item Weight	0.53 Pounds (8.5 ounces)
Number of Settings	2 (Zones)
UPC	042206651396
Country of Origin	Taiwan

Warranty & Support

The Melnor AquaTimer Digital Hose Timer is backed by a Melnor 7 Year Limited Warranty. For additional information, assistance, replacements, troubleshooting, or any questions/concerns, please contact Melnor Customer Care.



Image: Information regarding Melnor's 7-year limited warranty and how to contact customer care for support.

© 2025 Melnor. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D54HLN6Y

More documents and user manuals: **https://manuals.plus/**