Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Complete Cuisine CC-TST2000

Complete Cuisine CC-TST2000 Compact 2-Slice Toaster User Manual

Model: CC-TST2000 | Brand: Complete Cuisine

1. Introduction and Overview

Thank you for choosing the Complete Cuisine CC-TST2000 Compact 2-Slice Toaster. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read all instructions carefully before use and retain this manual for future reference.

This compact 2-slice toaster is designed for efficient and consistent toasting of bread, bagels, waffles, and toaster pastries. It features a durable stainless-steel exterior, variable browning control with 7 settings, and a convenient mid-cancel function.



This image shows the Complete Cuisine CC-TST2000 Compact 2-Slice Toaster from a front-side angle. The toaster features a sleek black and stainless steel design, with two slots visible at the top, each containing a slice of bread being toasted. The browning control dial and lever are visible on the side.

2. Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed, including the following:

- Read all instructions before operating the toaster.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or toaster in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.

- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Do not use appliance for other than intended use.
- Oversize foods, metal foil packages, or utensils must not be inserted in a toaster as they may create a fire or risk of electric shock.
- A fire may occur if toasters are covered or touching flammable material, including curtains, draperies, walls, and the like, when in operation.
- Do not attempt to dislodge food when toaster is plugged in.
- Always unplug the toaster after use.
- Do not operate unattended.

3. Product Features

The Complete Cuisine CC-TST2000 Toaster is designed with user convenience and optimal toasting performance in mind. Key features include:

- **2-Slice Capacity:** Accommodates two slices of bread, bagels, or waffles.
- **7-Setting Variable Browning Control:** Allows precise adjustment of toast shade from light to dark.
- **Mid-Cancel Function:** Stop the toasting cycle at any time by pressing the cancel button.
- **Hinged Crumb Tray:** For easy and convenient cleaning of accumulated crumbs.
- **Durable Stainless Steel Exterior:** Provides a sleek, modern look and is easy to wipe clean.
- **750W Power:** Ensures efficient and consistent toasting performance.



This image provides a side view of the Complete Cuisine toaster, focusing on the control panel. It highlights the sleek, modern design and the durable stainless steel material. The browning control dial, offering 7 settings, and the toast lever are clearly visible.



A graphic illustrating key features of the Complete Cuisine toaster. These include 7 browning settings for precise control, a mid-cancel function to stop toasting at any time, a convenient hinged crumb tray for easy cleaning, and a durable, easy-to-wipe stainless steel exterior.

4. Setup

1. **Unpack:** Carefully remove the toaster and all packaging materials from the box. Dispose of packaging responsibly.
2. **Placement:** Place the toaster on a stable, flat, heat-resistant surface, away from flammable materials such as curtains or walls. Ensure there is adequate ventilation around the toaster.
3. **First Use:** Before first use, operate the toaster without bread on the highest browning setting (7) in a well-ventilated area. This will burn off any manufacturing residues and eliminate initial odors. It is normal for a slight smell or smoke to occur during this process.

5. Operating Instructions

1. **Plug In:** Insert the power plug into a standard AC120V/50Hz electrical outlet.

2. **Insert Bread:** Place one slice of bread, bagel, or waffle into each toasting slot. Ensure the items are not too thick or large to fit comfortably without jamming.
3. **Select Browning Level:** Turn the browning control dial to your desired setting, from 1 (lightest) to 7 (darkest). Start with a medium setting (e.g., 3 or 4) and adjust as needed for future use.
4. **Lower Lever:** Press the toast lever down until it locks into place. The toasting cycle will begin, and the indicator light (if present) will illuminate.
5. **Toasting Complete:** Once the selected browning level is reached, the toast will automatically pop up, and the toaster will turn off.
6. **Cancel Function:** To stop the toasting cycle at any time, press the 'STOP' or 'CANCEL' button. The toast will pop up immediately.

6. Maintenance and Cleaning

Regular cleaning will help maintain the performance and appearance of your toaster.

1. **Unplug and Cool:** Always unplug the toaster from the power outlet and allow it to cool completely before cleaning.
2. **Empty Crumb Tray:** Locate the hinged crumb tray at the bottom of the toaster. Open the tray and slide out to remove accumulated crumbs. Discard crumbs and wipe the tray clean with a damp cloth. Ensure the tray is fully reinserted and closed before next use.
3. **Clean Exterior:** Wipe the exterior of the toaster with a soft, damp cloth. For stubborn stains, a mild detergent can be used, but ensure no liquid enters the toaster slots. Do not use abrasive cleaners, scouring pads, or harsh chemicals, as these can damage the finish.
4. **Storage:** When not in use, store the toaster in a clean, dry place.

7. Troubleshooting

If you encounter issues with your toaster, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Toaster does not turn on.	Not plugged in; power outlet issue; circuit breaker tripped.	Ensure the toaster is securely plugged into a working outlet. Check your household circuit breaker.
Toast is too light or too dark.	Browning setting is incorrect.	Adjust the browning control dial to a higher setting for darker toast or a lower setting for lighter toast.
Toast lever does not stay down.	Toaster is not plugged in; internal mechanism issue; bread jammed.	Ensure the toaster is plugged in. If plugged in and still not working, check for any jammed bread or crumbs preventing the lever from locking. If the issue persists, contact customer support.
Smoke or burning smell.	Crumbs accumulated in the toaster; food jammed; first use burn-off.	Unplug the toaster and allow it to cool. Clean the crumb tray thoroughly. If food is jammed, carefully remove it after unplugging. If it's the first use, this is normal.
Uneven toasting.	Uneven bread thickness; internal element issue.	Ensure bread slices are of uniform thickness. If the problem persists, contact customer support.

8. Specifications

Technical specifications for the Complete Cuisine CC-TST2000 Compact 2-Slice Toaster:



A close-up view of the Complete Cuisine 2-Slice Toaster, emphasizing its compact size. Text overlays indicate it is a '2-Slice Toaster' suitable for various bread types, waffles, and bagels, along with illustrative dimensions.

Brand: Complete Cuisine

Model: CC-TST2000

Color: Black

Material: Stainless Steel

Product Dimensions (D x W x H): 11" x 11.25" x 7.5"

Specific Uses: Bagel, Bread, Waffle

Wattage: 750 watts

Number of Slices: 2

Special Features: Cancel Function, Variable Browning Control

Style: Retro

Voltage: 120 Volts (AC)

Number of Browning Settings: 7

UPC: 079902182770

Manufacturer: Complete Cuisine

9. Warranty and Support

For warranty information or technical support, please contact Complete Cuisine customer service. Keep your purchase receipt as proof of purchase for any warranty claims.

For further assistance, please visit the official Complete Cuisine website or contact their customer support line.

© 2024 Complete Cuisine. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D5J47D2S

More documents and user manuals: **https://manuals.plus/**