Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Braun BRHD225SDE

Braun Hair Dryer HD2.2 (Model BRHD225SDE) Instruction Manual

Your guide to operating and maintaining your Braun Hair Dryer.

Important Safety Information

Please read all instructions carefully before using this appliance to ensure safe and effective operation. Keep this manual for future reference.

- Do not use this appliance near water, such as in bathtubs, showers, or other vessels containing water.
- Always unplug the appliance immediately after use.
- Do not use the appliance with wet hands.
- Do not block the air inlet or outlet during operation.
- If the power cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons to avoid a hazard.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Clean the air filter regularly to prevent overheating.

Product Overview

The Braun Hair Dryer HD2.2 (Model BRHD225SDE) is a 2200W ionic hair dryer designed for efficient drying and styling. It features IONTEC technology to reduce frizz and enhance shine, multiple heat and speed settings, and includes two attachments for versatile use.



Image: The Braun Hair Dryer HD2.2, its packaging, a drying nozzle, and a curl diffuser.

Components:

- Hair Dryer Unit
- Drying Nozzle (Concentrator)
- Curl Diffuser
- Power Cord

Setup

1. **Unpacking:** Carefully remove all components from the packaging. Retain packaging for storage or future transport.
2. **Attachment Installation:**
   - To attach the drying nozzle or curl diffuser, align the attachment with the front of the hair dryer and push it firmly into place until it clicks.
   - To remove, gently pull the attachment off. Ensure the appliance is cool before attaching or removing.
3. **Power Connection:** Plug the power cord into a suitable electrical outlet. Ensure the voltage matches the

specifications of the appliance.



Image: A close-up view demonstrating how to attach the drying nozzle to the hair dryer.

Operating Instructions

Controls:



Image: A detailed view of the control buttons on the handle of the hair dryer, showing settings for heat, speed, and cool shot.

- **Power/Speed Switch:** Located on the handle.
  - 0: Off
  - I: Low Speed
  - II: High Speed
- **Heat Settings:** Located on the handle.
  - 1: Low Heat
  - 2: Medium Heat
  - 3: High Heat
- **Cool Shot Button:** Press and hold for a burst of cool air to set your style.

Drying and Styling:

1. **Preparation:** Towel-dry your hair to remove excess water.

2. **Power On:** Plug in the dryer and select your desired speed and heat settings.
3. **General Drying:** For fast drying, use the high speed and high heat settings. Move the dryer continuously to prevent overheating any single section of hair.
4. **Using the Drying Nozzle:** Attach the drying nozzle for concentrated airflow, ideal for precise styling or smoothing sections of hair. Direct the airflow downwards along the hair shaft.
5. **Using the Curl Diffuser:** Attach the curl diffuser for gentle drying of curly or wavy hair. Place sections of hair into the diffuser bowl and lift towards the scalp. Use low speed and medium heat to define curls and reduce frizz.
6. **Setting the Style:** Once hair is dry, press the cool shot button to blast cool air over your hair. This helps to close the hair cuticles, locking in your style and adding shine.
7. **Power Off:** Switch the power/speed switch to '0' (off) and unplug the appliance after use.



Image: A woman using the Braun Hair Dryer with the curl diffuser attachment to dry her curly hair.



Image: A man using the Braun Hair Dryer with the drying nozzle attachment to style his short hair.



Image: A woman using the Braun Hair Dryer with the drying nozzle attachment to dry her long hair.

Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the lifespan of your hair dryer.

1. **Unplug:** Always unplug the hair dryer from the power outlet and allow it to cool completely before cleaning.
2. **Exterior Cleaning:** Wipe the exterior of the hair dryer with a soft, damp cloth. Do not use abrasive cleaners or solvents.
3. **Air Filter Cleaning:**
    - The rear air inlet grille can accumulate dust and lint. Regularly check and clean this filter.
    - Gently twist or pull off the rear grille (refer to product design for specific removal method).
    - Use a soft brush or a dry cloth to remove any accumulated dust or hair from the filter mesh.
    - Reattach the grille securely.
4. **Storage:** Store the hair dryer in a dry place, away from moisture. The cord can be wrapped around the handle for

compact storage.



Image: The Braun Hair Dryer with its power cord neatly wrapped around the handle for storage.

Troubleshooting

Problem	Possible Cause	Solution
Hair dryer does not turn on.	Not plugged in; power outlet malfunction; internal fault.	Ensure the plug is securely inserted. Test the outlet with another appliance. If still not working, contact customer support.
Airflow is weak or inconsistent.	Blocked air inlet filter.	Unplug the dryer and clean the air inlet filter as described in the Maintenance section.
Hair dryer overheats and shuts off.	Blocked air inlet/outlet; prolonged use on high heat.	Unplug and allow to cool for several minutes. Clean the air inlet filter. Ensure air outlets are not blocked during use. Reduce heat setting if used for extended periods.
Unusual noise during operation.	Debris in the fan; internal component issue.	Unplug the dryer. Check the air inlet for any visible debris and carefully remove it. If the noise persists, discontinue use and contact customer support.

Specifications

Brand	Braun
Model Name	HD2.2
Item Model Number	BRHD225SDE
Wattage	2200 watts
Power Source	Plug-in Electric
Number of Speeds	3
Heat Modes	3
Special Features	Ionic Technology, Cool Shot, Lightweight
Included Components	Drying Nozzle, Curl Diffuser
Product Dimensions	10 x 23.2 x 28.2 cm
Item Weight	1.14 kg
Color	Black
Material	Plastic

Warranty and Support

For warranty information, please refer to the warranty card included with your product or visit the official Braun website. Keep your proof of purchase for warranty claims.

For technical support, spare parts, or service, please contact Braun customer service in your region. Contact details can typically be found on the Braun website or in the product packaging.

Online Resources: www.braun.com

© 2024 Braun. All rights reserved. Model BRHD225SDE.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D5JP9JZM

More documents and user manuals: **https://manuals.plus/**