Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Nkove 5M-SMII-OI19

NKOVE Digital Kitchen Timer User Manual

Model: 5M-SMII-OI19

Brand: Nkove

1. Introduction

Thank you for choosing the NKOVE Digital Kitchen Timer. This versatile device is designed to assist you with various timing needs in your kitchen and beyond. It features a clear digital display, multiple operating modes including a 24-hour clock, countdown/count-up timer, and an alarm function. This manual provides detailed instructions to help you get the most out of your new timer.



Figure 1: Front view of the NKOVE Digital Kitchen Timer.

2. Product Features

- **Multifunctionality:** Operates as a TIMER, CLOCK, and ALARM.
- **Silent & Alarm Mode:** Features a silent mode with a signaling light for quiet environments and an audible alarm mode.
- **Count-Up/Count-Down:** Supports both counting up from zero and counting down from a set time (up to 24 hours).
- **Memory Function:** Remembers the last set countdown time for convenience.
- **Fast Forward Function:** Allows for quick adjustment of time settings.
- **Versatile Placement:** Equipped with a magnetic back for attachment to metal surfaces and a retractable stand for tabletop use.
- **Power On/Off Switch:** Helps conserve battery life.



Figure 2: Overview of timer functionalities.

3. Package Contents

Your NKOVE Digital Kitchen Timer package should include:

- 1 x NKOVE Digital Kitchen Timer Unit
- 1 x User Manual

Note: AAA batteries are required and may not be included. Please check product packaging for specific battery inclusion details.

4. Setup

4.1 Battery Installation

1. Locate the battery compartment cover on the back of the timer.
2. Slide the cover open.
3. Insert one AAA battery, ensuring correct polarity (+/-).
4. Close the battery compartment cover securely.

4.2 Initial Power On

After installing the battery, the timer will automatically power on and display the default time or '0:00:00'.



Figure 3: Back view of the timer with battery compartment and stand.

5. Operating Instructions

The timer features three main modes: TIMER, CLOCK, and ALARM. Press the**MODE** button to cycle through these functions.

5.1 Clock Setting

1. Press the **MODE** button until "CLOCK" appears on the screen.
2. Hold the **START/STOP** button for three seconds until the time display starts blinking.
3. Press the **HOUR**, **MIN**, and **SEC** buttons to set the desired time.
4. Press **START/STOP** again to activate the clock; the ":" will begin to blink.



Figure 4: Visual guide for setting the clock.

5.2 Timer Function (Count-Up)

1. Press the **MODE** button until "TIMER" is displayed and the screen shows "0:00:00".
2. Press the **START/STOP** button to begin counting up. The "COUNT-UP" symbol will appear.
3. Press **START/STOP** again to pause the count-up.

4. Press the **CLEAR** button to reset the timer to "0:00:00".

5.3 Timer Function (Count-Down)

1. Press the **MODE** button until "TIMER" is displayed and the screen shows "0:00:00".
2. Use the **HOUR**, **MIN**, and **SEC** buttons to set your desired countdown time. Hold down the buttons for fast forward adjustment.
3. Press the **START/STOP** button to begin the countdown.
4. Press **START/STOP** again to pause the countdown.
5. When the countdown reaches zero, the alarm will sound (if enabled) and the LED indicator will flash.
6. Press any button to stop the alarm. The timer will return to the last set time due to the memory function.
7. Press the **CLEAR** button to reset the timer to "0:00:00".



Figure 5: Visual guide for setting the countdown timer.

5.4 Alarm Setting

1. Press the **MODE** button until "ALARM" appears on the screen.
2. Hold the **HOUR** button for three seconds until the alarm time display starts blinking.
3. Press the **HOUR**, **MIN**, and **SEC** buttons to set your desired alarm time.
4. Press **START/STOP** to confirm the alarm time and activate the alarm. The alarm icon will appear on the display.
5. To deactivate the alarm, press **START/STOP** again. The alarm icon will disappear.



Figure 6: Visual guide for setting the alarm.

5.5 Silent / Audible Mode Switching

On the back of the timer, there is a physical switch to toggle between silent mode and audible alarm mode. In silent mode, the LED indicator will flash when the timer or alarm finishes. In audible mode, the timer will beep loudly.



Figure 7: Silent mode (top) and audible alarm mode (bottom) in use.

5.6 Placement Options

The NKOVE Digital Kitchen Timer offers flexible placement options:

- **Magnetic Back:** Strong magnets allow you to attach the timer to metal surfaces like refrigerators or ovens.
- **Retractable Stand:** A built-in stand can be pulled out to prop the timer on a countertop or table.



Figure 8: Examples of versatile timer placement.

6. Maintenance

6.1 Cleaning

To clean your timer, wipe it with a soft, damp cloth. Do not use abrasive cleaners or immerse the unit in water.

6.2 Battery Replacement

When the display dims or the timer functions become erratic, it's time to replace the AAA battery. Follow the battery installation steps in Section 4.1.

7. Troubleshooting

Problem	Possible Cause	Solution
Display is blank or dim.	Low or dead battery.	Replace the AAA battery.
Alarm is not sounding.	Timer is in silent mode.	Switch to audible mode using the switch on the back.
Timer not responding to button presses.	Battery issue or temporary malfunction.	Remove and reinsert the battery. If the issue persists, replace the battery.
Time is inaccurate.	Internal clock deviation.	Reset the clock as per Section 5.1. If inaccuracy continues, consider replacing the battery.

8. Specifications

- **Brand:** Nkove
- **Model Number:** 5M-SMII-OI19
- **Material:** Plastic
- **Color:** White
- **Product Dimensions:** 1.6"D x 3.1"W x 3.1"H (4.06 cm D x 7.87 cm W x 7.87 cm H)
- **Item Weight:** 4.8 ounces (136 grams)
- **Screen Size:** 3.1 Inches
- **Power Source:** 1 x AAA Battery (not always included)
- **UPC:** 769293818579

9. Warranty and Support

NKOVE offers a 100% satisfaction guarantee. If you encounter any product issues, please contact our customer service for assistance, including refunds or replacements. The product is eligible for returns within 30 days of purchase.
For further support, please refer to the contact information provided with your purchase or visit the official Nkove store online.

10. Product Overview Video

Watch video online

NKOVE Digital Kitchen Timer 24 Hour Clock and Alarm Function

Video: An official overview of the NKOVE Digital Kitchen Timer, demonstrating its various functions and features.

© 2026 Nkove. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D5Y8K47L

More documents and user manuals: **https://manuals.plus/**