Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LEXiBOOK HPBT05HP

LEXiBOOK Harry Potter Wireless Earbuds User Manual

Model: HPBT05HP | Brand: LEXiBOOK

Introduction

This manual provides essential instructions for the safe and efficient use of your LEXiBOOK Harry Potter Wireless Earbuds (Model: HPBT05HP). Please read this manual thoroughly before using the product and retain it for future reference.

What's in the Box

- 1 pair of LEXiBOOK Harry Potter Wireless Earbuds
- 1 Charging Case
- 1 USB-C Charging Cable
- 1 Instruction Manual (this document)

Product Overview

The LEXiBOOK Harry Potter Wireless Earbuds are designed for children aged 8 and above, featuring a volume limit of 85 dB for hearing protection. They offer touch controls for audio playback and call management, and come with a portable charging case.



Image 1: The Harry Potter themed charging case open, revealing the two earbuds inside. The case features the Hogwarts crest and house emblems.



Image 2: A side view of the open charging case with earbuds, highlighting the compact design and house emblems.



Image 3: A top-down view of the closed charging case, showcasing the Hogwarts crest on the lid and the four house emblems on the front.



Image 4: The two individual earbuds, showing their design and the "H" logo on the stems.

Controls:

The earbuds feature touch controls for various functions:

- **Play/Pause:** Tap once on either earbud.
- **Next Track:** Double-tap the right earbud.
- **Previous Track:** Double-tap the left earbud.
- **Answer/End Call:** Tap once on either earbud during an incoming call.
- **Reject Call:** Press and hold either earbud for 2 seconds during an incoming call.
- **Activate Voice Assistant:** Triple-tap either earbud (if supported by your device).

Setup

1. Charging the Earbuds and Case:

1. Place both earbuds into the charging case.
2. Connect the provided USB-C cable to the charging port on the case and to a compatible USB power source (e.g., computer, wall adapter).
3. The indicator light on the case will show charging status. A full charge typically takes approximately 1-2 hours.
4. Once fully charged, disconnect the cable.

Note: Ensure the charging case is sufficiently charged to power the earbuds.

2. Pairing with a Bluetooth Device:

1. Ensure the earbuds are charged.
2. Open the charging case. The earbuds will automatically enter pairing mode, indicated by a flashing LED light on the earbuds.
3. On your device (smartphone, tablet, etc.), go to the Bluetooth settings.
4. Search for available devices and select **"HPBT05HP"** from the list.
5. Once connected, the LED indicator on the earbuds will stop flashing or show a solid light, depending on the model.
6. If prompted, confirm the pairing.

The earbuds will automatically reconnect to the last paired device when removed from the case, if Bluetooth is enabled on the device.

Operating Instructions

Wearing the Earbuds:

Gently insert the earbuds into your ears, ensuring a comfortable and secure fit. The left earbud is marked 'L' and the right earbud 'R'.

Audio Playback:

- **Play/Pause:** Tap once on either earbud.
- **Next Track:** Double-tap the right earbud.
- **Previous Track:** Double-tap the left earbud.

Phone Calls:

- **Answer/End Call:** Tap once on either earbud during an incoming call.
- **Reject Call:** Press and hold either earbud for 2 seconds during an incoming call.

Volume Control:

The volume is limited to 85 dB for child safety. Adjust the volume directly on your connected device.

Maintenance

- Clean the earbuds and charging case regularly with a soft, dry cloth.
- Avoid using abrasive cleaners or solvents.
- Do not expose the product to extreme temperatures, humidity, or direct sunlight.
- Store the earbuds in their charging case when not in use to protect them and keep them charged.
- The earbuds are rated as "Waterproof" but this typically refers to resistance against splashes, not submersion. Avoid prolonged exposure to water.

Troubleshooting

Problem	Solution
Earbuds not turning on.	Ensure the earbuds and charging case are fully charged.
Cannot pair with device.	Make sure Bluetooth is enabled on your device. Ensure earbuds are in pairing mode (flashing LED). Move the earbuds closer to your device (within 10 meters). Forget "HPBT05HP" from your device's Bluetooth list and try pairing again. Perform a hard reset (refer to manufacturer's website if needed, as specific steps are not provided).
No sound or low volume.	Check the volume level on your connected device. Ensure earbuds are properly connected and selected as the audio output. Clean any debris from the earbud speakers.
Earbuds disconnect frequently.	Ensure you are within the 10-meter Bluetooth range. Avoid obstacles between the earbuds and your device. Check for interference from other wireless devices.

Specifications

Feature	Detail
Model Name	HPBT05HP
Connectivity Technology	Wireless (Bluetooth)
Bluetooth Version	5.0
Bluetooth Range	Up to 10 meters
Battery Life	3 to 4 hours (continuous listening)
Charging Port	USB-C
Control Method	Touch
Integrated Microphone	Yes
Volume Limit	85 dB (Child Safe)
Compatible Devices	Smartphones, Tablets, Laptops, Desktops, and Other Media Players with Bluetooth
Material	Plastic
Item Weight	1.28 ounces
Product Dimensions	1.97 x 1.97 x 0.83 inches
Water Resistance Level	Waterproof
Age Range (Description)	8+

Official Product Video

▶ **Watch video online**
LEXiBOOK Harry Potter Wireless Earbuds

Video 1: An official product video showcasing the LEXiBOOK Harry Potter Wireless Earbuds, highlighting key features such as child-safe volume, touch controls, and Harry Potter themed design.

Warranty and Support

For warranty information and customer support, please refer to the official LEXiBOOK website or contact your retailer. Keep your proof of purchase for any warranty claims.
Visit the official LEXiBOOK Store on Amazon for more products and information.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D6299HXT

More documents and user manuals: **https://manuals.plus/**