Fanxieast P4 Wireless Controller

Fanxieast Wireless Controller User Manual

Model: P4 Wireless Controller

1. Introduction

Thank you for purchasing the Fanxieast Wireless Controller. This manual provides detailed instructions on how to set up, operate, and maintain your controller. Please read this manual thoroughly before use to ensure optimal performance and a satisfying gaming experience.

Image 1: The Fanxieast P4 Wireless Controller, featuring a classic black design with illuminated central light bar and touchpad.

2. Product Features

The Fanxieast Wireless Controller is equipped with a variety of advanced features designed to enhance your gaming experience:

- **Multi-functional Design:** Includes continuous fire (turbo) function, dual vibration, accelerometer, gravity sensing, touch button, and touchpad.
- **Immersive Feedback:** Built-in LED light and speaker. Features a 6-axis gyro sensor and vibration motors that react instantly to in-game actions, providing precise control and immersive feedback.
- **Enhanced Control:** High operability of both left and right directional buttons allows for precise movements in games.
- **Audio Connectivity:** A 3.5mm earphone jack provides an immersive audio experience when using a headset.
- **Ergonomic Design:** Constructed from durable materials with an ergonomic shape that fits comfortably in your hands, reducing fatigue during extended play. Anti-slip pads prevent slipping even with sweaty hands.

Image 2: Overview of controller features including 3-stage turbo, vibration, gyro sensor, durable buttons, Bluetooth, and large capacity battery.

3. Compatibility

This wireless controller is compatible with the following platforms:

- P3
- P4
- P4 Pro
- P4 Slim
- PC (Windows 7/8/10)

It is also compatible with the P4 system software version. When connected to a computer via a USB cable, it functions as a wired controller.

Image 3: The controller is compatible with P4, P4 Pro, P4 Slim, Laptops, and PCs, offering versatile gaming options.

4. Setup and Connection

4.1 Initial Pairing (Wireless)

1. Ensure your P4 console or PC's Bluetooth function is enabled.
2. On the controller, press and hold the**SHARE** button and the **PS** button simultaneously until the light bar begins to flash rapidly. This indicates pairing mode.
3. On your P4 console or PC, navigate to the Bluetooth settings and select the controller from the list of available devices.
4. Once connected, the light bar will stop flashing and remain illuminated, indicating a successful connection.

The controller features a stable Bluetooth connection with a data transfer speed of 2.1Mbps, ensuring low latency and a smooth gaming experience. The communication distance with P4, P3, or PC can be up to 10 meters, and up to four controllers can be used simultaneously.

4.2 Wired Connection (PC)

To use the controller as a wired device with a PC (Windows 7/8/10), simply connect it using a USB cable. The PC will automatically detect and install the necessary drivers.

5. Operating Instructions

5.1 Turbo (Continuous Fire) Function

The controller supports a 3-stage turbo function. To adjust the continuous fire speed:

1. Press and hold the **SHARE** button.
2. While holding **SHARE**, press the desired action button (e.g., X, O, Square, Triangle) to activate turbo mode for that button.
3. To cycle through the turbo speeds (5 shots/sec, 12 shots/sec, 20 shots/sec), press the**SHARE** button and move the right analog stick up or down.

Image 4: Visual guide for activating and adjusting the 3-stage Turbo function, showing speeds of 5, 12, and 20 shots per second.

5.2 Vibration Adjustment

The controller features a four-stage vibration adjustment:

- 0% (No vibration)
- 30% (Weak vibration)
- 70% (Normal vibration)
- 100% (Strong vibration)

Refer to your game's settings or the controller's specific button combinations (if available) to adjust vibration intensity.

Image 5: Illustration of the four-stage vibration adjustment, from 0% to 100% intensity.

5.3 Touchpad Functionality

The high-precision touchpad supports various interactive methods, including dragging, sliding, and multi-point input, offering new gameplay experiences.

Image 6: The touchpad supports various gestures like dragging, sliding, and multi-touch for enhanced interaction.

5.4 Gyro Sensor

The integrated 6-axis gyro sensor provides precise motion control, enhancing directional control, field of view movement, and target aiming in compatible games.

Image 7: The 6-axis gyro sensor enables precise control for direction, field of view, and aiming in games.

5.5 Other Features

- **3.5mm Earphone Jack:** Connect your headset for in-game audio and communication.
- **Share Function:** Utilize the SHARE button for in-game sharing features.

Image 8: Key features including the 3.5mm earphone jack, Share button, and the location of the reset button.

6. Battery and Charging

The controller is equipped with a 1000mAh high-capacity rechargeable battery. A full charge provides over 10 hours of continuous gameplay. The controller features a low-voltage warning function to prevent interruptions due to low power.

Image 9: The controller features a 1000mAh battery, allowing for extended gaming sessions.

6.1 Charging

Connect the controller to your P4 console or a USB power source using the provided USB cable. The light bar will indicate charging status and turn off when fully charged.

7. Maintenance

- Keep the controller clean by wiping it with a soft, dry cloth.
- Avoid exposing the controller to extreme temperatures, humidity, or direct sunlight.
- Do not disassemble the controller, as this will void the warranty.
- Store the controller in a safe place when not in use to prevent damage.

8. Troubleshooting

8.1 Controller Not Connecting

If you experience issues with connection, locate the small reset button on the back of the controller (a 2mm hole). Use a needle or a small pointed object to press this button. This will reset the controller and may resolve connection problems.

8.2 Power Off

To power off the controller, press and hold the **PS** button for approximately 10 seconds.

8.3 Game Compatibility Note

Please note that this controller may not be ideally suited for certain games such as FF14, FPS (First-Person Shooter), or TPS (Third-Person Shooter) titles. Your understanding is appreciated.

9. Specifications

Feature	Specification
Model	P4 Wireless Controller
Connectivity	Wireless Bluetooth, Wired USB
Battery Capacity	1000mAh
Continuous Playtime	Over 10 hours (fully charged)
Wireless Range	Up to 10 meters
Sensors	6-axis Gyro Sensor, Accelerometer, Gravity Sensor
Vibration	Dual Vibration (4-stage adjustable)
Audio Port	3.5mm Headphone Jack
Dimensions	17.3 x 11.7 x 7.1 cm
Weight	280 g

10. Warranty and Support

This product comes with a **one-year warranty**. For initial defects or malfunctions, returns are accepted, and a new product will be provided without the need for repair.
For any inquiries or support, please contact us through your order history on Amazon. Our customer service is available from 9:00 to 23:00 (year-round).
The product has obtained various certifications including TELEC, CE, FCC, RED, and ROHS, ensuring quality and safety standards.

Image 10: Display of various product certifications, including TELEC, CE, FCC, RED, and ROHS.