Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Olympia 2226

Olympia Vitus 4G Dual-SIM User Manual

Model: 2226

Introduction

Thank you for choosing the Olympia Vitus 4G Dual-SIM mobile phone. This manual provides essential information for setting up, operating, and maintaining your device. Please read it carefully to ensure proper use and to maximize the lifespan of your phone.

Safety Information

Always follow basic safety precautions when using this product to reduce the risk of injury, fire, or electric shock. Keep the device away from water and extreme temperatures. Do not attempt to disassemble or repair the phone yourself. Use only approved accessories.

Package Contents

Ensure all items are present in the package:

- Olympia Vitus 4G Dual-SIM Mobile Phone
- Desktop Charger
- USB Cable
- Rechargeable Li-Ion Battery Pack
- User Manual (this document)

Setup

1. Inserting SIM Cards and MicroSD Card

The Olympia Vitus 4G supports Dual-SIM functionality, allowing you to use two SIM cards simultaneously. It also features a MicroSD slot for expandable storage up to 64 GB.

1. Carefully open the back cover of the phone.
2. Insert your SIM card(s) into the designated SIM slots. Ensure they are correctly oriented.
3. If desired, insert a MicroSD card into the MicroSD slot.
4. Close the back cover securely.


10:26
09.08.2023
Mittwoch
OLYMPIA



Figure 1: Front view of the Olympia Vitus 4G, illustrating the display and keypad area.

2. Battery Installation and Charging

The phone comes with a rechargeable Li-Ion battery pack. For first use, fully charge the battery.

1. After inserting SIM/MicroSD cards, insert the Li-Ion battery pack into its compartment, ensuring the contacts align.
2. Place the phone into the provided desktop charger, or connect the USB cable directly to the phone's charging port and a power source.
3. The phone will indicate charging status on its display. Allow the battery to charge completely before first use.





Figure 2: The Olympia Vitus 4G in its desktop charger, ready for use.

3. Powering On/Off

Press and hold the Power/End Call button to turn the phone on or off.

Operating Instructions

Basic Functions

- **Making Calls:** Enter the phone number and press the Call button.
- **Answering Calls:** Press the Call button when the phone rings.
- **Sending Messages:** Navigate to the Messaging menu to compose and send SMS.

Keypad and Display

The phone features extra large backlit dial keys for easy visibility. The dual-color LC-display (2.8" + 1.77") provides clear information. Symbol fields are available for menu control.

- **Direct Dial Keys:** Utilize the two direct dial keys for quick access to frequently called numbers.
- **Key Lock:** Activate the key lock to prevent accidental presses.
- **Volume Control:** Adjust call and ringtone volume using the dedicated volume buttons.

Advanced Features

- **Phonebook:** Store up to 2000 entries.
- **Hands-free Function:** Enable hands-free calling for convenience.
- **FM Radio:** Enjoy your favorite radio stations.
- **Bluetooth:** Connect to compatible Bluetooth devices.

- **Integrated Camera:** Capture photos with the built-in camera.
- **Integrated Mini-Flashlight:** Use the flashlight for illumination.
- **SOS Emergency Button:** In case of emergency, press the SOS button to activate predefined emergency calls/messages.
- **HAC (Hearing Aid Compatible):** Designed for use with hearing aids.
- **Vibration Alarm:** Set the phone to vibrate for incoming calls or messages.
- **Date/Time/Alarm Function:** Manage time, date, and set alarms.
- **Automatic Charging Reminder via SMS:** Receive reminders when your phone needs charging.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the phone's surface. Avoid liquid cleaners.
- **Battery Care:** To prolong battery life, avoid extreme temperatures. Do not leave the battery fully discharged for extended periods.
- **Storage:** If storing the phone for a long time, charge the battery to about 50% and store it in a cool, dry place.

Troubleshooting

Problem	Possible Cause / Solution
Phone does not turn on	Battery is discharged. Charge the battery. Battery not inserted correctly. Reinsert battery.
Cannot make/receive calls	No network signal. Move to an area with better reception. SIM card not inserted correctly or not activated. Check SIM card.
Short battery life	High usage of 4G network. 4G connectivity consumes more power than 2G. In areas with weak signal, the phone may consume more power searching for network. Reduce usage of power-intensive features. Ensure full charge before use.
Display is blank	Phone is in standby mode. Press any key to wake up. Battery is low. Charge the battery.

Specifications

- **Model Name:** Vitus
- **Model Number:** 2226
- **Brand:** Olympia
- **Form Factor:** Flip
- **Color:** Black
- **Display:** Dual Color LC-Display (2.8" + 1.77") with backlight
- **Mobile Technology:** 4G (GSM Standard Quad Band)
- **SIM Card Slots:** Dual-SIM
- **Internal Phonebook:** 2000 entries
- **Expandable Storage:** MicroSD Slot (up to 64 GB)
- **Connectivity:** Bluetooth
- **Battery:** Rechargeable Li-Ion Battery Pack
- **Standby Time:** Up to 200 hours (Note: Actual standby time may vary significantly based on network conditions, 4G usage, and signal strength.)

- **Talk Time:** Up to 4 hours
- **Special Features:** SOS Emergency Button, HAC (Hearing Aid Compatible), FM Radio, Integrated Camera, Integrated Mini-Flashlight, Vibration Alarm, Automatic Charging Reminder via SMS, Extra large backlit dial keys, Hands-free function, Date/Time/Alarm function, Key lock, Volume control, SIM-Lock free.
- **Weight:** 280 Grams
- **Dimensions:** 106 x 56 x 19 mm
- **Country of Origin:** China

Warranty and Support

This product is sold as new from a specialist dealer. For specific warranty terms and conditions, please refer to the documentation provided at the time of purchase or contact your retailer directly. For technical support, please contact Olympia customer service.
Note: The manufacturer's stated standby time of up to 200 hours is based on optimal 2G network conditions. Actual battery performance, especially in 4G networks or areas with weak signal, may be significantly lower due to increased power consumption for maintaining connectivity.

© 2024 Olympia. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D6LT7PC1

More documents and user manuals: **https://manuals.plus/**