Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

VASAGLE LRC032B04

VASAGLE 4-Tier Slim Kitchen Cart

Model: LRC032B04

Important Safety Information

Please read and understand all instructions before assembly and use. Keep this manual for future reference.

- **Warning:** Use the cart with caution to avoid tipping.
- Ensure that the weight remains on the mesh shelves inside the edge to protect items from falling.
- Do not overload the shelves. Refer to the 'Specifications' section for maximum weight recommendations.
- Keep small parts away from children during assembly.

Package Contents

Before you begin, ensure all parts listed in the assembly instructions are present and undamaged. If any parts are missing or damaged, please contact customer support.



Image: Detailed view of the cart with dimensions, illustrating various components.

The package includes all necessary components and tools for assembly, typically consisting of a steel frame, particleboard top, mesh shelves, wheels, a handle, and various fasteners.

Assembly Instructions

Assembly is straightforward with illustrated instructions and numbered parts. It is recommended to assemble the cart on a soft, clean surface to prevent scratches.

1. **Unpack and Identify Parts:** Carefully unpack all components and lay them out. Refer to the included parts list to identify each piece.
2. **Attach Wheels:** Secure the four wheels to the bottom of the cart's frame. Ensure they are firmly tightened for stability.
3. **Assemble Frame:** Connect the vertical steel frame sections according to the numbered diagrams.
4. **Install Mesh Shelves:** Slide the mesh shelves into their designated slots on the frame. The raised edges should face upwards to prevent items from falling.
5. **Attach Top Panel:** Place the particleboard top panel onto the uppermost frame section and secure it with the provided fasteners.
6. **Install Handle:** Attach the steel handle to the side of the top panel.
7. **Final Check:** Once assembled, gently shake the cart to ensure all connections are secure and the cart is stable.



Image: Detail of the mesh shelf with raised edges, designed to prevent items from falling.



Image: Detail of the practical steel handle for easy maneuvering.



Image: Detail of the 360-degree swivel wheels for smooth movement.

Operating Instructions

The VASAGLE 4-Tier Slim Kitchen Cart is designed for versatile storage in various small spaces.

- **Space Optimization:** Its slim 13 cm width makes it ideal for narrow gaps in kitchens, bathrooms, offices, living rooms, and bedrooms.
- **Easy Mobility:** Utilize the four smooth-rolling wheels and the integrated steel handle to effortlessly move the cart to your desired location.
- **Ample Storage:** The cart features a top surface for frequently accessed items and three mesh shelves for organizing jars, bottles, and other supplies. The raised edges on the mesh shelves help secure items in place.
- **Versatile Use:** Suitable for storing spices, cleaning supplies, office essentials, or personal care products.



Image: The cart in a kitchen setting, demonstrating its use for storing kitchen essentials.



Image: The cart in a bathroom setting, showcasing its narrow design and utility for bathroom storage.

Maintenance

To ensure the longevity and appearance of your VASAGLE Slim Kitchen Cart, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the cart with a dry cloth to remove dust and light dirt. For more stubborn marks, use a slightly damp cloth and mild detergent, then dry immediately.

- **Avoid Harsh Chemicals:** Do not use abrasive cleaners or harsh chemicals, as these can damage the finish of the steel frame and particleboard top.
- **Regular Checks:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary to maintain stability.
- **Weight Distribution:** Distribute items evenly across the shelves to prevent strain on the frame and maintain balance.

Troubleshooting

If you encounter any issues with your cart, refer to the following common problems and solutions:

- **Cart is Unstable/Wobbly:**
  Solution: Ensure all screws and fasteners are securely tightened. Check that the cart is on a flat, even surface. Uneven weight distribution can also cause instability; redistribute items if necessary.
- **Wheels Not Rolling Smoothly:**
  Solution: Check for any debris or hair caught in the wheels. Clean them thoroughly. Ensure the wheels are properly attached and not overtightened, which can restrict movement.
- **Items Falling Off Shelves:**
  Solution: Ensure items are placed within the raised edges of the mesh shelves. Avoid stacking items too high. Consider placing heavier items on lower shelves for better stability.
- **Difficulty Assembling:**
  Solution: Double-check the illustrated instructions and ensure all parts are correctly identified and oriented. Do not force parts together; if they don't fit, re-examine the steps.

Specifications

Feature	Detail
Model Number	LRC032B04
Product Dimensions (D x W x H)	13 x 45.4 x 77 cm (5.1 x 17.9 x 30.3 inches)
Shelf Type	Multi-tier shelf
Material	Alloy Steel, Particleboard
Frame Material	Alloy Steel
Color	Black Wood Grain + Black
Furniture Finish	Ebony Black
Style	Modern Style
Maximum Weight Recommendation	22 pounds (approx. 10 kg)
Item Weight	2.8 Kilograms (6.17 pounds)
Number of Shelves	4
Is Extendable	No
UPC / GTIN	194343267623

Warranty and Support

Specific warranty information for the VASAGLE LRC032B04 4-Tier Slim Kitchen Cart is not available in the provided product data. For details regarding warranty coverage, returns, or technical support, please contact the manufacturer, VASAGLE, directly or refer to their official website.

You can often find contact information on the product packaging or through the retailer where the product was purchased.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D6V9HM87

More documents and user manuals: **https://manuals.plus/**