Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Minolta MN26Z

Minolta MN26Z 20MP 26x Optical Zoom Digital Camera User Manual

Model: MN26Z

Introduction

This manual provides comprehensive instructions for the safe and effective operation of your Minolta MN26Z 20MP 26x Optical Zoom Digital Camera. Please read this manual thoroughly before using the camera and retain it for future reference. Understanding the features and functions will help you capture high-quality photos and videos.

Product Overview

Camera Components

The Minolta MN26Z is a bridge camera designed for versatility and ease of use. Key components include the lens, flash, LCD screen, and various control buttons.



Figure 1: Front-side view of the Minolta MN26Z Digital Camera, showing the lens, flash, and grip.



Figure 2: Back view of the Minolta MN26Z Digital Camera, displaying the LCD screen and control buttons.

Key Features

- **20 Megapixel Sensor:** Captures high-resolution images with clarity.
- **26x Optical Zoom:** Allows for detailed close-ups from a distance without compromising image quality.
- **1080p Full HD Video:** Records smooth, high-definition video.

- **Intuitive Controls:** User-friendly interface suitable for various skill levels.
- **Optical Image Stabilization:** Helps reduce blur caused by camera shake.
- **Face, Smile, and Blink Detection:** Enhances portrait photography by optimizing focus and capture timing.
- **Multiple Scene Modes:** Includes modes like Landscape, Portrait, Sports, Night, and Movie for various shooting conditions.
- **Wi-Fi Connectivity:** Enables wireless transfer of photos and videos to compatible devices.

Setup

1. Battery Installation and Charging

The camera uses a Lithium-Ion battery. Ensure the battery is fully charged before first use.

1. Open the battery compartment cover located at the bottom of the camera.
2. Insert the battery according to the polarity indicators (+/-).
3. Close the battery compartment cover securely.
4. Connect the camera to a power source using the provided USB cable and charger to charge the battery. The charging indicator light will show the charging status.

2. Memory Card Insertion

The Minolta MN26Z supports SD and Micro SD memory cards (up to 32GB recommended for optimal performance).

1. Locate the memory card slot, usually next to the battery compartment.
2. Insert the memory card with the metal contacts facing the correct direction, as indicated by the diagram near the slot.
3. Push the card gently until it clicks into place. To remove, push it again until it springs out.

3. Initial Power On and Settings

1. Press the **ON/OFF** button to power on the camera.
2. Follow the on-screen prompts to set the language, date, and time.
3. Format the memory card before first use to ensure compatibility and optimal performance. Navigate to the camera's menu, find "Format Card," and confirm.

Operating the Camera

1. Basic Photography

- **Power On:** Press the **ON/OFF** button.
- **Mode Dial:** Rotate the mode dial (located on top of the camera) to select your desired shooting mode (e.g., Auto, Program, Scene modes).

- **Framing:** Use the LCD screen to compose your shot.
- **Zoom:** Use the zoom lever (usually around the shutter button) to zoom in or out. The 26x optical zoom allows for significant magnification.
- **Focus:** Press the shutter button halfway down to autofocus. The focus frame will appear on the screen.
- **Capture:** Press the shutter button fully down to take a picture.

2. Video Recording

- **Select Movie Mode:** Turn the mode dial to the movie camera icon or select "Movie Mode" from the scene modes.
- **Start Recording:** Press the dedicated video recording button (often marked with a red dot) to begin recording.
- **Stop Recording:** Press the video recording button again to stop.
- The camera records in 1080p Full HD resolution.

▶ **Watch video online**
MINOLTA MN26Z 20 MP 1080P FHD Digital Camera

Video: Official product video demonstrating key features and usage of the Minolta MN26Z digital camera, including optical zoom, scene modes, and Wi-Fi connectivity. Duration: 0:55.

3. Scene Modes and Special Features

The MN26Z offers various scene modes to optimize settings for different situations:

- **Automatic:** Camera automatically selects optimal settings.
- **Landscape:** Enhances colors and sharpness for scenic shots.
- **Portrait:** Softens skin tones and blurs backgrounds for flattering portraits.
- **Sports:** Uses faster shutter speeds to freeze action.
- **Macro:** For close-up photography of small subjects.
- **Night Mode:** Optimizes settings for low-light conditions.
- **Burst Mode:** Captures a rapid sequence of photos for fast-moving subjects.

4. Wi-Fi Connectivity

Connect your camera to a smartphone or tablet via Wi-Fi to transfer images and videos or control the camera remotely.

1. Enable Wi-Fi on your camera through the menu settings.
2. Download the compatible Minolta app on your mobile device.
3. Connect your mobile device to the camera's Wi-Fi network (SSID and password usually displayed on the camera screen).
4. Use the app to browse, download, and share your media.

Maintenance

- **Cleaning the Lens:** Use a soft, lint-free cloth specifically designed for camera lenses. Avoid touching the lens surface with your fingers.
- **Cleaning the Body:** Wipe the camera body with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with

water. Do not use solvents.

- **Storage:** When not in use, store the camera in a cool, dry place, away from direct sunlight and extreme temperatures. Remove the battery if storing for extended periods.
- **Memory Card Care:** Handle memory cards carefully. Avoid bending or exposing them to static electricity.

Troubleshooting

Problem	Possible Cause	Solution
Camera does not power on.	Battery is depleted or incorrectly inserted.	Charge the battery. Ensure the battery is inserted with correct polarity.
Cannot take pictures.	Memory card is full, locked, or not inserted.	Insert a memory card, ensure it's unlocked, or delete unnecessary files.
Images are blurry.	Camera shake, out of focus, or low light.	Hold the camera steady, use a tripod, ensure proper focus, or use flash/increase ISO in low light.
Wi-Fi connection fails.	Incorrect password, app not running, or distance too far.	Verify password, ensure app is open, and move closer to the camera.

Specifications

Feature	Detail
Brand	Minolta
Model Name	MINOLTA MN26Z
Effective Still Resolution	20 MP
Optical Zoom	26x
Video Resolution	1080p (Full HD)
Photo Sensor Technology	CMOS
Image Stabilization	Digital
Supported File Format	JPEG, RAW
Connectivity Technology	Wi-Fi

Feature	Detail
Screen Size	3 Inches
Battery Type	Lithium Ion
Item Weight	2.66 Pounds
Shooting Modes	Automatic, Landscape, Macro, Movie, Portrait, Sports
Memory Storage Capacity	32 GB (with included card)

Warranty and Support

For warranty information and technical support, please refer to the warranty card included with your product or visit the official Minolta website. Keep your proof of purchase for warranty claims.
For additional assistance, you may contact the seller, 6ave, through your purchase platform.

© 2025 Minolta. All rights reserved.
This manual is for informational purposes only. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D6ZG7QSZ

More documents and user manuals: **https://manuals.plus/**