Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Panasonic SR-HVD1010-T

Panasonic IH Rice Cooker

Model: SR-HVD1010-T

Introduction

Thank you for purchasing the Panasonic IH Rice Cooker SR-HVD1010-T. This manual provides essential information for the safe and efficient use of your new appliance. Please read these instructions thoroughly before use and keep them for future reference.

Important Safety Information

- Always ensure the power supply matches the appliance's requirements.
- Do not immerse the main unit in water or other liquids.
- Keep out of reach of children.
- Do not operate if the power cord or plug is damaged.
- Refer to the full safety guidelines in the printed manual for comprehensive details.

Product Overview

The Panasonic IH Rice Cooker SR-HVD1010-T is designed to deliver perfectly cooked rice with advanced IH (Induction Heating) technology and a Diamond Copper Pot.

Key Features:

- **Diamond Copper Pot:** Ensures even heat distribution to each grain of rice for optimal cooking.
- **Umami Aging Soaking:** A specialized soaking process that enhances the natural sweetness and flavor of the rice without degradation.
- **Mixed Rice Course:** Designed to make mixed rice dishes fluffy and allow flavors to be easily absorbed.
- **Quick Cook Functionality:** Allows for delicious rice cooking immediately after washing, eliminating the need for pre-soaking.
- **Capacity:** 5.5 cups (1.0 liter) of uncooked rice.



Figure 1: Panasonic IH Rice Cooker SR-HVD1010-T. This image shows the front view of the rice cooker, highlighting its compact design and control panel.

Setup

1. **Unpacking:** Carefully remove the rice cooker and all accessories from the packaging. Retain packaging for future transport or storage.
2. **Initial Cleaning:** Before first use, wash the inner pot, inner lid, and rice scoop with warm soapy water. Rinse thoroughly and dry completely. Wipe the exterior of the main unit with a damp cloth.
3. **Placement:** Place the rice cooker on a stable, flat, heat-resistant surface, away from direct sunlight and heat sources. Ensure adequate ventilation around the unit.
4. **Power Connection:** Plug the power cord into a grounded electrical outlet. Ensure the voltage matches the specifications of the appliance.

Operating Instructions

Basic Rice Cooking:

1. **Measure Rice:** Use the provided measuring cup to measure the desired amount of rice. For the SR-HVD1010-T, the maximum capacity is 5.5 cups (1.0 liter).
2. **Wash Rice:** Wash the rice thoroughly until the water runs clear.
3. **Add Water:** Place the washed rice into the inner pot. Add water up to the corresponding water level mark inside the inner pot for the type and quantity of rice being cooked. The "Umami Aging Soaking" feature means pre-soaking is not required.
4. **Place Inner Pot:** Insert the inner pot into the main unit, ensuring it is seated correctly. Close the outer lid securely.
5. **Select Cooking Mode:** Press the "Menu" button to select your desired cooking mode (e.g., White Rice, Mixed Rice).
6. **Start Cooking:** Press the "Start" button to begin the cooking process. The display will show the remaining cooking time.
7. **After Cooking:** Once cooking is complete, the rice cooker will switch to "Keep Warm" mode. Fluff the rice with

the rice scoop and serve.

Mixed Rice Course:

The dedicated "Mixed Rice" course is optimized for dishes where ingredients are cooked with rice. Prepare your ingredients and seasonings, add them to the inner pot with the washed rice and water, then select the "Mixed Rice" course. This course ensures the rice is fluffy and absorbs flavors effectively.

Maintenance and Cleaning

Regular cleaning ensures optimal performance and longevity of your rice cooker.

Cleaning the Inner Pot and Inner Lid:

- After each use, remove the inner pot and inner lid.
- Wash them with a soft sponge and mild dish soap.
- Rinse thoroughly with water and dry completely before reassembling.
- **Important:** The inner pot is **not dishwasher safe**. Hand wash only to preserve its coating and performance.

Cleaning the Main Unit:

- Before cleaning, always unplug the power cord.
- Wipe the exterior of the main unit with a soft, damp cloth.
- Do not use abrasive cleaners, harsh chemicals, or scrub brushes, as these can damage the surface.
- Clean the steam vent and surrounding areas to prevent blockages.

Troubleshooting

Problem	Possible Cause	Solution
Rice is undercooked or too hard.	Insufficient water, incorrect water level, or incorrect cooking mode selected.	Ensure correct water-to-rice ratio. Select the appropriate cooking mode.
Rice is overcooked or too soft.	Too much water, incorrect water level, or incorrect cooking mode selected.	Reduce water slightly. Select the appropriate cooking mode.
Rice cooker does not start.	Power cord not properly plugged in, inner pot not seated correctly, or lid not closed.	Check power connection. Ensure inner pot is correctly placed and lid is fully closed.
Unusual odor during cooking.	Food residue on heating plate or steam vent.	Clean the heating plate and steam vent thoroughly.

If the problem persists after trying these solutions, please contact customer support.

Specifications

Feature	Detail
Brand	Panasonic

Feature	Detail
Model Number	SR-HVD1010-T
Cooking Method	IH (Induction Heating)
Capacity	1.0 Liter (5.5 cups)
Dimensions (Approx.)	Width 255mm × Height 366mm × Depth 210mm
Weight (Approx.)	4.1 kg
Power Cord Length (Approx.)	1.0 m
Inner Pot Material	Diamond Copper Pot
Inner Pot Thickness	1.7 mm
Color	Brown
JAN Code	4549980506301



Figure 2: Product label showing key specifications including cooking method, capacity, inner pot thickness, and inner pot warranty.

Warranty and Support

Warranty Information:

This product comes with a standard manufacturer's warranty. The inner pot specifically has a **3-year warranty**. Please retain your proof of purchase for warranty claims. For detailed warranty terms and conditions, refer to the warranty card included with your product or visit the official Panasonic website.

Customer Support:

For technical assistance, service, or inquiries regarding your Panasonic IH Rice Cooker, please contact Panasonic customer support. Contact details can typically be found on the official Panasonic website or in the warranty documentation.

Official Panasonic Website: www.panasonic.com

© 2024 Panasonic Corporation. All rights reserved.
This manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D78FQYXP

More documents and user manuals: **https://manuals.plus/**