**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



## SKATER ZPAS1-A

# Skater ZPAS1-A Pass Case Card Case with Reel Love Unicorn

User Manual

## Introduction

This manual provides comprehensive instructions for the Skater ZPAS1-A Pass Case Card Case with Reel Love Unicorn. Designed for convenience and style, this pass case is ideal for daily commuting, school, or work, allowing easy access to your cards without detaching the case from your bag.

Please read this manual carefully to ensure proper use and maintenance of your new pass case.

## Product Overview

The Skater ZPAS1-A Pass Case features a compact design with a charming Love Unicorn motif. It includes a retractable reel for extended reach and a secure hook for attachment.

### Key Features:

- **Compact Size:** Approximately 10 cm (3.9 inches) wide x 7.25 cm (2.8 inches) tall.
- **Reel Mechanism:** Equipped with a retractable reel that extends up to approximately 25 cm, allowing easy scanning of cards without removing the case from your bag.
- **Hook Fitting:** A sturdy hook for secure attachment to bags, backpacks, or belt loops.
- **Card Compatibility:** Designed to hold standard card sizes such as Suica, PASMO, credit cards, entrance cards, and commuter passes.
- **Durable Materials:** Constructed from Polyester, Vinyl chloride resin, and Zinc Alloy for longevity.

### Product Components:

- Pass Case Body (with card slot)
- Retractable Reel
- Attachment Hook
- Strap




Figure 1: Front view of the Skater Pass Case, showcasing the "Love Unicorn" design, black bow, and heart-shaped charm. The case is purple with a black strap and gold-colored hardware.



Figure 2: Back view of the Skater Pass Case, featuring a clear window for card display and a black and white plaid pattern on the reverse side.




Figure 3: Front view of the Skater Pass Case with approximate dimensions: 10 cm (3.9 inches) in width and 7.25 cm (2.8 inches) in height. The image also indicates the reel length of approximately 25 cm.

## Setup

Setting up your Skater Pass Case is straightforward. Follow these steps to prepare it for use:

1. **Unpack:** Carefully remove the pass case from its packaging.
2. **Insert Card:** Slide your desired commuter pass, ID card, or credit card into the designated card slot on the back of the pass case. Ensure it is fully inserted and visible through the clear window if applicable.




Figure 4: A hand demonstrating the insertion of a card into the pass case. The card is visible through the clear window on the back of the case.

3. **Attach to Bag:** Use the integrated hook fitting to securely attach the pass case to a loop, strap, or D-ring on your bag, backpack, or belt. Ensure the hook is fully closed to prevent accidental detachment.




Figure 5: The pass case securely attached to a black bag, demonstrating how it hangs for easy access during commuting.

## Operating Instructions

The Skater Pass Case is designed for ease of use, especially when navigating public transport or accessing buildings.

### Using the Reel Mechanism:

1. **Extend the Reel:** When approaching a ticket gate or card reader, simply pull the pass case away from your bag. The reel will extend smoothly, allowing you to reach the reader without detaching the case. The reel can extend up to approximately 25 cm.




Figure 6: A hand demonstrating the extension of the reel, showing the pass case being pulled away from its attachment point for scanning.

2. **Retract the Reel:** After scanning your card, release the pass case. The spring-loaded reel will automatically rewind, pulling the case back to its original position near your bag.

This reel feature eliminates the need to remove your bag or fumble for your card, making your daily commute more efficient.

## Maintenance

To ensure the longevity and appearance of your Skater Pass Case, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the surface of the pass case with a soft, damp cloth. For stubborn spots, a mild soap solution can be used, but avoid harsh chemicals or abrasive cleaners.
- **Drying:** Allow the pass case to air dry completely after cleaning. Do not expose it to direct sunlight or high heat, which can damage the materials.

- **Storage:** When not in use, store the pass case in a cool, dry place away from direct sunlight to prevent fading or material degradation.
- **Avoid Overstuffing:** Do not attempt to force too many cards into the slot, as this can stretch or damage the material and affect the fit of your cards.
- **Reel Care:** Avoid excessive pulling or sudden jerks on the reel, as this can damage the internal spring mechanism.

## Troubleshooting

If you encounter any issues with your Skater Pass Case, refer to the following common problems and solutions:

| Problem | Possible Cause | Solution |
|---|---|---|
| Reel does not retract fully. | Internal spring mechanism is damaged or obstructed. | Ensure the reel cord is not tangled. If the issue persists, the reel mechanism may be damaged and require replacement of the unit. |
| Card is difficult to insert or remove. | Too many cards inserted, or card is not aligned properly. | Remove excess cards. Ensure the card is inserted straight into the slot. |
| Hook fitting feels loose. | Wear and tear, or improper attachment. | Ensure the hook is securely fastened to a sturdy loop. If the hook is visibly damaged, consider replacing the unit. |

If you experience problems not listed here, or if the suggested solutions do not resolve the issue, please contact customer support.

## Specifications

| Attribute | Detail |
|---|---|
| Model Number | ZPAS1-A |
| Brand | SKATER |
| Color | Love Unicorn (Purple) |
| Material | Polyester, Vinyl chloride resin, Zinc Alloy |
| Product Dimensions (H x W) | Approx. 10 cm x 7.25 cm (3.9 inches x 2.8 inches) |
| Package Dimensions | 10.6 x 8.7 x 1.3 cm |
| Item Weight | 40 Grams |
| Reel Extension Length | Up to approx. 25 cm |
| Included Components | Card Holder (Pass Case with Reel and Hook) |
| Country of Origin | China |

## Warranty and Support

This product is manufactured by SKATER. For any inquiries regarding product defects or operational issues, please

refer to the retailer's return policy or contact the manufacturer directly.

Please retain your proof of purchase for any warranty claims or support requests.

© 2024 SKATER. All rights reserved.
Manual Version: 1.0

## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B0D82C7VWK**

More documents and user manuals: **https://manuals.plus/**