Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

OUKITEL OUKITEL G1

OUKITEL G1 Rugged Smartphone User Manual

Model: OUKITEL G1 | Brand: OUKITEL

1. Introduction and Overview

The OUKITEL G1 is a robust and versatile rugged smartphone designed for durability and high performance. It features a large battery, advanced camera system, and is built to withstand challenging environments, making it ideal for outdoor enthusiasts and professionals. This manual provides essential information to help you set up, operate, and maintain your device.



Image: Front and back view of the OUKITEL G1 Rugged Smartphone, showcasing its durable design and camera module.

2. Package Contents

Please verify that all items are present in your OUKITEL G1 package:

- 1 x OUKITEL G1 Smartphone
- 1 x Data Cable
- 1 x Charger
- 1 x Card Needle (SIM Ejector Tool)
- 1 x User Manual (this document)

3. Key Features

3.1. Performance and Operating System

The OUKITEL G1 is powered by Android 14, offering enhanced security and customizable features. It boasts 24GB RAM (6GB physical + 18GB virtual) and 256GB ROM, expandable up to 1TB, ensuring smooth performance and ample storage.



Image: The OUKITEL G1 running Android 14, highlighting its advanced operating system and user interface.



Image: Visual representation of the OUKITEL G1's 24GB RAM and 256GB ROM, powered by an Octa-Core processor for efficient multitasking and storage.

3.2. Durability and Resistance

Engineered for rugged outdoor use, the OUKITEL G1 is IP68/IP69K certified for water and dust resistance and meets MIL-STD-810H standards for shockproof durability. It can withstand immersion in 1.5 meters of water for 30 minutes and operates in extreme temperatures from -20°C to 55°C.



Image: The OUKITEL G1 demonstrating its IP68 waterproof, IP69K dustproof, and MIL-STD-810H military-grade durability in various challenging environments.

Video: OUKITEL G1 Rugged Smartphone undergoing rigorous testing to demonstrate its durability and resistance to drops and impacts.

Video: Demonstration of the OUKITEL G1's IP68/IP69K waterproof capabilities, showing its resilience in wet conditions.

3.3. Battery and Charging

Equipped with a 10600mAh battery, the OUKITEL G1 provides extended usage times: up to 1000 hours standby, 60 hours talk time, 18 hours video playback, and 10 hours gaming. It supports 18W fast charging for quick power replenishment.



Image: The OUKITEL G1 highlighting its massive 10600mAh battery capacity and 18W fast charging capability via Type-C port.

3.4. Display and Camera System

The 6.52-inch HD+ display offers clear and vivid visuals. Capture high-quality photos with the 48MP F1.8 main camera, a 5MP F2.2 front camera, and a 2MP macro camera for detailed close-up shots.



Image: The OUKITEL G1's 6.52-inch HD+ display protected by Corning Gorilla Glass 5, emphasizing its scratch resistance and high transparency.



Image: Overview of the OUKITEL G1's camera system, including the 48MP main camera, 2MP macro camera, and 5MP front camera, illustrating their uses.

3.5. Connectivity and Navigation

The OUKITEL G1 supports NFC and Google Pay for convenient transactions. It features dual SIM card slots or one slot for storage expansion. Accurate navigation is provided by GPS, GLONASS, Beidou, and Galileo. For security, it includes facial and rear fingerprint recognition.



Image: The OUKITEL G1 demonstrating its multi-functional capabilities, including precise GPS navigation and convenient NFC for mobile payments.



Image: The OUKITEL G1 illustrating its compatibility with T-Mobile carriers and listing the supported frequency bands for cellular communication.

Video: An overview of the OUKITEL G1 Rugged Smartphone, highlighting its key features and Android 14 operating system.

4. Setup

4.1. SIM Card and Storage Installation

To install your SIM card(s) and/or microSD card (for storage expansion up to 1TB), locate the SIM tray on the side of the device. Use the provided card needle to eject the tray. Carefully place your SIM card(s) and/or microSD card into the designated slots, ensuring correct orientation. Reinsert the tray firmly until it clicks into place.

Video: A brief unboxing and initial setup demonstration of the OUKITEL G1, including the process of inserting SIM cards.

4.2. Initial Power On and Setup Wizard

Press and hold the Power button on the side of the device until the OUKITEL logo appears. Follow the on-screen instructions to complete the initial setup, including language selection, Wi-Fi connection, Google account sign-in, and security settings (fingerprint/face ID setup).

5. Operating Instructions

5.1. Basic Navigation

Utilize the touchscreen for navigation. Swipe up from the bottom to access the app drawer, swipe down from the top for notifications and quick settings. Use the on-screen navigation gestures or buttons (configurable in settings) to go back, home, or view recent apps.

5.2. Camera Usage

Open the Camera app from your home screen or app drawer. Tap the shutter button to take a photo. Switch between main, macro, and front cameras using the icons on the screen. Explore various modes like Portrait, Night, and Pro for different shooting scenarios.

5.3. NFC and Google Pay

To use NFC for contactless payments or data transfer, ensure NFC is enabled in Settings > Connected devices > Connection preferences > NFC. For Google Pay, set up your cards in the Google Wallet app and hold your phone near a compatible payment terminal.

5.4. Fingerprint and Face Recognition

Set up fingerprint unlock via Settings > Security > Fingerprint. For face recognition, go to Settings > Security > Face Unlock. Follow the on-screen prompts to register your fingerprint and face for quick and secure unlocking.

6. Maintenance

6.1. Cleaning Your Device

Despite its rugged design, regular cleaning is recommended. Wipe the screen and body with a soft, lint-free cloth. For stubborn dirt, use a slightly damp cloth. Ensure all ports are dry before charging or connecting accessories, especially after exposure to water or dust.

6.2. Battery Care

To maximize battery lifespan, avoid extreme temperatures. Use only the provided charger and data cable. Do not fully discharge the battery frequently. For long-term storage, charge the battery to around 50%.

6.3. Software Updates

Regularly check for software updates to ensure optimal performance and security. Go to Settings > System > System update to check for and install available updates. Ensure your device is connected to Wi-Fi and has sufficient battery before starting an update.

7. Troubleshooting

7.1. Common Issues and Solutions

- **Device not turning on:** Ensure the battery is charged. Connect to the charger and wait a few minutes before attempting to power on again.
- **Network connectivity issues:** Check if your SIM card is properly inserted. Verify that mobile data is enabled in settings. If using T-Mobile, ensure LTE functionality is enabled. Note: AT&T SIM cards are not supported.
- **Apps crashing or freezing:** Close background apps. Clear the cache of the problematic app (Settings > Apps > [App Name] > Storage > Clear cache). Restart the device.
- **Slow performance:** Free up storage space by deleting unnecessary files or apps. Restart the device regularly.
- **Water/Dust exposure:** If the device gets wet, ensure all ports are dry before charging. Do not attempt to open the device.

If issues persist, consider performing a factory reset (Settings > System > Reset options > Erase all data (factory reset)). **Warning: This will erase all data on your device. Back up important data before proceeding.**

8. Specifications

Feature	Specification

Model Name	OUKITEL G1
Operating System	Android 14
RAM	24 GB (6GB physical + 18GB virtual)
Internal Storage (ROM)	256 GB (Expandable up to 1TB)
Display Size	6.52 Inches HD+
Main Camera	48 MP F1.8
Front Camera	5 MP F2.2
Macro Camera	2 MP
Battery Capacity	10600 mAh
Charging	18W Fast Charging
Durability Ratings	IP68/IP69K Waterproof & Dustproof, MIL-STD-810H Shockproof
Connectivity	4G Cellular, Wi-Fi, Bluetooth, NFC
Navigation	GPS, GLONASS, Beidou, Galileo
Security Features	Face ID, Rear Fingerprint Recognition
Item Weight	1.48 pounds
Dimensions	9.25 x 7.09 x 2.91 inches (Package)

9. Warranty and Support

OUKITEL provides a 2-year free maintenance service for your G1 smartphone. For any inquiries, technical assistance, or warranty claims, please contact OUKITEL official customer service. Refer to the contact information provided on the OUKITEL website or your purchase documentation.

© 2025 OUKITEL. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D89YDNF7

More documents and user manuals: **https://manuals.plus/**