Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

CANTA TU CTC26000

Canta Tu Portable Karaoke System 2024

Model: CTC26000

Brand: CANTA TU

Introduction

Welcome to the Canta Tu Portable Karaoke System 2024 user manual. This guide provides essential information for setting up, operating, and maintaining your new karaoke system. Please read these instructions carefully before using the device to ensure optimal performance and longevity.

The Canta Tu Portable Karaoke System offers a unique entertainment experience with its 14-inch touch screen, Android 12 operating system, and a powerful 40W RMS audio system. Designed for portability, it features an 8-inch woofer, a wireless microphone, and a rechargeable battery providing up to 3 hours of continuous use. Connectivity options include Wi-Fi, Bluetooth, HDMI, USB, and TF card support.

Safety Information

Important Safety Instructions:

- Do not expose the device to water or excessive moisture.
- Avoid placing the device near heat sources or in direct sunlight.
- Use only the provided power adapter for charging.
- Do not attempt to disassemble or repair the device yourself. Contact qualified service personnel.
- Keep the device out of reach of small children.
- Ensure proper ventilation around the device during use.
- No specific warnings beyond general electronic device safety apply.

Package Contents

Please check the box for the following items:

- Canta Tu Portable Karaoke System (Model CTC26000)
- Wireless Microphone (2.4G)
- Padded Shoulder Strap

- Power Adapter
- User Manual



Figure 1: Canta Tu Portable Karaoke System 2024, showing the device, wireless microphone, and product packaging.

Product Overview

Key Features:

- **14-inch Touch Screen:** Large and intuitive display for easy control and clear viewing during performances.
- **Powerful Audio System:** 40W RMS with an 8-inch woofer for exceptional sound, suitable for both indoor and outdoor use.
- **Versatile Connectivity:** Supports Wi-Fi, Bluetooth 5.3, HDMI, USB, and TF card for connecting various devices and sharing music.
- **Wireless Microphone:** Includes one 2.4G wireless microphone. A slot for a second Canta Tu wireless microphone is available (sold separately).
- **Portability and Autonomy:** Wireless design with an included padded shoulder strap and a rechargeable battery offering up to 3 hours of continuous use.



Figure 2: Front view of the Canta Tu Portable Karaoke System, highlighting the 14-inch touch screen and the included wireless microphone.



Figure 3: Side view of the Canta Tu Portable Karaoke System, showing the attachment point for the padded shoulder strap.



Figure 4: Detailed view of the Canta Tu wireless microphone, showing its design and power switch.

Setup

1. Charging the Device:

1. Connect the provided power adapter to the charging port on the back of the karaoke system.
2. Plug the adapter into a standard wall outlet.
3. The charging indicator light will illuminate. Allow the device to fully charge before first use (approximately 3-4 hours).

2. Powering On/Off:

- To power on, press and hold the power button located on the top panel until the screen illuminates.
- To power off, press and hold the power button until a shutdown prompt appears on the screen, then confirm.

3. Connecting the Wireless Microphone:

- Ensure the karaoke system is powered on.
- Insert batteries into the wireless microphone (if not already installed).
- Turn on the microphone using its power switch. The microphone should automatically pair with the karaoke system.
- Test the microphone by speaking into it and adjusting the microphone volume knob on the top panel.



Figure 5: Close-up of the top control panel, showing power button, volume knobs, and microphone input.



Figure 6: Rear view of the Canta Tu Portable Karaoke System, indicating the charging port and other connectivity options.

Operating Instructions

Using the Touch Screen:

The 14-inch touch screen operates like a standard Android tablet. Navigate through menus, select songs, and adjust settings by tapping and swiping.

Audio Controls:

- **Master Volume:** Use the main volume knob on the top panel to adjust the overall sound output.
- **Microphone Volume:** Adjust the dedicated microphone volume knob to control the microphone's output level.
- **Echo/Reverb:** Use the effect knobs to add echo or reverb to your vocals for a more professional sound.

Voice Changer:

The system includes a voice changer function. Access this feature through the on-screen menu or dedicated buttons (if available) to modify your vocal pitch and tone for fun effects.

Connectivity Options:

- **Wi-Fi:** Connect to a wireless network via the Android settings menu to access online karaoke platforms, stream music, or browse the internet.
- **Bluetooth:** Pair your smartphone or other Bluetooth-enabled devices to stream audio wirelessly to the karaoke system. Go to Android settings, enable Bluetooth, and select your device.
- **HDMI:** Connect the system to an external display (TV, projector) using an HDMI cable for a larger viewing experience.
- **USB/TF Card:** Insert a USB drive or TF (microSD) card into the respective slots to play music or video files directly from storage.

Maintenance

Cleaning:

- Wipe the screen and exterior surfaces with a soft, dry, lint-free cloth.
- For stubborn marks, slightly dampen the cloth with water or a mild, non-abrasive cleaner.
- Do not use harsh chemicals or abrasive materials, as they may damage the finish.

Storage:

- When not in use for extended periods, store the karaoke system in a cool, dry place.
- Ensure the battery is partially charged (around 50%) before storing to prolong battery life. Recharge every few months if stored for a long time.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Device does not power on.	Low battery; Power button not pressed long enough.	Charge the device; Press and hold the power button for several seconds.
No sound from speakers.	Master volume too low; Muted; External device not connected properly.	Increase master volume; Check if muted in software; Reconnect external audio source.
Microphone not working.	Microphone off; Low microphone battery; Microphone volume too low; Not paired.	Turn on microphone; Replace batteries; Increase microphone volume; Ensure microphone is paired.
Wi-Fi connection issues.	Incorrect password; Out of range; Router issue.	Verify Wi-Fi password; Move closer to router; Restart router.
Screen flickering or display issues.	Software glitch; Loose internal connection.	Restart the device; If problem persists, contact customer support.

Specifications

Feature	Detail
Model Number	CTC26000
Display	14-inch Touch Screen
Operating System	Android 12
Audio Output	40W RMS with 8-inch Woofer
Microphone	2.4G Wireless Microphone (1 included, slot for 2nd)
Connectivity	Wi-Fi, Bluetooth 5.3, HDMI, USB, TF Card
Battery Type	Lithium Polymer (1 included)
Battery Life	Up to 3 hours continuous use
Dimensions (L x W x H)	47 x 35 x 18 cm (approx. 18.5 x 13.8 x 7.1 inches)
Weight	6.84 kg (approx. 15.1 lbs)
Material	Plastic
Color	Gray
Recommended Age	8 years and up

Warranty and Support

For warranty information and customer support, please refer to the warranty card included with your product or visit the

official CANTA TU website. Keep your purchase receipt as proof of purchase for any warranty claims.
If you encounter any issues not covered in this manual, please contact CANTA TU customer service for assistance.

© 2024 CANTA TU. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D8FHDT2Z

More documents and user manuals: **https://manuals.plus/**