Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

AUNMAS AUNMASy6pnb9zeva-11

AUNMAS Robot Mop User Manual

Model: AUNMASy6pnb9zeva-11

1. Product Overview

The AUNMAS Robot Mop is designed for efficient and automatic cleaning of various hard floor surfaces, including hardwood, marble, and tiles. It features high-frequency mopping for thorough cleaning and operates with low noise for a quiet environment.



Image: Top view of the AUNMAS Robot Mop. This image displays the compact, black, square-shaped robot mop with rounded corners, featuring a central power button and a blue microfiber cleaning pad visible around its base. A USB charging cable is also shown next to the robot.



Image: Side view of the AUNMAS Robot Mop with dimensions. This image shows the robot mop from the side, highlighting its compact profile. Text overlays indicate its width as 23 cm (9.1 inches) and height as 6 cm (2.4 inches), demonstrating its ability to clean under furniture.

2. Package Contents

- AUNMAS Robot Mop
- Microfiber Cleaning Pad (pre-attached or separate)
- USB Charging Cable
- User Manual

3. Setup

3.1 Charging the Robot Mop

Before first use, fully charge the robot mop. Connect the provided USB charging cable to the charging port on the robot and plug the other end into a compatible USB power adapter (not included).



Image: Charging port under the handle. This image shows a detailed view of the robot mop's charging port, which is discreetly located under its integrated carry handle. A USB charging cable is depicted plugged into the port, illustrating the charging connection.

3.2 Attaching the Cleaning Pad

Ensure the microfiber cleaning pad is securely attached to the bottom of the robot mop. The pad is designed for easy attachment and removal.



Image: Use steps for the AUNMAS Robot Mop. This image presents a six-step visual guide for operating the robot mop. It includes instructions for preparing the cleaning pad, activating the device, attaching the pad, filling the water tank, assembling the unit, and initiating the cleaning cycle.

4. Operating Instructions

4.1 Preparing for Cleaning

1. **Wipe towel wet and wring dry:** Dampen the microfiber cleaning pad with water and wring out excess water until it is just damp, not dripping.
2. **Fill the water tank:** Locate the water tank filling port and carefully pour clean water into the tank. Ensure the cap is securely closed to prevent leakage.



Image: Preparation steps for the AUNMAS Robot Mop. This image illustrates the initial steps for using the robot mop, including dampening and wringing the cleaning pad, and filling the water tank, emphasizing proper preparation for effective cleaning.

4.2 Starting the Cleaning Cycle

1. **Turn on the chassis switch:** Locate the main power switch on the chassis of the robot and turn it to the "ON" position.
2. **Press the ON/OFF button:** Press the power button on the top of the robot to start the cleaning cycle. The robot will begin its automatic mopping process.



Image: Robot Mop controls. This image provides a close-up view of the robot mop's power button, labeled "ON/OFF," and the charging port, demonstrating the primary controls for operation and charging.

4.3 Cleaning Performance

The robot mop is designed to navigate and clean various hard floor types effectively. It can reach under furniture to clean blind areas, ensuring high coverage.



Image: Whole house cleaning, cleaning blind areas. This image shows the robot mop in action on a floor, with a graphic overlay indicating its cleaning coverage, including its capability to navigate and clean under beds and other obstacles, ensuring comprehensive cleaning of hard-to-reach spots.



Image: Easy to deal with a variety of flooring materials. This image features the robot mop positioned on a floor, with text highlighting its versatility across different surfaces such as wooden floors, marble, and tiles, demonstrating its adaptability for various household flooring types.

5. Maintenance

5.1 Cleaning the Microfiber Pad

After each use, remove the microfiber cleaning pad and wash it thoroughly with water. It can be hand-washed or machine-washed on a gentle cycle. Allow it to air dry completely before reattaching.

5.2 Cleaning the Robot

Wipe the exterior of the robot mop with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners. Ensure no water enters the charging port or other openings.

5.3 Water Tank Maintenance

Periodically rinse the water tank to prevent residue buildup. Ensure the tank is completely dry before storage if not in

immediate use.

6. Troubleshooting

Problem	Possible Cause	Solution
Robot does not turn on.	Battery is low or depleted.	Charge the robot mop fully.
Robot not mopping effectively.	Cleaning pad is too dry or dirty.	Dampen the cleaning pad and ensure it is clean. Refill water tank if empty.
Robot gets stuck frequently.	Obstacles on the floor.	Clear the cleaning area of small objects, loose cables, or thick rugs.
Water leakage from tank.	Water tank cap not sealed properly.	Ensure the water tank cap is securely closed.

7. Specifications

Feature	Detail
Brand	AUNMAS
Model Number	AUNMASy6pnb9zeva-11
Product Dimensions	41 x 30 x 7 cm (16.1 x 11.8 x 2.8 inches)
Item Weight	1.16 kg (2.56 lbs)
Cleaning Type	High-Frequency Mopping
Suitable Floor Types	Hardwood, Marble, Tiles
Noise Level	Low Noise

8. Warranty and Support

For warranty information and customer support, please refer to the purchase documentation or contact AUNMAS customer service directly. Keep your proof of purchase for any warranty claims.
Return Policy: This product is subject to a 30-day refund/replacement return policy as per Amazon's terms.
Seller: Comborte

© 2024 AUNMAS. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D8LNLJ3X

More documents and user manuals: **https://manuals.plus/**