Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZWP RC-738M

RC-738M Replacement Remote Control User Manual

Model: RC-738M

Introduction

This manual provides comprehensive instructions for the operation and maintenance of your new ZWP RC-738M remote control. Please read this manual thoroughly before use to ensure proper functionality and longevity of the device.
This replacement remote control is designed to be compatible with various Onkyo AV Receiver models, including **HT-RC160, HT-S7200, TX-SR607, TX SR607, TX-SR607B, TXSR607B**.

Setup

1. Battery Installation

The remote control requires two 1.5V AAA batteries (not included). Follow these steps to install them:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.



Figure 1: Battery Installation - This image shows the rear view of the RC-738M remote control with the battery cover removed, illustrating the correct orientation for inserting two AAA batteries. The positive and negative terminals are clearly marked.

2. Initial Use (No Programming Required)

This replacement remote control is designed for immediate use with compatible Onkyo AV Receivers. No programming or pairing is required. Once batteries are installed, the remote is ready to operate your device.



Figure 2: Ready for Use - This image depicts the RC-738M remote control positioned next to a television displaying content, accompanied by a graphic indicating that no programming or pairing is necessary for operation. Simply insert batteries and it's ready to function.

Operating Instructions

The RC-738M remote control provides full functionality for compatible Onkyo AV Receivers. Below is a general overview of key button functions.



Figure 3: Remote Control Layout - This image displays the front face of the RC-738M remote control, highlighting the arrangement and labeling of all its buttons, including power, input selectors, volume, navigation, and playback controls.

Key Functions:

- **ON/STANDBY (I/O)**: Powers the AV Receiver on or off.
- **ZONE2**: Controls functions for a second audio zone, if supported by your receiver.
- **DISPLAY**: Toggles display information on the receiver or connected TV.
- **REMOTE MODE/INPUT SELECTOR**: Buttons like DVD/BD, VCR/DVR, CBL/SAT, GAME, AUX, TV/TAPE, TUNER, PORT allow you to select the desired input source on your receiver.
- **REMOTE MODE (CD, TV, RECEIVER, MUTING)**: Switches the remote's operating mode to control other devices (e.g., TV) or directly control receiver functions like muting.

- **VOL (+/-)**: Adjusts the master volume level.
- **INPUT**: Cycles through available input sources.
- **GUIDE/TOP MENU, PREV CH/MENU**: Navigation buttons for on-screen menus.
- **Navigation Pad (Up, Down, Left, Right, ENTER)**: Used to navigate menus and confirm selections.
- **SETUP, AUDIO, RETURN**: Access setup menus, audio settings, and go back in menus.
- **Playback Controls (Rewind, Play, Fast Forward, Stop, Pause, Skip Back, Skip Forward)**: Control media playback.
- **LISTENING MODE (MOVIE/TV, MUSIC, GAME, STEREO, PLAY MODE)**: Selects different audio listening modes.
- **SEARCH, REPEAT, RANDOM**: Functions for media playback.
- **Numeric Keypad (0-9, +10, CLR)**: For direct input of channel numbers or other numerical selections.
- **D.TUN**: Digital tuner function.
- **DIMMER**: Adjusts the brightness of the receiver's display.
- **SLEEP**: Sets a sleep timer for the receiver.

Operating Range:

The remote control operates using infrared (IR) technology. For optimal performance, ensure a clear line of sight between the remote and the AV receiver. The effective operating distance is approximately 10 meters (33 feet).



Figure 4: Operating Distance - This image illustrates the RC-738M remote control being used to control a television, emphasizing its capability for long-distance and precise control via infrared technology, effective up to 10 meters or 33 feet.

Maintenance

- **Cleaning**: To clean the remote control, wipe it gently with a soft, dry cloth. Do not use liquid cleaners, sprays, or abrasive materials, as these may damage the surface or internal components.
- **Battery Replacement**: Replace batteries when the remote's response becomes sluggish or it stops functioning. Always replace both batteries at the same time with new ones of the same type (AAA).
- **Storage**: If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage to the device. Store in a cool, dry place.
- **Material**: The remote is constructed from high-quality ABS material, designed for durability and a comfortable hand feeling. The buttons are made of soft plastic.



Figure 5: Material and Features - This image highlights key features of the RC-738M remote control, including that it requires no setup, features soft plastic buttons for comfortable use, and is made from durable ABS material.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Remote not responding.	◦ Batteries are dead or incorrectly inserted. ◦ No clear line of sight to the receiver. ◦ Receiver is off or unplugged.	◦ Replace batteries with new ones, ensuring correct polarity. ◦ Remove any obstructions between the remote and the receiver. ◦ Ensure the receiver is powered on and plugged in.

Problem	Possible Cause	Solution
Limited operating range.	◦ Low battery power. ◦ Interference from strong light sources (e.g., direct sunlight).	◦ Replace batteries. ◦ Adjust lighting or position to avoid direct interference.
Specific buttons not working.	◦ Button stuck or damaged. ◦ Remote is in the wrong mode (e.g., TV mode instead of Receiver mode).	◦ Gently press the button multiple times. If still unresponsive, the button may be damaged. ◦ Press the "RECEIVER" button under "REMOTE MODE" to ensure it's controlling the AV receiver.

SPECIFICATIONS

Feature	Detail
Model Number	RC-738M
Compatible Devices	Onkyo AV Receiver models: HT-RC160, HT-S7200, TX-SR607, TX SR607, TX-SR607B, TXSR607B
Power Source	2 x 1.5V AAA Batteries (not included)
Color	Black
Material	High-quality ABS
Item Weight	2.4 ounces (approx. 68 grams)
Package Dimensions	10 x 3 x 1 inches (approx. 25.4 x 7.6 x 2.5 cm)
Special Feature	Ergonomic design, No programming required



Figure 6: Product Dimensions - This image provides multiple views (front, side, and back) of the RC-738M remote control, clearly indicating its dimensions: approximately 7.48 inches in length, 1.18 inches in thickness, and 2.16 inches in width.

Warranty and Support

This product is a replacement remote control. For any questions or issues regarding its functionality or compatibility, please contact the seller directly. The seller, ZWP-STORE, is committed to assisting with product-related inquiries. Please refer to your purchase documentation or the seller's information on the platform where you purchased the item for specific warranty details and contact methods.

© 2024 ZWP. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D8XV7Q4Y

More documents and user manuals: **https://manuals.plus/**