Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

MERACH B0D91KNHY2

MERACH Electric Mini Elliptical User Manual

Model: B0D91KNHY2 | Brand: MERACH

1. Introduction

Thank you for choosing the MERACH Electric Mini Elliptical. This compact and portable fitness device is designed to provide a low-impact exercise solution for various users, including seniors, individuals in rehabilitation, and those seeking to stay active while working or relaxing. Its quiet operation and versatile modes make it an ideal addition to any home or office environment. This manual provides essential information for the safe and effective use of your elliptical. Please read it thoroughly before operation and keep it for future reference.



Image 1.1: The MERACH Electric Mini Elliptical, showcasing its compact design and included remote control.

2. Safety Information

- Always consult with a healthcare professional before starting any new exercise program.
- Place the elliptical on a flat, stable surface. Ensure there is adequate space around the device for safe operation.
- Keep children and pets away from the elliptical during operation.
- Do not stand on the elliptical. It is designed for seated use only.
- Ensure the power cable is not damaged or tangled. Use only the provided power adapter.
- If you experience any pain, dizziness, or discomfort during exercise, stop immediately and consult a healthcare professional.
- Do not attempt to disassemble or repair the elliptical yourself. Contact customer support for assistance.

3. Product Overview and Components

The MERACH Electric Mini Elliptical is designed for ease of use and portability. Key components include:

- **Main Unit:** Houses the motor, display, and control panel.
- **Pedals:** Non-slip foot pedals for comfortable and secure use.
- **LCD Display:** Shows real-time data such as time, speed, calories, and distance.
- **Remote Control:** Allows convenient adjustment of settings without bending over.
- **Power Port:** For connecting the power adapter.



Image 3.1: The elliptical in use, demonstrating its suitability for seated exercise and rehabilitation.



Image 3.2: Illustration highlighting the ultra-quiet and smooth operation of the elliptical, with noise levels below 15dB.

4. Setup

The MERACH Electric Mini Elliptical comes 100% pre-assembled, requiring no complex installation. Simply unbox the unit, place it on a stable surface, and connect it to a power source.

What's in the Box:

- 1 x Main Elliptical Unit
- 1 x Power Cable
- 1 x Remote Control
- 1 x AAA Battery (for remote control)
- 1 x User Manual



Image 4.1: The elliptical unit straight out of the box, highlighting its pre-assembled status and portability.

5. Operating Instructions

Your MERACH elliptical offers both manual and automatic modes to suit your exercise needs.

5.1 Power On/Off

Connect the power cable to the elliptical and a wall outlet. Press the 'Power' button on the remote control or the main unit to turn the device on or off.

5.2 Using the Remote Control

The remote control allows you to conveniently adjust settings without bending down. Insert the provided AAA battery into the remote before first use.



Image 5.1: The digital display and remote control, showing various functions like distance, speed, calories, and time.

5.3 Manual Mode

In Manual Mode, you can freely adjust the speed and direction of the pedals. There are 12 adjustable speeds. Use the speed buttons on the remote or main unit to increase or decrease the speed. The pedals support both forward and backward movement.



Image 5.2: Visual representation of the 12 adjustable speeds available in Manual Mode.

5.4 Automatic Mode

The Automatic Mode offers 12 pre-set programs (P1-P12) that automatically change the direction and speed for a varied workout. These programs are designed for different purposes:

- **P1-P4:** Assisted Training
- **P5-P8:** Functional Training
- **P9-P12:** Rehabilitation Training

The device will automatically shut off after 15 minutes of continuous use to protect its components and prolong its lifespan. This is normal behavior. To continue your workout, simply restart the device.



Image 5.3: Overview of the Automatic Mode, detailing the different program categories.

5.5 Digital Display

The LCD display provides real-time feedback on your workout. It cycles through and shows:

- **Time:** Duration of your exercise session.
- **Speed:** Current pedaling speed.
- **Calories:** Estimated calories burned.
- **Distance:** Estimated distance covered.

6. Maintenance

Regular maintenance will help prolong the life of your MERACH elliptical.

6.1 Cleaning

Wipe down the elliptical with a soft, damp cloth after each use to remove dust and sweat. Do not use abrasive cleaners or solvents, as these may damage the finish or electronic components. Ensure the device is unplugged before cleaning.

6.2 Storage

Store the elliptical in a cool, dry place away from direct sunlight and extreme temperatures. Its compact size allows for easy storage under a desk or in a closet.

7. Troubleshooting

If you encounter any issues with your MERACH elliptical, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Device does not power on.	Power cable not connected; Power outlet issue.	Ensure the power cable is securely plugged into both the elliptical and a working wall outlet. Try a different outlet.
Elliptical stops after 15 minutes.	Automatic safety shut-off feature.	This is normal. Restart the device to continue your workout.
Remote control not working.	Battery low or incorrectly inserted; Obstruction between remote and unit.	Check and replace the AAA battery. Ensure there is a clear line of sight between the remote and the elliptical's sensor.
Pedals are not moving smoothly.	Debris caught in mechanism; Unit not on a flat surface.	Inspect for any obstructions. Ensure the elliptical is on a flat, stable surface.

8. Specifications

Feature	Specification
Display Type	LCD
Maximum Speed	12 Revolutions per minute
Maximum Stride Length	45 Centimeters
Number of Resistance Levels	12
Operating Mode	Manual / Automatic
Power Source	Wired Electric
Product Dimensions (L x W x H)	49.5 x 43 x 30 cm
Product Weight	7.57 Kilograms

Feature	Specification
Number of Programs	12 (Automatic Mode)
Batteries Included	Yes (1x AAA for remote)
Color	Black
Material	Aluminum
Control Type	Remote Control

9. Warranty and Support

Your MERACH Electric Mini Elliptical is covered by a return policy allowing for refund or replacement within 30 days of purchase. For any product-related inquiries, technical support, or warranty claims, please contact the seller, MERACH Direct EU, through your Amazon purchase history. Please have your model number (B0D91KNHY2) and purchase date ready when contacting support.

© 2025 MERACH. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D91KNHY2

More documents and user manuals: **https://manuals.plus/**