Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Lehwey Y-CD-146

Lehwey Portable CD Player Instruction Manual

Model: Y-CD-146 | Brand: Lehwey

Introduction

Thank you for choosing the Lehwey Portable CD Player. This versatile device combines classic audio playback with modern connectivity options, including Bluetooth, FM radio, USB, and AUX inputs. Designed for ease of use and high-quality sound, this manual will guide you through the setup, operation, and maintenance of your new CD player to ensure a seamless audio experience.

What's in the Box

Please check the package contents to ensure all items are present:

- CD Player
- 1.5m Type-C Charging Cable
- Adapter
- Remote Control
- User Manual



Figure 1: Package Contents. The image displays the Lehwey Portable CD Player along with its accessories: a remote control, user manual, 5V-2A USB adapter, Type-C charging cable, and a 3.5mm AUX cable.

Product Overview

Familiarize yourself with the various components and controls of your Lehwey CD Player:



Figure 2: Product Components. This diagram highlights the key parts of the CD player, including control buttons, ports, and features.

Table 1: Component Functions

No.	Component	Function
1	Mode (Press Button)/Volume	Press to switch modes (CD, Bluetooth, FM, USB, AUX). Rotate to adjust volume.
2	Play/Pause	Starts or pauses playback.
3	Next	Skips to the next track/station.
4	Previous	Skips to the previous track/station.
5	Bluetooth Connection	Activates Bluetooth pairing mode.
6	Built-in Dual Speakers	Provides stereo audio output.

No.	Component	Function
7	Dustproof Cover	Protects the CD mechanism from dust.
8	Music Fiber Optics	(Functionality not detailed in source, likely decorative or indicator)
9	Headphone Jack	3.5mm output for private listening.
10	AUX Socket	3.5mm input for connecting external audio devices.
11	USB Port	For playing audio from USB drives.
12	DC IN 5V	Power input port.
13	Power Switch	Turns the device on or off.
14	Turntable Arm Switch	(Functionality not detailed in source, likely related to CD playback initiation)

Setup

1. **Unpacking:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.
2. **Power Connection:** Connect the provided Type-C charging cable to the DC IN 5V port (12) on the back of the CD player. Plug the other end into the adapter, then into a standard wall outlet.



Figure 3: Power Connection. The image shows the Type-C cable connected to the DC IN 5V port on the back of the unit.

3. **Power On:** Locate the Power Switch (13) on the back of the unit and slide it to the "ON" position. The LED indicator light will illuminate.

4. **Remote Control Setup:** Insert 2 AAA batteries (not included) into the remote control.

Operating Instructions

CD Mode

1. **Insert CD:** Gently lift the Dustproof Cover (7). Place a CD (CD, CD-R, CD-RM, CD-G, MP3, WMA, WAV compatible) onto the spindle. Ensure the CD is seated correctly.
2. **Select CD Mode:** Press the Mode button (1) until "CD Mode" is announced or indicated.
3. **Play/Pause:** Press the Play/Pause button (2) to start or pause playback.
4. **Skip Tracks:** Use the Next (3) and Previous (4) buttons to navigate between tracks.
5. **Adjust Volume:** Rotate the Mode/Volume knob (1) clockwise to increase volume and counter-clockwise to decrease.



Figure 4: CD Playback. The player is shown with a CD ready for playback.

Your browser does not support the video tag.

Video 1: CD Playback Demonstration. This video demonstrates the CD player in action, showing the disc spinning and audio playback.

Bluetooth Mode (Receiver & Transmitter)

The CD player supports Bluetooth 5.0 for both receiving audio from your devices and transmitting audio to Bluetooth headphones/speakers.

1. **Activate Bluetooth:** Press the Mode button (1) until "Bluetooth Mode" is announced. The LED indicator will flash, indicating pairing mode.
2. **Pairing (Receiver):** On your smartphone, tablet, or other Bluetooth-enabled device, search for "Lehwey CD Player" in the Bluetooth settings and select it to pair. Once connected, a confirmation sound will play.
3. **Pairing (Transmitter):** To transmit audio from the CD player to Bluetooth headphones or speakers, ensure your

headphones/speakers are in pairing mode. The CD player will automatically search and connect to nearby devices.



Figure 5: Bluetooth Connectivity. This image illustrates how the CD player can connect to various Bluetooth devices.

FM Radio Mode

1. **Select FM Mode:** Press the Mode button (1) until "FM Radio Mode" is announced.
2. **Auto-Scan:** Press and hold the Play/Pause button (2) to initiate an automatic scan for available FM stations. The player will save found stations.
3. **Tune Stations:** Use the Next (3) and Previous (4) buttons to switch between saved FM stations.

USB Mode

1. **Insert USB Drive:** Insert a USB flash drive into the USB Port (11) on the back of the unit.
2. **Select USB Mode:** Press the Mode button (1) until "USB Mode" is announced. The player will automatically begin playing compatible audio files from the USB drive.
3. **Control Playback:** Use the Play/Pause (2), Next (3), and Previous (4) buttons to control playback.



Figure 6: USB Connection. The image shows a USB drive connected to the player's USB port.

AUX Mode

Connect external audio devices (e.g., MP3 players, smartphones without Bluetooth) using the AUX input.

1. **Connect AUX Cable:** Connect one end of a 3.5mm AUX cable (included) to the AUX Socket (10) on the back of the CD player. Connect the other end to the headphone jack or audio output of your external device.
2. **Select AUX Mode:** Press the Mode button (1) until "AUX Mode" is announced.
3. **Play Audio:** Play audio from your external device. The sound will be routed through the CD player's speakers.



Figure 7: AUX Connection. The image shows an AUX cable connected to the player's AUX port.

Remote Control Usage

The included remote control allows for convenient operation from a distance. Point the remote directly at the front of the CD player for optimal response.



Figure 8: Remote Control in Use. This image shows the remote control being used to operate the CD player from a comfortable distance.
Refer to the remote control diagram in the included User Manual for specific button functions.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the CD player. For stubborn marks, slightly dampen the cloth with water. Do not use abrasive cleaners or solvents.
- **CD Care:** Handle CDs by their edges to avoid fingerprints and scratches. Store CDs in their cases when not in use.
- **Dust Protection:** Keep the dustproof cover closed when the CD player is not in use to prevent dust accumulation on the CD mechanism.
- **Storage:** If storing the unit for an extended period, disconnect it from power and store it in a cool, dry place.

Troubleshooting

If you encounter any issues with your Lehwey Portable CD Player, please refer to the following common problems and solutions:

Table 2: Common Troubleshooting Steps

Problem	Possible Cause	Solution
No power	Power cable not connected; Power switch off; Outlet malfunction.	Ensure power cable is securely connected. Turn the Power Switch (13) to ON. Try a different power outlet.
CD not playing / Skipping	CD dirty or scratched; Incorrect CD format; CD not seated properly.	Clean the CD with a soft, lint-free cloth. Ensure the CD format is compatible (CD, CD-R, CD-RM, CD-G, MP3, WMA, WAV). Re-insert the CD, ensuring it is flat on the spindle.
No sound	Volume too low; Incorrect mode selected; External device volume low (AUX mode).	Increase the volume using the Mode/Volume knob (1) or remote. Ensure the correct mode (CD, Bluetooth, FM, USB, AUX) is selected. If using AUX, check the volume on the connected external device.
Bluetooth not connecting	Device not in pairing mode; Out of range; Interference.	Ensure the CD player is in Bluetooth Mode (5) and flashing. Make sure your external device's Bluetooth is on and searching. Move devices closer. Avoid strong electromagnetic interference.
Remote control not working	Batteries dead or incorrectly inserted; Obstruction between remote and player.	Replace batteries (2 AAA). Ensure batteries are inserted with correct polarity. Remove any obstructions and point the remote directly at the player.

Specifications

Table 3: Product Specifications

Feature	Detail
Product Dimensions	6.3 x 3.15 x 7.87 inches (L x W x H)
Item Weight	1.98 pounds
Model Number	Y-CD-146
Brand	Lehwey
Connectivity Technology	Bluetooth, Auxiliary, USB
Color	Brown
Speaker Type	Stereo

Feature	Detail
Power Input	DC 5V
FM Frequency Range	76MHz-108MHz
Compatible CD Formats	CD, CD-R, CD-RM, CD-G, MP3, WMA, WAV



Figure 9: Product Dimensions. This image provides a visual representation of the CD player's physical dimensions.

Warranty and Support

The Lehwey Portable CD Player comes with a manufacturer's warranty. For detailed warranty information, technical support, or service inquiries, please refer to the contact information provided on the product packaging or visit the official Lehwey website. Please retain your purchase receipt as proof of purchase for warranty claims.

© 2025 Lehwey. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Can I fast-forward and rewind CD tracks on the Lehwey Y-CD-146 Portable CD Player?

Based on the instruction manual for the Lehwey Y-CD-146, the device features Next and Previous buttons for navigating between tracks. While the manual explicitly mentions using these buttons to "skip tracks," it does not...

Read full answer

Open the live page

https://manuals.plus/asin/B0D9H8T52V

More documents and user manuals: **https://manuals.plus/**