Eureka E20 Plus

Eureka E20 Plus Robot Vacuum Cleaner User Manual

Model: E20 Plus (NERE20PLUSBK)

1. Introduction

The Eureka E20 Plus is an advanced robot vacuum cleaner designed to simplify your home cleaning routine. Featuring powerful 8000 Pa suction, an innovative self-emptying station, intelligent mop lifting, and precise 3D obstacle avoidance, this device offers a comprehensive and hands-free cleaning experience. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your Eureka E20 Plus to ensure optimal performance and longevity.

2. Safety Information

Please read all safety instructions carefully before using the appliance and keep this manual for future reference. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- This appliance is for indoor household use only. Do not use outdoors or on commercial/industrial surfaces.
- Do not allow children to play with the appliance. Supervise children and pets when the robot is operating.
- Do not handle the power cord or plug with wet hands.
- Do not vacuum liquids, burning or smoking objects (e.g., hot ashes, cigarettes), or large, sharp objects.
- Ensure the charging station is placed on a level surface against a wall, with adequate clear space around it.
- Turn off the robot and unplug the charging station before performing any maintenance or cleaning.
- Use only the original charging station and power adapter provided by Eureka.
- Do not attempt to repair or modify the appliance yourself. Contact authorized service personnel for repairs.

3. Package Contents

Verify that all items are present and in good condition upon unpacking. If any items are missing or damaged, please contact Eureka customer support.



Image: The Eureka E20 Plus robot vacuum, its self-emptying station, and all standard accessories including two side brushes, a main roller brush, two HEPA filters, and two mop pads.

- Eureka E20 Plus Robot Vacuum Cleaner
- Self-Emptying Station
- Cleaning Pad x 2 (1 pre-installed)
- Side Brushes x 2
- HEPA Filter x 2 (pre-installed)
- Main Brush x 1 (pre-installed)
- Instruction Manual x 1

4. Product Overview

4.1 Robot Vacuum Cleaner

The robot vacuum is equipped with advanced sensors and cleaning mechanisms for efficient navigation and debris collection.

- **LiDAR Navigation Sensor:** Located on top, for precise mapping and navigation.
- **Front Bumper:** Contains anti-collision sensors.
- **Side Brushes:** Two brushes on the front-sides to sweep debris into the main brush path.
- **Main Brush:** Located underneath, designed with an anti-tangle structure for effective cleaning.
- **Dustbin & Water Tank:** Integrated unit for dry vacuuming and wet mopping.
- **Mop Pad:** Attaches to the water tank for mopping functions.
- **Charging Contacts:** Located on the underside, for connecting to the self-emptying station.

4.2 Self-Emptying Station

The station serves as both a charging dock and an automatic dust collection unit.

- **Dust Collection Port:** Connects to the robot's dustbin for automatic emptying.
- **Bagless Dustbin:** Large 2-liter capacity, transparent for easy monitoring, and designed for bagless operation.
- **Charging Contacts:** Align with the robot's contacts for recharging.

5. Setup

5.1 Station Placement

Place the self-emptying station on a hard, level surface against a wall. Ensure there is at least 0.5 meters (1.6 feet) of clear space on both sides and 1.5 meters (4.9 feet) in front of the station for optimal robot navigation.

5.2 Initial Charging

Connect the power adapter to the station and plug it into a wall outlet. Place the robot onto the charging contacts. The robot will begin charging. For first use, fully charge the robot (approximately 6 hours).

5.3 App Download and Connection

Download the "Eureka" app from your smartphone's app store. Follow the in-app instructions to connect your robot. Ensure your Wi-Fi network is 2.4GHz, as the robot is only compatible with this frequency.

5.4 Initial Mapping

Once connected, initiate a full cleaning cycle from the app. The robot will create a map of your home, which can then be used for customized cleaning plans, virtual walls, and no-go zones.

6. Operation

6.1 Starting a Cleaning Cycle

Press the power button on the robot or use the Eureka app to start a cleaning cycle. The robot will automatically return to the station to empty its dustbin and recharge as needed.

6.2 Cleaning Modes

- **Auto Clean:** The robot intelligently cleans the entire mapped area.

- **Spot Clean:** Directs the robot to clean a specific small area intensely.
- **Zone Clean:** Select specific rooms or areas on the map for cleaning via the app.
- **Scheduled Clean:** Set specific times for the robot to automatically clean.

6.3 Suction Power and Mopping



Image: The underside of the robot vacuum illustrating its powerful 8000 Pa suction capability.

The E20 Plus offers three adjustable suction levels (8000 Pa max) for different cleaning needs. When mopping, the intelligent mop lifting feature automatically raises the mop by 10mm when detecting carpets or no-mop zones, preventing wetting and staining.



Image: The robot vacuum automatically lifting its mop pad by 10mm as it transitions from hard floor to carpet, ensuring carpets remain dry.

6.4 Obstacle Avoidance and Navigation



Image: A visual representation of the robot vacuum's 3D DuoDetect AI technology, showing how it detects and avoids obstacles like shoes and small objects.

Equipped with 3D DuoDetect AI technology, the E20 Plus precisely navigates and avoids obstacles, even in low-light conditions, ensuring a thorough and uninterrupted cleaning path.

6.5 Voice Control



Image: The robot vacuum shown with logos for Amazon Alexa, Google Assistant, and Siri, indicating its compatibility with these voice control platforms.

Control your Eureka E20 Plus using voice commands through Amazon Alexa or Google Assistant for convenient hands-free operation.

7. Maintenance

Regular maintenance ensures your Eureka E20 Plus operates at peak performance. Always turn off the robot and unplug the station before performing maintenance.

7.1 Self-Emptying Station Dustbin



Image: The self-emptying station with a visual representation of its 45-day hands-free operation, showing the transparent dustbin being emptied.

The 2-liter bagless dustbin in the self-emptying station can hold debris for up to 45 days, significantly reducing manual emptying frequency. Periodically check and empty the station's dustbin as needed. The multi-cyclone dust collection system filters 98% of dust and dirt.



Image: A close-up of the multi-cyclone dust collection system within the self-emptying station, highlighting its efficiency in filtering dust.

7.2 Robot Dustbin and Water Tank

Empty the robot's internal dustbin and refill the water tank after each mopping session or as needed. Rinse the dustbin and water tank with clean water and allow them to air dry completely.

7.3 Main Brush



Image: A comparison showing the anti-tangle brush design of the Eureka E20 Plus (left) against a traditional brush (right), emphasizing its effectiveness in preventing hair entanglement.

Remove the main brush cover and lift out the main brush. Use the cleaning tool (if provided) to remove any tangled hair or debris. The anti-tangle design minimizes hair wrapping, but regular checks are recommended.

7.4 Side Brushes

Check the side brushes for wear or damage. If they are bent or worn, replace them. Clean any hair or debris wrapped around the base of the brushes.

7.5 HEPA Filter

Tap the HEPA filter gently to remove dust. Do not wash the HEPA filter with water. Replace the HEPA filter every 3-6 months, depending on usage.

7.6 Mop Pad

Remove the mop pad after each use and wash it with water. Allow it to air dry completely before reattaching.

7.7 Sensors and Charging Contacts

Wipe all sensors (LiDAR, cliff, anti-collision) and charging contacts on both the robot and the station with a clean, dry cloth to ensure proper function.

8. Troubleshooting

Problem	Possible Cause	Solution
Robot does not charge.	Charging contacts are dirty or misaligned. Station is not powered.	Clean charging contacts on both robot and station. Ensure station is plugged in and powered.
Robot gets stuck frequently.	Too many obstacles. Sensors are dirty.	Clear clutter from the cleaning area. Clean all sensors on the robot.
Poor cleaning performance.	Dustbin full. Brushes tangled. Filter clogged.	Empty robot dustbin and station dustbin. Clean main brush and side brushes. Clean or replace HEPA filter.
App connection issues.	Incorrect Wi-Fi frequency (not 2.4GHz). Weak Wi-Fi signal.	Ensure your router is set to 2.4GHz. Move robot closer to the router. Restart robot and router.
Station not emptying robot.	Station dustbin full. Obstruction in emptying port.	Empty station dustbin. Check for and remove any blockages in the station's emptying port.

9. Specifications

Feature	Detail
Brand	Eureka
Model Number	NERE20PLUSBK
Dimensions (L x W x H)	35 x 35 x 9.7 cm (13.8 x 13.8 x 3.8 inches)
Weight	10.63 kg (23.4 lbs)
Suction Power	8000 Pa (Max)
Battery Capacity	5200 mAh
Runtime	Up to 180 minutes (3 hours)
Self-Emptying Station Dustbin Capacity	2 Liters (up to 45 days hands-free)
Noise Level	65 dB
Filter Type	HEPA
Connectivity	2.4GHz Wi-Fi
Voice Assistant Compatibility	Amazon Echo, Google Home

Feature	Detail
Special Features	3D DuoDetect AI Obstacle Avoidance, Intelligent Mop Lifting (10mm), Bagless Auto-Emptying

10. Warranty and Support

Warranty information for your Eureka E20 Plus is typically provided with your purchase documentation. Please refer to the warranty card or contact your retailer for specific terms and conditions.

For technical support, troubleshooting assistance, or to inquire about replacement parts, please visit the official Eureka website or contact their customer service department. Information regarding spare parts availability is not provided in this manual.

Official Website: www.eureka.com (Please note: This is a placeholder URL. Refer to your product packaging for the correct support website.)

© 2025 Eureka. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question