Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SICOTAS DR006

SICOTAS Rattan Dresser (Model DR006) User Manual

For the 57" Wide 6-Drawer Dresser in Reclaimed Caramel Oak

1. Introduction

Welcome to your new SICOTAS Rattan Dresser. This manual provides essential information for the assembly, safe operation, and maintenance of your 57-inch wide, 6-drawer dresser. Please read these instructions thoroughly before beginning assembly or use to ensure proper setup and longevity of your furniture.



The SICOTAS Rattan Dresser, showcasing its elegant design and ample storage capacity.

2. Important Safety Information

Your safety is paramount. Please adhere to the following guidelines to prevent injury or damage.

- **Tip-Over Prevention:** This dresser meets the criteria outlined in safety standard (ASTM 2057–2023) for Clothing Storage Units to protect children from tip-over-related injury. Always use the included anti-tip kit to securely anchor the dresser to a wall.
- **Stability:** To further enhance its stability, ensure all assembly screws are securely fastened. Periodically check and tighten all fasteners.
- **Assembly Surface:** Assemble the dresser on a soft, clean, and flat surface to prevent scratches or damage to the furniture.
- **Small Parts:** Keep all small parts and hardware out of reach of children during and after assembly.
- **Weight Distribution:** Distribute weight evenly across drawers and the top surface to maintain balance and prevent tipping.

3. Package Contents

Before beginning assembly, please verify that all components listed below are present and undamaged. All parts are clearly labeled for your convenience.

- Dresser Panels (Top, Bottom, Sides, Back)
- Drawer Fronts with Rattan Inlay (6 pieces)
- Drawer Sides and Backs
- Drawer Bottoms
- Gold Handles (6 pieces)
- Steel Ball-Bearing Drawer Slides (sets for 6 drawers)
- Assembly Hardware (screws, dowels, cam locks, etc.)
- Anti-Tip Kit
- Instruction Manual

4. Setup and Assembly

Assembly is required for this product. Please follow the detailed instructions provided in the included manual. For a visual guide, refer to the installation video below.

Tools Required

- Phillips Head Screwdriver
- Hammer (for dowels, if applicable)

Step-by-Step Assembly

1. Unpack all components and lay them out on a soft, clean surface. Verify all parts are present against the package contents list.
2. Attach the main frame panels (sides, top, bottom) using the provided hardware.
3. Assemble each of the six drawers by attaching the sides, back, and bottom to the rattan front panel.
4. Install the steel ball-bearing drawer slides onto both the dresser frame and the assembled drawers.
5. Insert the assembled drawers into the dresser frame.
6. Attach the gold handles to each drawer front.
7. Securely install the anti-tip kit to the back of the dresser and anchor it to a wall stud.

Installation Guide Video

▶ **Watch video online**

Dresser Installation Guide

Official installation guide for the SICOTAS Rattan Dresser, demonstrating step-by-step assembly.

Product Dimensions



Refer to this diagram for overall product dimensions and individual drawer measurements.

5. Operating Instructions

Your SICOTAS dresser is designed for ease of use and ample storage.

Drawer Functionality

The six spacious drawers are equipped with steel ball-bearing slides, ensuring superior smoothness and strength. They glide effortlessly for easy opening and closing, even when fully loaded. The gold handles provide a comfortable grip and complement the rattan design.



The generously sized drawers offer ample storage, capable of holding numerous clothing items or other belongings.

Versatile Placement

This dresser is suitable for various rooms and purposes. While ideal for bedroom storage, its sturdy construction and aesthetic design also make it a functional and stylish TV stand for your living room or a large chest of drawers for a closet.



The dresser's robust design allows it to function effectively as a TV stand.

6. Care and Maintenance

Proper care will help maintain the beauty and functionality of your dresser for years to come.

- **Cleaning:** Wipe the surfaces with a dry, soft cloth. Avoid using abrasive cleaners, harsh chemicals, or excessive moisture, as these can damage the wood finish and rattan.
- **Spills:** Immediately wipe up any spills with a dry cloth to prevent staining or water damage.
- **Hardware:** Periodically check all screws and fasteners and tighten them as needed to ensure the dresser remains stable and secure.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight to prevent fading or discoloration of the wood and rattan.

7. Troubleshooting

If you encounter any issues with your dresser, refer to the common problems and solutions below.

Drawers not closing/opening smoothly

- Check for any obstructions within the drawer or along the drawer slides.
- Ensure the drawer slides are properly aligned and securely attached to both the drawer and the dresser frame. Tighten any loose screws.
- Verify that the dresser is placed on a level surface. Uneven flooring can cause misalignment.

Dresser feels unstable or wobbly

- Confirm that all assembly screws and connections are fully tightened.
- Ensure the anti-tip kit is correctly installed and securely anchored to a wall stud.
- Avoid placing excessively heavy items on one side of the dresser or in a single drawer. Distribute weight evenly.

8. Product Specifications

Feature	Detail
Brand	SICOTAS
Model Name	Dresser (DR006)
Product Dimensions	17.72"D x 56.85"W x 31.34"H
Color	Reclaimed Caramel Oak
Material	Engineered Wood
Finish Type	Wood Grain
Number of Drawers	6
Item Weight	118.8 pounds (54 Kilograms)
Assembly Required	Yes
Product Care Instructions	Wipe with Dry Cloth
UPC	635508493537
ASIN	B0DB7BHXZV

9. Warranty Information

For specific warranty details regarding your SICOTAS Rattan Dresser, please refer to any documentation included with your original purchase. If no specific warranty information is provided, please contact SICOTAS customer service for assistance.

10. Customer Support

Should you have any questions, require assistance with assembly, or need to report missing or damaged parts, our friendly customer service team is ready to help.

Please visit the SICOTAS Store on Amazon for more information or to contact support.

© 2026 SICOTAS. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DB7BHXZV

More documents and user manuals: **https://manuals.plus/**